

20" Planer

(Model RC-51)

INSTRUCTION MANUAL



DATED 1-20-92

PART NO. 1345297

© Delta International Machinery Corp. 1992

 **DELTA**

TABLE OF CONTENTS

SAFETY RULES	3
ADDITIONAL SAFETY RULES FOR PLANERS	4
UNPACKING AND CLEANING THE MACHINE	4
ASSEMBLING DUST CHUTE	5
ELECTRICAL CONNECTIONS	5
OPERATING CONTROLS	
On/Off Controls	6
Raising And Lowering The Table	6
Feed Roll Speeds	7
Table Rollers	8
Anti-Kickback Fingers	8
ADJUSTMENTS	
Checking And Adjusting Drive Belt Tension	9
Checking And Adjusting Feed Roll Belt Tension	9
Checking, Adjusting And Replacing Knives	10
Adjusting Spring Tension On Feed Rollers	11
Adjusting Chipbreakers	11
Adjusting Pressure Bar	12
Adjusting Outfeed Roller	12
Adjusting Chip Deflector	13
Adjusting Table Height Scale	14
Checking And Adjusting Bed Roll Height	14
Leveling The Table	16
LUBRICATION	17
GAGE BLOCK	17
AUTHORIZED SERVICE STATIONS	18-19
PARTS, SERVICE AND WARRANTY ASSISTANCE	20
WARRANTY	20

SAFETY RULES

As with all machinery there are certain hazards involved with operation and use of the machine. Using the machine with respect and caution will considerably lessen the possibility of personal injury. However, if normal safety precautions are overlooked or ignored, personal injury to the operator may result.

This machine was designed for certain applications only. Delta Machinery strongly recommends that this machine NOT be modified and/or used for any application other than for which it was designed. If you have any questions relative to its application DO NOT use the machine until you have written Delta Machinery and we have advised you.

**DELTA INTERNATIONAL MACHINERY CORP.
MANAGER OF TECHNICAL SERVICES**

246 ALPHA DRIVE

PITTSBURGH, PENNSYLVANIA 15238

(IN CANADA: 644 IMPERIAL ROAD, GUELPH, ONTARIO N1H 6M7)

WARNING: FAILURE TO FOLLOW THESE RULES MAY RESULT IN SERIOUS PERSONAL INJURY

- 1. FOR YOUR OWN SAFETY, READ INSTRUCTION MANUAL BEFORE OPERATING THE TOOL.** Learn the tool's application and limitations as well as the specific hazards peculiar to it.
- 2. KEEP GUARDS IN PLACE** and in working order.
- 3. ALWAYS WEAR EYE PROTECTION.**
- 4. GROUND ALL TOOLS.** If tool is equipped with three-prong plug, it should be plugged into a three-hole electrical receptacle. If an adapter is used to accommodate a two-prong receptacle, the adapter lug must be attached to a known ground. Never remove the third prong.
- 5. REMOVE ADJUSTING KEYS AND WRENCHES.** Form habit of checking to see that keys and adjusting wrenches are removed from tool before turning it "on."
- 6. KEEP WORK AREA CLEAN.** Cluttered areas and benches invite accidents.
- 7. DON'T USE IN DANGEROUS ENVIRONMENT.** Don't use power tools in damp or wet locations, or expose them to rain. Keep work area well-lighted.
- 8. KEEP CHILDREN AND VISITORS AWAY.** All children and visitors should be kept a safe distance from work area.
- 9. MAKE WORKSHOP CHILDPROOF** - with padlocks, master switches, or by removing starter keys.
- 10. DON'T FORCE TOOL.** It will do the job better and be safer at the rate for which it was designed.
- 11. USE RIGHT TOOL.** Don't force tool or attachment to do a job for which it was not designed.
- 12. WEAR PROPER APPAREL.** No loose clothing, gloves, neckties, rings, bracelets, or other jewelry to get caught in moving parts. Nonslip foot wear is recommended. Wear protective hair covering to contain long hair.
- 13. ALWAYS USE SAFETY GLASSES.** Wear safety glasses (must comply with ANSI Z87.1). Everyday eyeglasses only have impact resistant lenses; they are not safety glasses. Also use face or dust mask if cutting operation is dusty.
- 14. SECURE WORK.** Use clamps or a vise to hold work when practical. It's safer than using your hand and frees both hands to operate tool.
- 15. DON'T OVERREACH.** Keep proper footing and balance at all times.
- 16. MAINTAIN TOOLS IN TOP CONDITION.** Keep tools sharp and clean for best and safest performance. Follow instructions for lubricating and changing accessories.
- 17. DISCONNECT TOOLS** before servicing and when changing accessories such as blades, bits, cutters, etc.
- 18. USE RECOMMENDED ACCESSORIES.** The use of improper accessories may cause hazards.
- 19. AVOID ACCIDENTAL STARTING.** Make sure switch is in "OFF" position before plugging in power cord.
- 20. NEVER STAND ON TOOL.** Serious injury could occur if the tool is tipped or if the cutting tool is accidentally contacted.
- 21. CHECK DAMAGED PARTS.** Before further use of the tool, a guard or other part that is damaged should be carefully checked to ensure that it will operate properly and perform its intended function - check for alignment of moving parts, binding of moving parts, breakage of parts, mounting, and any other conditions that may affect its operation. A guard or other part that is damaged should be properly repaired or replaced.
- 22. DIRECTION OF FEED.** Feed work into a blade or cutter against the direction of rotation of the blade or cutter only.
- 23. NEVER LEAVE TOOL RUNNING UNATTENDED. TURN POWER OFF.** Don't leave tool until it comes to a complete stop.
- 24. DRUGS, ALCOHOL, MEDICATION.** Do not operate tool while under the influence of drug, alcohol or any medication.
- 25. MAKE SURE TOOL IS DISCONNECTED FROM POWER SUPPLY** while motor is being mounted, connected or reconnected.
- 26. WARNING:** The dust generated by certain woods and wood products can be injurious to your health. Always operate machinery in well ventilated areas and provide for proper dust removal. Use wood dust collection systems whenever possible.

ADDITIONAL SAFETY RULES FOR PLANERS

1. **IF YOU ARE NOT** thoroughly familiar with the operation of planers, obtain advice from your supervisor, instructor or other qualified person.
2. **MAKE SURE** wiring codes and recommended electrical connection instructions are followed, and that the machine is properly grounded.
3. **MAKE** all adjustments with the power off.
4. **DISCONNECT** machine from power source when making repairs.
5. **KEEP** fingers and hands away from chip exhaust opening. The cutterhead rotates at extremely high speeds.
6. **NEVER** feed the work into the outfeed end of machine.
7. **ADEQUATELY** support the workpiece at all times.
8. **NEVER** start the machine with the workpiece in contact with the cutterhead.
9. **MAKE SURE** the workpiece is free from nails and other foreign objects which could cause injury or damage to the blades.

10. **MAKE SURE** the blades are properly secured in the cutterhead, as explained in the instruction manual, before turning on power.

11. **ALWAYS** allow the cutterhead to reach full speed before using.

12. **DO NOT** perform planing operations on material shorter than 14 inches, or wider than 20 inches.

13. **ADDITIONAL INFORMATION** regarding the safe and proper operation of this product is available from the National Safety Council, 444 N. Michigan Avenue, Chicago, IL 60611 in the Accident Prevention Manual for Industrial Operation and also in the Safety Data Sheets provided by the NSC. Please also refer to the American National Standards Institute ANSI 01.1 Safety Requirements for Woodworking Machine and the U.S. Department of Labor OSHA 1910.213 Regulations.

UNPACKING AND CLEANING THE MACHINE

Carefully remove the planer from the shipping crate. The planer is shipped complete with motor, motor pulley and belts assembled to the machine.

IN ORDER TO PROPERLY CLEAN THE MACHINE, PROCEED AS FOLLOWS:

1. Turn lock knob (A) Fig. 2, counterclockwise. **NOTE:** If it is necessary to lower the table to facilitate cleaning, turn handwheel (B) counterclockwise until table is at the desired height for cleaning.
2. Completely loosen and remove lock knob (A) Fig. 2, and handwheel (B) from the planer.
3. Loosen two screws (C) Fig. 2, and swing open side covers (D).
4. Remove two screws (E) Fig. 3, from the rear of the machine and carefully lift off top cover (F), exposing the feed rolls, cutterhead, and cutterhead knives as shown in Fig. 4.
5. Remove the protective coating from the table, bed rollers, infeed roller, anti-kickback fingers, cutterhead and cutterhead knives. This coating may be removed with a soft cloth moistened with kerosene. **(DO NOT USE GASOLINE, ACETONE OR LACQUER THINNER FOR THIS PURPOSE.) CAUTION: EXTREME CARE MUST BE TAKEN WHEN CLEANING THE CUTTERHEAD BECAUSE THE CUTTING KNIVES ARE POSITIONED IN THE CUTTERHEAD AND ARE VERY SHARP!**
6. After cleaning, cover the table surface with a good quality paste wax.
7. Replace top cover, handwheel and lock knob which were removed in **STEPS 2** and **4**.



Fig. 2




Fig. 3




Fig. 4

ASSEMBLING DUST CHUTE

To assemble the dust chute to your planer, remove the three screws (A) Fig. 5, from the rear of the planer. The dust chute is then assembled to the rear of the planer, as shown in Fig. 6, and fastened in place using the three screws (A) Fig. 5.

ELECTRICAL CONNECTIONS

Before connecting your machine to an electrical power system, make sure the motor rating agrees with the electrical system it is to be connected to. The single phase planer is shipped wired for 230 volts only and the three phase planer is shipped wired for 230 volts unless 460 volts was specified. In all cases remove the black terminal strip cover (A) Fig. 7, located on the rear of the machine. Bring the power line up through the connector located on bottom of the terminal strip cover and proceed as follows:

If single phase, connect the two power lines to terminals L1 and L2 and the green ground line to the ground terminal, as shown in Fig. 8.

If three phase, connect the three power lines to terminals L1, L2 and L3 and the green ground line to the ground terminal, as shown in Fig. 9. **IMPORTANT - THREE PHASE MACHINE ONLY.** If after the machine is in operation the cutterhead revolves in the wrong rotation, simply interchange any two of the three power lines that are connected to terminals L1, L2 and L3.




Fig. 5




Fig. 6




Fig. 7




Fig. 8




Fig. 9

OPERATING CONTROLS

ON/OFF CONTROLS

The machine is started by pressing the green (shrouded) "ON" button (A) Fig. 10. To stop the machine, push red (mushroom type) "OFF" button (B).




Fig. 10

RAISING AND LOWERING THE TABLE

For fast and easy changes in thickness settings to accommodate thick or thin stock, the table can be rapidly raised or lowered by pulling up or pushing down on table raising and lowering control lever (C) Fig. 10. **NOTE:** The machine must be turned "ON" and feed roll lever (H) Fig. 11, engaged when doing this.

Fine adjustment to the table height can be accomplished by loosening lock knob (D) Fig. 10, and turning table raising and lowering handwheel (E). Tighten lock knob (D) after table height adjustment is made. The English/Metric scale (F) Fig. 10, indicates the table height setting.




Fig. 11

The English/Metric scale and shelf (G) Fig. 12, located on the front of the table is used to quickly determine the thickness of stock, before or after planing, by simply placing the stock on the shelf as shown in Fig. 12. This enables you to quickly position the table for the next cut.

NOTE: The setting of the table to its final position should always be made by **RAISING THE TABLE** to the desired setting and **NOT LOWERING THE TABLE**. This insures that all backlash will be removed from the raising and lowering screws.




Fig. 12

FEED ROLL SPEEDS

Your planer is supplied with feed roll speeds of 16 and 28 feet per minute if it is a single phase machine and 25 and 46 feet per minute if it is a three phase machine. When feed roll engagement lever (A) Fig. 13, is all the way in the "OUT" position, as shown, the feed rolls are disengaged and the planer will not feed. When feed roll engagement lever (A) is in the "IN" position, as shown in Fig. 14, and notch (B) Fig. 13, is engaged with the front of the casting, the feed rolls are engaged and the planer will feed. To disengage the feed rolls, simply lift up on engagement lever (A) Fig. 14.




Fig. 13



Fig. 14

To change feed roll speeds, make sure the feed roll engagement lever (A) Fig. 15, is disengaged (in the out position) and open the left side door of the machine. When belt (C) Fig. 15, is on the smallest step of motor pulley (D) and the largest step of gearbox pulley (E) the feed roll speed will be 16 feet per minute on single phase machines and 25 feet per minute on three phase machines. When belt (C) is on the largest step of motor pulley (D) and the smallest step of gearbox pulley (E) the feed roll speed will be 28 feet per minute on single phase machines and 46 feet per minute on three phase machines.




Fig. 15

TABLE ROLLERS

Your planer is supplied with two table rollers (A) Fig. 16, which aid in feeding the stock by reducing friction and turn as the stock is fed through the planer. It is not possible to give exact dimensions on the proper height setting of the table rollers because each type of wood behaves differently. As a general rule, however, when planing rough stock the table rollers should be set **HIGH** and when planing smooth stock the table rollers should be set **LOW**.

To raise table rollers (A) Fig. 16, turn adjustment knob (B) clockwise. To lower table rollers (A) turn adjustment knob (B) counterclockwise.




Fig. 16

ANTI-KICKBACK FINGERS

Anti-kickback fingers (A) Fig. 17, are provided on your planer to prevent kickback. These fingers operate by gravity and it is necessary to inspect them occasionally as shown in Fig. 17, to make sure they are free of gum and pitch so they move independently and operate correctly.




Fig. 17

ADJUSTMENTS

Although your planer was carefully adjusted at the factory, it should be checked before being put into operation. Any inaccuracies due to rough handling in transit can easily be corrected by following these directions. In order to check the adjustments you will need a feeler gage and a gage block. **WHEN CHECKING ADJUSTMENTS, ALWAYS MAKE SURE THE PLANER IS DISCONNECTED FROM THE POWER SOURCE.**

CHECKING AND ADJUSTING DRIVE BELT TENSION

Proper drive belt tension is obtained when there is 1/4" deflection, using light finger pressure on drive belts (A) Fig. 18, midway between pulleys. If an adjustment is necessary proceed as follows:

1. **MAKE CERTAIN THE MACHINE IS DISCONNECTED FROM THE POWER SOURCE.**
2. Disengage feed roll lever (D).
3. Loosen two hex nuts (B) Fig. 19, and move motor plate (C) up or down as necessary to adjust tension.
4. Tighten two hex nuts (B) Fig. 19, after adjustment is made.

CHECKING AND ADJUSTING FEED ROLL BELT TENSION

Proper tension on the feed roll belt is obtained when there is approximately 1" deflection, using light finger pressure on feed roll belt (E) Fig. 18, midway between pulleys with the feed roll lever (D) engaged ("IN" POSITION).

If an adjustment is necessary:

1. **MAKE CERTAIN THE MACHINE IS DISCONNECTED FROM THE POWER SOURCE.**
2. Change position of rod (D) Fig. 20, in stud (F) by tightening and loosening two nuts (G) until correct belt tension is obtained. Both hex nuts (G) should be tight against stud (F) as shown in Fig. 20, after adjustment is made.




Fig. 18




Fig. 19




Fig. 20

CHECKING, ADJUSTING AND REPLACING KNIVES

When checking, adjusting or replacing the cutterhead knives on the 20" Planer, proceed as follows:

1. DISCONNECT THE MACHINE FROM THE POWER SOURCE AND REMOVE THE TOP COVER OF THE PLANER EXPOSING THE CUTTERHEAD.

- A. Check all four knives for proper setting using the knife gage (A), as shown in Fig. 21. When the gage (A) is placed on the cutterhead and the bottom of the two roll pins, one of which is shown at (B), are against the edge of the slot (C) opposite the knife, the knife should just contact the bottom of the gage (D).

- B. If any of the knives require an adjustment, slightly loosen the knife locking bar of each of the four knives by turning the knife locking screws, four of which are shown at (E) Fig. 21, into the locking bar just enough to relieve stress in the cutterhead but not disturb the setting of the four knives.

- C. To adjust the knife that must be reset, loosen all of that knife's locking screws (E) Fig. 21, by turning them into the locking bar. As the knife locking bar becomes loose, lifter springs under the knife will raise the knife until it contacts the bottom of the gage (D). Then snug up the knife locking bar by lightly backing out the locking screws (E) against the knife slot. **IMPORTANT: AT THIS TIME, ONLY TIGHTEN THE KNIFE INTO THE SLOT ENOUGH TO HOLD IT IN POSITION.**

- D. If additional knives must be reset, repeat **STEP C**.

- E. After all four knives are set with the screws just snug, back out and tighten the locking screws, four of which are shown at (E) Fig. 21, against the slot. Start with the end screws first and proceed on alternate sides toward the center screws until the knife is securely held in the cutterhead. Tighten the remaining three knives in the same manner.




Fig. 21

2. If the knives are removed for sharpening, care must be exercised in replacing and resetting them, as follows:

- A. To remove each knife, loosen the knife locking bar, by turning the locking screws, four of which are shown at (E) Fig. 21, into the knife locking bar and remove the locking bar, knife and springs located under the knife.

- B. Remove the remaining three knives in the same manner.

- C. Thoroughly clean the knife slots, knife bars, springs and screws. If the threads appear worn or stripped or if the heads are becoming rounded, replace them.

- D. Inspect the cutting edge of the knives for nicks or dull wire edges. Hone the knives slightly using a stone or if the knives are to be sharpened, maintain a cutting angle of 40 degrees.

- E. Insert springs, knives and knife locking bars into all four slots in the cutterhead. Push knives down as far as possible and back out locking screws, four of which are shown at (E) Fig. 21, just enough to hold all four knives in the cutterhead.

- F. Adjust all four knives as explained in **STEP 1** above.

ADJUSTING SPRING TENSION ON FEED ROLLERS

The outfeed roll (A) Fig. 22, and infeed roll (not visible) are those parts of your planer that feed the stock while it is being planed. The feed rolls are under spring tension and this tension must be sufficient to feed the stock uniformly through the planer without slipping but should not be too tight that it causes damage to the board. The tension should be equal at both ends of each roll.

To adjust spring tension on the infeed roll, turn screws (B) Fig. 22, right or left until they are flush with top of casting (C). To adjust spring tension on the outfeed roll (A), turn screws (D) until they are 2 to 3 complete turns below surface of casting (C).




Fig. 22

ADJUSTING CHIPBREAKERS

The chipbreakers are located on top of the planer and extend down around the front of the cutterhead. The chipbreakers raise as stock is fed through and "breaks or curls" the chips the same as a plane iron cap on a hand plane. The bottom of the chipbreakers must be parallel to the knives and set .011" below the cutting circle. To check and adjust the chipbreakers, proceed as follows:

1. **DISCONNECT MACHINE FROM THE POWER SOURCE.**

2. Make certain the knives are adjusted properly as previously explained under **CHECKING, ADJUSTING AND REPLACING KNIVES.**

3. Place gage block (A) Fig. 23, on the table directly underneath the cutterhead, as shown. Using a .011" feeler gage (B) Fig. 23, placed on top of the gage block, raise or lower the table until the knife just touches the feeler gage when the knife is at its lowest point. Do not move the table any further until the adjustment is completed.




Fig. 23

4. Move the gage block (A) underneath the chipbreakers (C) as shown in Fig. 24. The bottom of the chipbreakers should just touch the top of the gage block. Check opposite end of chipbreakers in the same manner.

5. If an adjustment to the chipbreakers is necessary, loosen three screws (D) Fig. 25, and move chipbreaker bracket (E) until bottom of chipbreakers just touch gage block at both ends.

6. The spring tension of the individual chipbreakers can be adjusted by tightening or loosening the ten adjusting screws (F) Fig. 25.




Fig. 24




Fig. 25

ADJUSTING PRESSURE BAR

The pressure bar is located directly behind the cutterhead and rides on the planed surface of the stock pressing the stock down on the table. The pressure bar must be parallel to the knives and tangent to the table and set .011" below the cutting circle. To adjust the pressure bar, proceed as follows:

6. Repeat **STEPS 1, 2 and 3** under **ADJUSTING CHIPBREAKERS**.

7. Move the gage block (A) underneath the pressure bar (B), as shown in Fig. 26. The bottom of the pressure bar (B) should just touch the top of the gage block. Check the opposite end of the pressure bar in the same manner.

8. If an adjustment to the height of the pressure bar is necessary, loosen locking nut (C) Fig. 27, and turn adjusting nut (D) until the bottom of the pressure bar just touches the gage block. Repeat at opposite end of pressure bar.

9. The spring tension of the pressure bar can be adjusted by loosening locking nut (E) Fig. 27, and turning adjusting screw (F) on both ends of the pressure bar until desired spring tension is obtained. Tighten lock nuts (C) and (E) after adjustments are made.




Fig. 26




Fig. 27

ADJUSTING OUTFEED ROLLER

The outfeed roll has been set at .035" below the cutting circle prior to shipment and an adjustment should not be necessary.

To check the setting of the outfeed roll:

1. **MAKE CERTAIN THE MACHINE IS DISCONNECTED FROM THE POWER SOURCE.**

2. Make certain the knives are adjusted properly as explained in section "**CHECKING, ADJUSTING AND REPLACING KNIVES.**"

3. Place gage block (A) Fig. 28, on the table directly underneath the cutterhead as shown. Using a .035" feeler gage (B) placed on top of gage block (A), raise or lower table until the knife just touches the feeler gage (B), when the knife is at its lowest point. Do not move the table any further until the adjustment is completed.




Fig. 28

4. Place the gage block (A) Fig. 29, underneath outfeed roll (C). The bottom of outfeed roller (C) should just touch the top of gage block (A) which would be .035" below the cutting circle.




Fig. 29

5. If an adjustment is necessary, loosen locknut (D) Fig. 30, and turn adjustment screw (E) until the outfeed roll just touches the top of gage block.

6. Repeat the adjustment at the opposite end of outfeed roller. Tighten lock nut (D) Fig. 30, after adjustment is made.




Fig. 30

ADJUST CHIP DEFLECTOR

1. DISCONNECT MACHINE FROM THE POWER SOURCE.

2. Remove two screws (A) Fig. 31, and lift up on chip chute (B).




Fig. 31

3. The edge (C) of the chip deflector (D) Fig. 32, should be adjusted so it is a minimum of .040" and a maximum of .080" away from the cutting circle. Place a feeler gage between the knife and the edge of the chip deflector as shown in Fig. 32. If an adjustment is necessary loosen three screws (E) and move chip deflector.




Fig. 32

ADJUSTING TABLE HEIGHT SCALE

The table height scale is adjusted at the factory and indicates the distance from the table to the cutting circle (depth of cut).

To check and adjust the pointer, proceed as follows:

1. Run a piece of wood part way through the planer and stop the machine.
2. Measure the thickness of the finished piece, as shown in Fig. 33. If necessary, loosen two screws (A) Fig. 34, adjust pointer (B) and retighten screws (A).




Fig. 33




Fig. 34

CHECKING AND ADJUSTING BED ROLL HEIGHT

The height of the bed rolls (A) Fig. 35, should be set between .002" and .004" above the table surface, with the bed rolls at their lowest position. To check the infeed bed roller height setting, proceed as follows:

1. **MAKE CERTAIN THE MACHINE IS DISCONNECTED FROM THE POWER SOURCE.**
2. Turn height adjustment knob (B) Fig. 35, counter-clockwise as far as it will go.
3. Place a straight edge (C) Fig. 35, across the infeed and outfeed rollers on the left side of the table as shown.



Fig. 35

4. With a feeler gage (D) Fig. 36, measure the gap between the table surface and the straight edge (B) near the infeed roll (E).

5. If an adjustment to the infeed roller (E) Fig. 36, is necessary, loosen set screw (F) Fig. 37, located underneath the left front end of the table.

6. Turn adjustment collar (G) Fig. 37, left or right as needed to attain proper height adjustment.

7. Tighten set screw (F) Fig. 37, after adjustment is made.




Fig. 36




Fig. 37

To check the outfeed roller height setting, proceed as follows:

1. With a feeler gage (H) Fig. 38, measure the gap between the table surface and the straight edge (B) near the outfeed roller (J).

2. If an adjustment to the outfeed roller is necessary, loosen jam nut (K) Fig. 39, located on the left side of machine under the table, and turn collar (L) right or left as needed until the outfeed roller is adjusted properly.

3. Tighten jam nut (K) Fig. 39.




Fig. 38




Fig. 39

LEVELING THE TABLE

The table is set parallel to the cuttinghead at the factory and no further adjustment should be necessary. If your machine is planing a taper, first check to see if the knives are set properly in the cutterhead. Then check to see if the table is set parallel to the cuttinghead as follows:

1. **DISCONNECT MACHINE FROM THE POWER SOURCE.**

2. Place gage block (A) Fig. 40, on table directly under front edge of head casting (B) as shown. Raise the table until gage block (A) just touches lower edge of head casting (B).

3. Move gage block (A) Fig. 41, to opposite side of table, as shown. Distance from table to edge of head casting (B) Fig. 41, should be the same.

4. Repeat **STEPS 2** and **3** on outfeed end of table.

5. If head casting is not parallel to table, raise chain and sprocket covers (C) Fig. 42.

6. Remove bolt (D) and loosen bolt (E) Fig. 43, which will allow you to move the idler sprocket assembly (F) far enough to remove chain from sprocket on end of head-casting that must be adjusted.

7. Turn sprocket (G) Fig. 43, by hand to bring that corner into adjustment with other three corners. **IMPORTANT: THIS ADJUSTMENT IS VERY SENSITIVE AND IT SHOULD NOT BE NECESSARY TO TURN THE SPROCKET MORE THAN ONE OR TWO TEETH.** Turning sprocket (G) clockwise will decrease the distance between the table and headcasting. Counter-clockwise will increase the distance.

8. Replace chain being careful not to disturb the position of the sprockets and replace idler sprocket assembly (F) Fig. 43. Tighten bolt (E) and replace bolt (D) which was removed in **STEP 6**.




Fig. 40




Fig. 41




Fig. 42




Fig. 43

LUBRICATION

The gear box oil should be changed once a year using extreme pressure gear oil, available from Delta in one pint cans under part number 999-01-013-1210. The gear box drain plug is shown at (C) Fig. 44. The oil fill screw is shown at (B) and the oil level indicator is shown at (A) Fig. 44.




Fig. 44

GAGE BLOCK

A gage block has been supplied with your planer; however, if it is ever necessary to make a gage block out of hardwood, follow the instructions shown in Fig. 45.




Fig. 45



PARTS, SERVICE OR WARRANTY ASSISTANCE

All Delta Machines and accessories are manufactured to high quality standards and are serviced by a network of factory service centers and authorized service stations listed in your owner's manual. To obtain additional infor-

mation regarding your Delta quality product or to obtain parts, service or warranty assistance, please call or fax Delta's toll-free 'hotline' number.

Delta maintains a modern, efficient Parts Distribution Center, maintaining an inventory of over 15,000 parts located in Memphis, Tennessee.

Highly qualified and experienced Customer Service Representatives are standing by to assist you on weekdays from 8:00 A.M to 5:00 P.M. Memphis time.




Memphis, TN 38118
4290 Raines Road
Phone: (901) 363-8800

HOTLINE
800-223-PART
FAX: 800-535-6488

DELTA Two Year Limited Warranty Delta Machinery

Delta will repair or replace, at its expense and at its option, any Delta machine, machine part, or machine accessory which in normal use has proven to be defective in workmanship or material, provided that the customer notifies his supplying distributor of the alleged defect within two years from the date of delivery to him, of the product and provides Delta Machinery with reasonable opportunity to verify the defect by inspection. Delta Machinery may require that electric motors be returned prepaid to the supplying distributor or authorized service center for inspection and repair or replacement. Delta Machinery will not be responsible for any asserted defect which has resulted from misuse, abuse or repair or alteration made or specifically authorized by anyone other than an authorized Delta service facility or representative. Under no circumstances will Delta Machinery be liable for incidental or consequential damages resulting from defective products. This warranty is Delta Machinery's sole warranty and sets forth the customer's exclusive remedy, with respect to defective products; all other warranties, express or implied, whether of merchantability, fitness for purpose, or otherwise, are expressly disclaimed by Delta.




REPLACEMENT PARTS


Ref No.	Part No.	Description	Ref No.	Part No.	Description
1	428-07-026-0001	Dust Collector	55	438-01-017-0173	Switch w/On Button
2	428-07-116-0006	Gasket	56	438-01-017-0172	Switch w/Off Button
3	1243379	(DIN 912) M6 x 10mm Soc Hd Screw	57	1246090	(DIN 84) M6 x 30mm Cheese Hd Screw
4	1085187	"Danger" Label	58	428-07-104-0023	Spacer
5	428-07-031-0020	Cover	59	1246045	(DIN 84) M6 x 10mm Cheese Hd Screw
6	1243567	(DIN 912) M6 x 35mm Soc Hd Screw	60	428-07-123-0001	Panel
7	428-07-116-0005	Gasket	61	428-07-071-0004	Spring Pin
8	428-07-072-0009	Chip Deflector Plate	62	428-07-122-0006	Spring
9	428-07-031-0011	Cover	63	1246114	(DIN 934) M16 Hex Nut
10	1330433	Warning Label	64	428-07-027-0001	Spring Regulator
11	1246045	(DIN 84) M6 X 10mm Cheese Hd Screw	65	1243456	(DIN 934) M6 Hex Nut
12	428-07-071-0012	Pin	66	1246175	(DIN 931) M6 x 30mm Hex Hd Screw
13	1246182	(DIN 1481) Ø3 x 8mm Roll Pin	67	428-07-122-0009	Spring
14	1246054	(DIN 912) M8 x 20mm Soc Hd Screw	68	428-07-106-0015	Belt Tension Shaft
15	422-29-079-0001	Washer	69	432-07-138-0005	Handle
15A	1243526	(DIN 125) Ø8mm Flat Washer	*	428-07-351-0001	Gear Box Assembly, Const of:
16	428-07-071-0013	Hinge Pin	70	428-07-112-0006	Tilt Nut
17	428-07-059-0007	Hinge - Left	71	428-07-071-0003	(DIN 1481) Ø8 x 60mm Roll Pin
18	1243398	(DIN 934) M8 Hex Nut	72	428-07-071-0004	Spring Pin (Install with Loctite)
19	428-07-059-0006	Hinge - Right	73	428-07-031-0004	Rear Gear Box Cover
20	1246034	(DIN 933) M8 x 20mm Hex Hd Screw	74	1246143	(DIN 1481) Ø8 x 40mm Roll Pin
21	428-07-005-0003	Upper Base	75	428-07-074-0003	Plug
22	422-29-079-0015	Washer	76	920-04-020-5348	Bearing
23	1243502	(DIN 125) Ø10mm Flat Washer	77	428-07-051-0005	Gear
24	1246018	(DIN 933) M10 x 25mm Hex Hd Screw	78	428-07-079-0005	Key
25	428-07-055-0005	Vertical Table Guide	79	428-07-116-0003	Seal
26	1246149	(DIN 913) M10 x 16mm Hex Soc Set Screw	80	428-07-116-0002	O-Ring
27	1246179	(DIN 7980) Ø12mm Lockwasher	81	428-07-079-0004	Key
28	1246172	(DIN 912) M12 x 45mm Soc Hd Screw	82	428-07-051-0003	Gear
29	428-07-059-0008	Lower Hinge	83	428-07-051-0004	Gear
30	1246034	(DIN 933) M8 x 20mm Hex Hd Screw	84	428-07-051-0002	Gear
31	1243301	(DIN 471) 16e External Retaining Ring	85	428-07-116-0004	O-Ring
32	428-07-130-0004	Sheave	86	920-04-022-4014	Bearing
33	428-07-106-0013	Sheave Shaft - Left	87	428-07-051-0001	Gear
34	1246007	(DIN 913) M4 x 8mm Hex Soc Set Screw	88	428-07-104-0004	Spacer
35	428-07-089-0017	Cursor Support	89	428-07-017-0004	Bearing
36	428-07-081-0001	Cable (See Service Note A)	90	428-07-116-0001	O-Ring
37	428-07-104-0025	Spacer	91	428-07-056-0001	Gasket
38	428-07-075-0002	Cursor	92	1243331	(DIN 912) M6 x 40mm Soc Hd Screw
39	1246117	(DIN 963) M4 x 10mm Flat Hd Screw	93	1246055	(DIN 912) M6 x 50mm Soc Hd Screw
40	428-07-130-0005	Sheave - Minor	94	428-07-031-0003	Gear Box - Pulley Side
41	428-07-106-0012	Sheave Shaft - Right	95	1246070	(DIN 912) M6 x 30mm Soc Hd Screw
42	428-07-389-0001	Scale Support, Incl.:	96	428-07-074-0002	Oil Level Plug (For 30 Models Only)
43	428-07-132-0002	Scale	97	428-07-074-0005	Plug (For 10 Models Only)
44	422-28-079-0015	Rivet	98	428-07-104-0003	Washer
45	1246053	(DIN 912) M8 x 25mm Soc Hd Screw	99	1246048	(DIN 963) M8 x 20mm Flat Hd Screw
46	1246013	(DIN 933) M6 x 12mm Hex Hd Screw	100	428-07-130-0002	Pulley (For 30 Models Only)
47	1243456	(DIN 934) M6 Hex Nut	101	428-07-130-0006	Pulley (For 10 Models Only)
48	904-01-010-1604	1/4" Flat Washer	102	428-07-104-0005	Washer
49	428-07-089-0015	Support	103	1246049	(DIN 963) M8 x 25mm Flat Hd Screw
50	428-07-013-0001	Switch Box	104	1246016	(DIN 933) M8 x 25mm Hex Hd Screw
51	428-07-031-0017	Switch Box Cover	105	428-07-350-0001	Knife Gage, Incl.:
52	901-06-133-1263	#10-24 X 3/8" Type F Pan Hd Screw	106	1246185	(DIN 1481) Ø5 x 40mm Roll Pin
53	1246130	(DIN 84) M6 x 16mm Cheese Hd Screw	107	428-07-112-0022	Adjusting Screw (Early Models Only)
54	428-07-123-0002	Panel	108	1243476	(DIN 934) M12 Hex Nut (Early Models Only)
			109	1330270	Gage Block

* NOT SHOWN ASSEMBLED

SERVICE NOTES:

A - Follow sequential diagram below for correct tracking of cable.






REPLACEMENT PARTS


Ref No.	Part No.	Description	Ref No.	Part No.	Description
150	428-07-010-0003	Right Block w/Bushing	195	428-07-023-0003	Infeed Roller Drive Chain (59 Pitches), Incl.: (See Service Note B)
151	1246044	(DIN 913) M8 x 30mm Hex Soc Set Screw	196	428-07-135-0007	Master Link
152	1243398	(DIN 934) M8 Hex Nut	197	428-07-135-0001	Offset Link
153	428-07-088-0002	Limiter	198	428-07-134-0007	Sprocket - Outfeed Roller (Outboard)
154	1246056	(DIN 912) M16 x 12mm Soc Hd Screw	199	428-07-023-0004	Outfeed Roller Drive Chain (35 Pitches), Incl.: (See Service Note B)
155	428-07-079-0002	Key	200	428-07-135-0007	Master Link
156	428-07-080-0005	Outfeed Roller - Outboard	201	428-07-135-0001	Offset Link
157	428-07-010-0005	Block w/Bushing	202	1246019	(DIN 933) M10 x 35mm Hex Hd Screw
159	428-07-079-0001	Key	203	1243360	(DIN 7980) Ø10mm Lockwasher
160	428-07-080-0004	Outfeed Roller - Inboard	204	428-07-112-0003	Adjusting Nut
161	428-07-079-0010	Key	205	428-07-122-0003	Spring
162	428-07-111-0003	Stud (Install with Loctite)	206	428-07-089-0008	Support - Right Side
163	1243456	(DIN 934) M6 Hex Nut	207	428-07-088-0003	Stop
164	904-01-010-1604	1/4" Flat Washer	208	1246056	(DIN 912) M6 x 12mm Soc Hd Screw
165	428-07-089-0019	Rear Chipbreaker Support	209	1246122	(DIN 912) M8 x 15mm Soc Hd Screw
165A	1243398	(DIN 934) M8 Hex Nut (Current Models Only)	210	428-07-089-0020	Support
166	1246044	(DIN 913) M8 x 30mm Hex Soc Set Screw (Current Models Only)	211	1246144	(DIN 914) M6 x 12mm Hex Soc Set Screw
166A	1246168	(DIN 915) M10 x 25mm Hex Soc Set Screw (Early Models Only)	212	428-07-104-0024	Cable Lock
167	1330697	Spring (Current Models Only)	213	1246137	(DIN 912) M5 x 8mm Hex Soc Set Screw
167A	432-07-122-0003	Spring (Early Models Only)	214	428-07-072-0005	Chipbreaker Limiter Plate
168	1246109	(DIN 1481) Ø5 x 16 mm Roll Pin	215	1246078	(DIN 933) M8 x 12mm Hex Hd Screw
169	428-07-004-0005	Rear Pressure Bar	216	1243526	(DIN 125) Ø8mm Flat Washer
*	428-07-312-0003	Outterhead Assembly, Const of:	217	1246053	(DIN 912) M8 x 25mm Soc Hd Screw
170	428-07-112-0001	Locking Screw	218	428-07-089-0010	Chipbreaker Support
171	428-07-004-0006	Knife Locking Bar	219	428-07-122-0010	Spring
172	22-466	Set of Four (4) Knives	220	428-07-112-0021	Chipbreaker Adjusting Screw
173	428-07-079-0003	Key	221	428-07-312-0002	Block w/Bushing
174	428-07-012-0002	Outterhead	222	428-07-080-0003	Infeed Roller
175	428-07-122-0001	Spring	223	428-07-079-0002	Key
176	1330667	(DIN 933) M12 x 30mm Hex Hd Screw	224	429-07-036-0002	Chipbreaker
177	428-07-104-0009	Washer	225	428-07-106-0007	Chipbreaker Shaft
178	428-07-130-0001	Cutterhead Pulley	226	428-07-104-0028	Spacer
179	1246068	(DIN 472) 80i Internal Retaining Ring	227	428-07-108-0004	Support Rod
180	428-07-017-0001	Bearing	228	428-07-108-0005	Anti-Kick Back Rod
181	1246166	(DIN 914) M5 x 12mm Hex Soc Set Screw	229	428-06-047-0001	Anti-Kick Back Finger
182	1246043	(DIN 916) M5 x 10mm Hex Soc Set Screw	230	428-06-104-0006	Washer
183	428-07-010-0002	Bearing Block - Left	231	428-07-104-0027	Spacer
184	428-07-054-0002	Bearing Guard	232	428-07-112-0001	Adjusting Nut
185	428-07-010-0001	Bearing Block - Right	233	1330696	Spring
186	1246069	(DIN 471) 40e External Retaining Ring	233A	428-07-122-0002	Spring
187	1246049	(DIN 963) M8 x 25mm Flat Hd Screw	234	428-07-089-0009	Support - Left Side
188	428-07-104-0002	Washer	235	1246052	(DIN 912) M10 x 35mm Soc Hd Screw
189	428-07-134-0005	Sprocket - Infeed Roller	236	1243360	(DIN 7980) Ø10mm Lockwasher
190	428-07-134-0008	Sprocket - Outfeed Roller (Inboard)	237	1246057	(DIN 912) M12 x 35mm Soc Hd Screw
191	428-07-023-0006	Table Elevating Drive Chain (65 Pitches), Incl: (See Service Note B)	238	1246179	(DIN 7980) Ø12mm Lockwasher
192	428-07-135-0003	Master Link	239	1246144	(DIN 914) M6 x 12mm Soc Hd Screw
193	428-07-135-0005	Offset Link	240	1246060	(DIN 1481) Ø8 x 30mm Roll Pin
194	428-07-134-0006	Sprocket - Outfeed Roller (Inboard)			

* NOT SHOWN ASSEMBLED


SERVICE NOTES:

B - See diagram below for correct chain selection.





CURRENT MODELS ONLY




EARLY MODELS ONLY

REPLACEMENT PARTS

Ref No.	Part No.	Description	Ref No.	Part No.	Description
*	1330690	Complete Table Assembly, Const of: (Current Models Only)	375	428-07-091-0002	Table
300	1330446	Table	376	428-07-055-0009	Auxiliary Guide
301	428-07-055-0009	Auxiliary Guide	377	1246045	(DIN 84) M6 x 10mm Cheese Hd Screw
302	1246045	(DIN 84) M6 x 10mm Cheese Hd Screw	378	1246155	(DIN 963) M6 x 12mm Flat Hd Screw
303	1246155	(DIN 963) M6 x 12mm Flat Hd Screw	379	428-07-055-0008	Table Guide - Left
304	428-07-055-0008	Table Guide - Left	380	428-07-055-0006	Table Position Guide
305	428-07-055-0006	Table Position Guide	381	1243526	(DIN 125) Ø8mm Flat Washer
306	1243526	(DIN 125) Ø8mm Flat Washer	382	1246016	(DIN 933) M8 x 25mm Hex Hd Screw
307	1246016	(DIN 933) M8 x 25mm Hex Hd Screw	383	428-07-072-0008	Plate - Left
308	1330483	Plate - Left	384	428-07-055-0007	Table Guide - Right
309	1246002	(DIN 84) M6 x 12mm Cheese Hd Screw	385	1246144	(DIN 914) M6 x 12mm Hex Soc Set Screw
310	428-07-055-0007	Table Guide - Right	386	428-07-071-0015	Bronze Pin
311	428-07-071-0015	Bronze Pin	387	1246167	(DIN 913) M10 x 25mm Hex Soc Set Screw
312	1246167	(DIN 913) M10 x 25mm Hex Soc Set Screw	388	1243496	(DIN 934) M10 Hex Nut
313	1243496	(DIN 934) M10 Hex Nut	389	1243301	(DIN 471) 16e External Retaining Ring
314	428-07-071-0011	Pin	390	428-07-130-0004	Sheave
315	428-07-130-0004	Sheave	391	428-07-089-0016	Sheave Support
316	428-07-089-0016	Sheave Support	392	428-07-071-0011	Pin
317	1243301	(DIN 471) 16e External Retaining Ring	393	1246130	(DIN 84) M6 x 16mm Cheese Hd Screw
318	1246130	(DIN 84) M6 x 16mm Cheese Hd Screw	394	428-07-072-0007	Plate - Right
319	1246045	(DIN 84) M6 x 10mm Cheese Hd Screw	395	428-07-072-0006	Plate
320	428-07-072-0007	Plate - Right	396	428-07-132-0003	Scale
321	1246045	(DIN 84) M6 x 10mm Cheese Hd Screw	397	422-28-079-0015	Rivet
322	428-07-132-0003	Scale	398	428-07-137-0002	Indicator Plate
323	422-28-079-0015	Rivet	399	428-07-067-0003	Ball Handle
324	1330449	Front Plate	400	428-07-017-0006	Roller Bushing
325	1330450	Indicator Plate	401	428-07-380-0001	Table Roller Assembly, Incl.:
326	1330458	Knob	402	920-04-020-5348	Bearing
327	1246009	(DIN 913) M8 x 10mm Hex Soc Set Screw	403	428-07-106-0014	Table Roller Shaft
328	1243456	(DIN 934) M6 Hex Nut	404	428-07-089-0004	Roller Pivot
329	1330448	Table Roller Pivot - Left	405	1243321	(DIN 913) M6 x 10mm Hex Soc Set Screw
330	1246041	(DIN 914) M8 x 15mm Hex Soc Set Screw	406	1243497	(DIN 471) 12e External Retaining Ring
331	1330454	Rear Pivot Bar	407	428-07-004-0004	Pivot Bar
332	1243497	(DIN 471) 12e External Retaining Ring	408	428-07-071-0006	Pivot Pin
333	428-07-071-0006	Pivot Pin	409	428-07-112-0011	Adjusting Nut Screw
334	1243476	(DIN 934) M12 Hex Nut	410	1243476	(DIN 934) M12 Hex Nut
335	1330453	Adjusting Screw	411	428-07-112-0020	Roller Adjusting Screw
336	1330455	Pivot Bar - Front			
337	1330456	Adjusting Nut			
338	1330457	Lock Nut			
339	1246137	(DIN 913) M5 x 8mm Hex Soc Set Screw			
340	1330452	Roller Adjustment Lever			
341	1330459	Washer			
342	1320106	Bearing			
343	1330451	Table Roller Shaft			
344	1330481	Table Roller			
345	1330447	Table Roller Pivot - Right			
346	1246009	(DIN 913) M8 x 10mm Hex Soc Set Screw			

* NOT SHOWN ASSEMBLED



REPLACEMENT PARTS

Ref No.	Part No.	Description	Ref No.	Part No.	Description
425	1330411	Table Support (Current Models Only)	505	1246133	(DIN 913) M8 x 8mm Hex Soc Set Screw (Early Models Only, See Service Note D)
425A	428-07-089-0011	Table Support (Early Models Only)	506	428-07-122-0012	Spring (Early Models Only, See Service Note D)
426	1243502	(DIN 125) Ø10mm Flat Washer	507	921-01-010-0028	1/4" Dia. Ball (Early Models Only, See Service Note D)
427	1246035	(DIN 933) M10 x 30mm Hex Hd Screw	508	428-07-134-0009	Sprocket w/Bushing (Early Models Only, See Service Note D)
428	1246122	(DIN 912) M8 x 15mm Soc Hd Screw	509	428-06-079-0003	Key
429	428-07-088-0004	Lock Ring	510	1330695	Drive Shaft (Current Models Only, See Service Note D)
430	1246028	(DIN 6799) RS-15 External Retaining Ring	510A	428-07-051-0014	Drive Shaft (Early Models Only, See Service Note D)
431	428-07-088-0005	Lock Ring	511	428-07-104-0026	Washer (Current Models Only)
432	1246164	(DIN 7971) Ø4.2 x 13mm Pan Hd Metal Screw	512	428-07-031-0012	Cover Right - Side
433	904-01-010-1603	3/16" Flat Washer	513	1243398	(DIN 934) M8 Hex Nut
434	428-07-104-0011	Plate	514	422-29-079-0001	Washer
435	428-07-031-0021	Elevating Screw Cover	515	428-07-059-0008	Lower Hinge
436	1330486	Elevating Screw w/Gear	516	428-07-071-0013	Hinge Pin
437	428-07-023-0005	Chain (172 Pitches), Incl.:	517	428-07-138-0001	Knob
438	428-07-135-0003	Master Link	518	428-07-100-0002	Wheel
440	428-07-054-0004	Elevating Screw Guard - Rear	519	1246078	(DIN 933) M8 x 15mm Hex Hd Screw
441	1246130	(DIN 84) M6 x 16mm Cheese Hd Screw	520	422-30-079-0006	Washer
442	920-41-013-1442	Bearing	*	428-07-333-0001	Table Raising Assembly, Const of:
443	1246013	(DIN 933) M6 x 12mm Hex Hd Screw	521	1246177	(DIN 84) M4 x 6mm Cheese Hd Screw
444	428-06-104-0002	Washer	522	428-07-031-0014	Cover
445	428-06-134-0002	Sprocket w/Bushing	523	1246181	(DIN 471) 25e External Retaining Ring
446	428-06-084-0001	Idler	524	428-07-134-0004	Sprocket
447	1246018	(DIN 933) M10 x 25mm Hex Hd Screw	525	1246110	(DIN 1481) Ø6 x 24mm Roll Pin
448	1243502	(DIN 125) Ø10mm Flat Washer	526	1246176	(DIN 931) M8 x 80mm Hex Hd Screw
449	1246099	(DIN 931) M10 x 50mm Hex Hd Screw	527	1246131	(DIN 933) M8 x 60mm Hex Hd Screw
450	1243496	(DIN 934) M10 Hex Nut	528	428-07-104-0020	Spacer
451	428-07-103-0002	Flange	529	428-07-089-0013	Front Gear Support w/Bushings
452	1246157	(DIN 7980) Ø8mm Lockwasher	530	428-07-051-0012	Gear - 20 Teeth
453	1243530	(DIN 912) M8 x 30mm Soc Hd Screw	531	428-07-079-0008	Key
454	428-07-074-0004	Plug	532	428-07-106-0010	Wheel Shaft
455	1246133	(DIN 913) M8 x 8mm Hex Soc Set Screw	533	428-07-051-0011	Gear - 22 Teeth
456	428-07-079-0011	Nut	534	428-06-079-0003	Key
457	1243398	(DIN 934) M8 Hex Nut (See Service Note C)	535	428-07-106-0011	Intermediate Shaft
458	422-30-079-0006	Washer (See Service Note C)	536	428-07-051-0009	Gear w/Pins and Bushing - 35 Teeth
459	1246017	(DIN 933) M8 x 30mm Hex Hd Screw (See Service Note C)	537	428-07-079-0007	Key
460	1243398	(DIN 934) M8 Hex Nut (Early Models Only)	538	1246092	(DIN 914) M6 x 6mm Hex Soc Set Screw
461	1243526	(DIN 125) Ø8mm Flat Washer (Early Models Only)	539	428-07-106-0009	Clutch Shaft
462	428-07-315-0001	Brake Assembly	540	428-07-071-0009	Pin
463	1246122	(DIN 912) M8 x 15mm Soc Hd Screw (Current Models Only)	541	428-07-051-0008	Gear w/Pins and Bushing - 39 Teeth
463A	1246054	(DIN 912) M8 x 20mm Soc Hd Screw (Early Models Only)	541A	428-07-089-0012	Rear Gear Support w/Bushing
464	428-07-031-0013	Cover Left - Side	542	1246016	(DIN 933) M8 x 25mm Hex Hd Screw
465	428-07-138-0001	Knob	543	1243446	1/4" Dia. Ball (Current Models Only)
466	1246072	(DIN 912) M10 x 80mm Soc Hd Screw (For 30 Models Only)	543A	921-01-010-0029	3/16" Dia. Ball (Early Models Only)
467	901-03-010-0777	3/8-16 x 3" Soc Hd Screw (For 10 Models Only)	544	428-07-122-0012	1/4" Dia. Spring (Current Models Only)
468	428-07-104-0017	Washer	544A	428-07-122-0011	3/16" Dia. Spring (Early Models Only)
469	428-07-133-0001	V-Belt (For 30 Models Only)	545	428-07-328-0001	Clutch Assembly, Incl.:
470	428-07-133-0003	V-Belt (For 10 Models Only)	546	1246184	(DIN 1481) Ø3 x 20mm Roll Pin
471	428-07-133-0002	Matched Set of Three (3) V-Belts	547	428-07-051-0013	Gear - 12 Teeth
472	428-07-130-0003	Motor Pulley (For 30 Models Only)	548	1243301	(DIN 471) 16e External Retaining Ring
473	428-07-130-0007	Motor Pulley (For 10 Models Only)	549	428-07-089-0014	Lever Support
474	1246009	(DIN 913) M8 x 10mm Hex Soc Set Screw (For 30 Models Only)	550	428-07-067-0009	Clutch Lever
475	438-02-314-0932	Motor - 7.5 HP, 200-220/440V, 60 Hz, 3Ø	551	1243398	(DIN 934) M8 Hex Nut
476	83-004	Motor - 5 HP, 230V, 60 Hz, 1Ø	552	428-07-067-0010	Lever
477	1246019	(DIN 933) M10 x 35mm Hex Hd Screw	553	432-07-138-0005	Knob
478	428-07-005-0005	Motor Base	554	1246176	(DIN 931) M8 x 80mm Hex Hd Screw
479	1243496	(DIN 934) M10 Hex Nut	555	428-07-104-0020	Spacer
480	428-07-104-0029	Spacer	556	1246016	(DIN 933) M8 x 25mm Hex Hd Screw
481	1246020	(DIN 933) M10 x 80mm Hex Hd Screw	557	428-07-079-0009	Key
482	1243502	(DIN 125) Ø10mm Flat Washer	558	901-06-133-1263	#10-24 x 3/8" Self Tap Screw (Current Models Only)
483	428-07-104-0030	Spacer	558A	1246045	(DIN 84) M6 x 10mm Cheese Hd Screw (Early Models Only)
484	428-07-072-0010	Limiter Plate	559	428-07-031-0015	Electrical Box Cover
485	1243502	(DIN 125) Ø10mm Flat Washer	560	1246007	(DIN 913) M4 x 8mm Hex Soc Set Screw
486	1246035	(DIN 933) M10 x 30mm Hex Hd Screw	561	428-07-104-0021	Cable Lock
487	1246180	(DIN 471) 22e External Retaining Ring	562	1243502	(DIN 125) Ø10mm Flat Washer
488	428-07-106-0008	Motor Base Shaft	563	1246115	(DIN 933) M10 x 20mm Hex Hd Screw
489	1243502	(DIN 125) Ø10mm Flat Washer	564	428-07-111-0002	Stud
490	1243496	(DIN 934) M10 Hex Nut	565	1243395	(DIN 934) M5 Hex Nut
491	1246045	(DIN 84) M6 x 10mm Cheese Hd Screw	566	438-01-011-0060	Insulation Paper
492	428-07-054-0003	Elevating Screw Guard - Front	567	438-01-018-0056	Terminal Strip Assembly
493	1246019	(DIN 933) M10 x 35mm Hex Hd Screw	568	438-01-008-0051	Cover
494	1243502	(DIN 125) Ø10mm Flat Washer	569	1246102	(DIN 125) Ø5mm Flat Washer
495	428-06-134-0002	Sprocket w/Bushing	570	428-07-005-0004	Lower Base
496	428-07-071-0014	Pin	571	428-07-031-0016	Motor Cover, Incl.:
497	1243301	(DIN 471) 16e External Retaining Ring	572	1243502	(DIN 125) Ø10mm Flat Washer
498	428-07-051-0013	Gear - 12 Teeth	573	1243496	(DIN 934) M10 Hex Nut
499	428-07-104-0026	Bronze Washer	574	901-06-133-1263	#10-24 x 3/8" Self Tap Screw
500	428-07-014-0001	Bracket w/Bushing	575	428-07-137-0001	Nameplate
501	1330147	(DIN 912) M8 x 40mm Soc Hd Screw	576	422-28-079-0015	Rivet
502	428-07-088-0006	Stop Collar (Early Models Only, See Service Note D)	577	1246153	(DIN 933) M6 x 25mm Hex Hd Screw
503	1246039	(DIN 913) M8 x 12mm Hex Soc Set Screw (Early Models Only, See Service Note D)	578	428-07-089-0018	Electrical Box Support
504	428-07-071-0016	Bronze Washer (Early Models Only, See Service Note D)	*	NOT SHOWN ASSEMBLED	

SERVICE NOTES:

C - For use with outboard elevating screws only.

D - When replacement becomes necessary for early style sprocket w/bushing (Ref. No. 508) or drive shaft (Ref. No. 510A) a new style drive shaft (Ref. No. 510) (shaft and sprocket incorporated as one piece) will be shipped. Customer MUST discard stop collar (Ref. No. 502), set screw (Ref. No. 503), washer (Ref. No. 504), set screw (Ref. No. 505), spring (Ref. No. 506), and ball (Ref. No. 507) for proper machine operation, as the new style drive shaft no longer requires the use of these parts.

This parts list is provided to aid in obtaining service parts. Operational and maintenance information is contained in a separate owner's manual which is available through your local service outlet.