


# Instruction manual



**Rockwell**

## 20'' Wood/ Non-Ferrous Cutting Band Saw



**No. 28-340 Band Saw**  
Shown with Accessory 25-857 Lamp Attachment, 28-701 Blade Welder and Flash Grinder, 28-005 Blade Shear, and Electricals.

The Serial No./Model No. plate is attached to the frame of the machine. Locate this plate and record the Serial No. and Model No. in your manual for future reference.

SERIAL NO. \_\_\_\_\_

MODEL NO. \_\_\_\_\_

DATE OF PURCHASE \_\_\_\_\_

# Replacement Parts

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
150	426-04-063-5001	Table Insert	190	426-05-331-5005	Lower Door (Early Models Only, Prior to S/N 173-5645) Incl:
151	426-04-091-5002	Table	190	426-05-331-5012	Lower Door (Current Models Only, Beginning with S/N 173-5645) Incl:
152	906-00-000-2438	1/8" Hex Soc. Pipe Plug	191	901-02-010-0561	10-32 X 3/8" Rd. Hd. Mach. Scr.
153	426-04-095-5002	Rear Trunnion	192	426-05-068-5001	Latch
**	426-05-355-5008	Lower Blade Guide (Current Models Only, See Note A), Const. Of:	193	904-03-020-1775	10-Internal Tooth Lockwasher
154	426-05-014-5036	Bracket	194	902-01-120-1203	10-32 Hex Nut
155	901-04-150-0206	5/16-18 X 5/16" Soc. Set Scr.	195	426-05-063-5006	Insert Handle
156	426-05-380-5001	Roller Ass'y.	196	901-02-140-0584	10-32 X 3/8" Bind. Hd. Scr.
157	1203002	Plate	197	426-05-063-5006	Insert Handle
158	904-01-010-1617	Washer	198	1201998	Rear Cover (Current Model)
159	901-03-010-0760	1/4-20 X 1-1/4" Hex Soc. Cap Scr.	199	426-05-331-5006	Rear Door (Early Models Only), Incl:
161	901-01-060-0649	5/16-18 X 1" Hex Hd. Scr.	200	901-02-140-0584	10-32 X 3/8" Bind. Hd. Scr.
162	426-04-095-5001	Front Trunnion	201	961-04-021-5001	Hinge
163	901-01-060-0632	7/16-14 X 2-3/4" Hex Hd. Scr.	202	904-03-020-1775	Lockwasher
164	426-02-027-0001	Table Clamp	203	902-01-120-1203	10-32 Hex Nut
165	901-01-060-0617	3/8-16 X 1-1/2" Hex Hd. Scr.	204	901-05-131-7351	12 X 1/2" Rd. Hd. Scr.
166	402-05-075-5001	Pointer	205	961-04-042-3110	Spring Catch
167	901-02-010-0502	1/4-20 X 1/4" Rd. Hd. Scr.	206	426-04-026-5001	Dust Spout
168	426-04-004-5003	Bar	207	902-01-120-1203	10-32 Hex Nut
169	901-04-020-0306	1/4-20 X 3/4" Sq. Hd. Set Scr.	208	901-01-060-0648	3/8-16 X 1-1/4" Hex Hd. Scr.
170	902-01-120-1034	1/4"-20 Hex Nut	209	904-01-010-1615	13/32 X 13/16 X 1/16" Washer
171	426-04-014-5012	Bracket	210	902-01-040-1026	3/8-16 Hex Nut
172	902-01-040-1004	7/16"-14 Hex Nut	211	426-04-036-5001	Deflector
173	426-05-072-5032	Scale	212	901-02-010-0559	10-32 X 1/2" Rd. Hd. Scr.
174	901-06-450-2252	2 X 3/16" Drive Scr.	213	426-05-072-5028	Motor Plate
175	904-01-010-1615	13/32 X 13/16 X 1/16" Washer	214	426-05-106-5012	Motor Plate Shaft
176	901-01-060-0648	3/8-16 X 1-1/4" Hex Hd. Scr.	215	904-15-010-7008	Retaining Ring
177	426-04-112-5001	Threaded Bushing	216	1202596	5/16-18 Stud
178	901-01-060-0617	3/8-16 X 1-1/2" Hex Hd. Scr.	217	904-02-010-1703	5/16" Lockwasher
179	426-04-349-5004	Frame Ass'y. (Early Models Only, Prior to S/N 173-5645)	218	902-01-020-5435	5/16"-18 Hex Nut
179	426-04-349-5005	Frame Ass'y. (Current Models Only, Beginning with S/N 173-5645)	221	904-03-030-1756	Tooth Lockwasher
180	426-05-331-5003	Upper Door, Incl:	222	904-02-020-1704	3/8" Lockwasher
181	901-02-010-0561	10-32 X 3/8" Rd. Hd. Mach. Scr.	**		Lower Blade Guide (Early Models Only, See Note A) Const. Of:
182	426-05-068-5001	Latch	223	426-05-014-5018	Bracket
183	904-03-020-1775	10-Internal Tooth Lockwasher	224	901-04-150-0206	5/16-18 X 5/16" Soc. Set Scr.
184	902-01-120-1203	10-32 Hex Nut	225	1202640	Bearing Ass'y.
185	Nameplate	By Request Only	226	426-05-072-5020	Plate
186	901-06-450-2250	4 X 3/16" Drive Screw	227	426-05-072-5021	Plate
187	901-02-140-0584	10-32 X 3/8" Bind. Hd. Scr.	228	904-01-031-2626	Washer
188	904-03-020-1775	10-Internal Tooth Lockwasher	229	901-03-010-0762	5/16-18 X 5/8" Hex Soc. Cap Scr.
189	426-05-063-5006	Insert Handle	230	901-03-010-0770	5/16-18 X 1-1/4" Soc. Hd. Cap Scr.
**	NOT SHOWN ASSEMBLED		231 n	901-02-010-0502	1/4 - 20 x 1/4 Rd. Hd. Scr.
			232 n	426-05-031-5007	Cover
			233 n	400-06-603-0001	Envelope
			234 n	400-06-079-0001	Retainer

NOTE:

A - All Units After Serial Number 174-0455 Incorporate A New Blade Guide Assembly (426-05-355-5008). This Current Assembly will Replace Either The Early Model Upper Or Early Model Lower Blade Guides. The Current Guide Assembly Is Completely Interchangeable With The Early Model Guides.

# SAFETY RULES FOR ALL TOOLS

As with all power tools there is a certain amount of hazard involved with the operator and his use of the tool. Using the tool with the respect and caution demanded as far as safety precautions are concerned will considerably lessen the possibility of personal injury. However, if normal safety precautions are overlooked or completely ignored, personal injury to the operator can develop.

There are also certain applications for which this tool was designed. Rockwell strongly recommends that this tool NOT be modified and/or used for any application other than for which it was designed. If you have any questions relative to its application DO NOT use the tool until you have written Rockwell and we have advised you.

ROCKWELL INTERNATIONAL  
MANAGER OF PRODUCT SAFETY  
POWER TOOL DIVISION  
400 NORTH LEXINGTON AVENUE  
PITTSBURGH, PENNSYLVANIA 15208

1. **KNOW YOUR POWER TOOL.** Read the owner's manual carefully. Learn the tools applications and limitations, as well as the specific potential hazards peculiar to it.
2. **KEEP GUARDS IN PLACE** and in working order.
3. **GROUND ALL TOOLS.** If tool is equipped with three-prong plug, it should be plugged into a three-hole electrical receptacle. If an adapter is used to accommodate a two-prong receptacle, the adapter lug must be attached to a known ground. Never remove the third prong.
4. **REMOVE ADJUSTING KEYS AND WRENCHES.** Form habit of checking to see that keys and adjusting wrenches are removed from tool before turning it on.
5. **KEEP WORK AREA CLEAN.** Cluttered areas and benches invite accidents.
6. **AVOID DANGEROUS ENVIRONMENT.** Don't use power tools in damp or wet locations, or expose them to rain. Keep work area well lighted.
7. **KEEP CHILDREN AND VISITORS AWAY.** All children and visitors should be kept a safe distance from work area.
8. **MAKE WORKSHOP KIDPROOF** - with padlocks, master switches, or by removing starter keys.
9. **DON'T FORCE TOOL.** It will do the job better and be safer at the rate for which it was designed.
10. **USE RIGHT TOOL.** Don't force tool or attachment to do a job it was not designed for.
11. **WEAR PROPER APPAREL.** No loose clothing, gloves, neckties, or jewelry to get caught in moving parts. Nonslip footwear is recommended. Wear protective hair covering to contain long hair.
12. **USE SAFETY GLASSES.** Also use face or dust mask if cutting operation is dusty.
13. **SECURE WORK.** Use clamps or a vise to hold work, when practical. It's safer than using your hand and frees both hands to operate tool.
14. **DON'T OVERREACH.** Keep your proper footing and balance at all times.
15. **MAINTAIN TOOLS IN TOP CONDITION.** Keep tools sharp and clean for best and safest performance. Follow instructions for lubricating and changing accessories.
16. **DISCONNECT TOOLS** before servicing and when changing accessories such as blades, bits, cutters.
17. **USE RECOMMENDED ACCESSORIES.** Consult the owner's manual for recommended accessories. The use of improper accessories may cause hazards.
18. **AVOID ACCIDENTAL STARTING.** Make sure switch is in "OFF" position before plugging in cord.
19. **NEVER STAND ON TOOL.** Serious injury could occur if the tool is tipped or if the cutting tool is accidentally contacted.
20. **CHECK DAMAGED PARTS.** Before further use of the tool, a guard or other part that is damaged should be carefully checked to ensure that it will operate properly and perform its intended function — check for alignment of moving parts, binding of moving parts, breakage of parts, mounting, and any other conditions that may affect its operation. A guard or other part that is damaged should be properly repaired or replaced.
21. **DIRECTION OF FEED.** Feed work into a blade or cutter against the direction of rotation of the blade or cutter only.
22. **NEVER LEAVE TOOL RUNNING UNATTENDED. TURN POWER OFF.** Don't leave tool until it comes to a complete stop.
23. **DRUGS, ALCOHOL, MEDICATION.** Do not operate tool while under the influence of drugs, alcohol or any medication.



---

## ADDITIONAL SAFETY RULES FOR BAND SAWS

1. **ADJUST** the upper guide about 1/8" above the material being cut.
2. **MAKE SURE** that blade tension and blade tracking are properly adjusted.
3. **STOP** the machine before removing scrap pieces from the table.
4. **ALWAYS** keep hands and fingers away from blade.
5. **CHECK** for proper blade size and type.
6. **DO NOT** attempt to saw stock that does not have a flat surface, unless a suitable support is used.
7. **HOLD** material firmly and feed into blade at a moderate speed.
8. **TURN OFF** machine if the material is to be backed out of an uncompleted cut.
9. **MAKE "release"** cuts before cutting long curves.

# EARLY MODEL BLADE GUIDE

- \* 226 (8)
- \* 230 (4)



\* NOT ASSEMBLED WITH BASIC MACHINE

## INTRODUCTION

All Rockwell Band Saws are carefully inspected and tested before shipment. While in transit, however, it is possible that the machine may get out of alignment. Therefore before putting the machine into operation give it a careful check and make adjustments where necessary. A carefully set up machine will save you time, trouble and money.

## SELECTING FLOOR SPACE

It is important that the Band Saw be set on a solid, level foundation. If rocking occurs, place metal shims at the corners between the cabinet and floor. Lag screws or bolts should be used to secure the machine to the floor.

## CLEANING THE BAND SAW

The machined and unpainted surfaces have been protected with a coating of rust preventive. This coating should be removed with a soft cloth moistened with kerosene or mineral spirits. (Do not use acetone, gasoline or lacquer thinner for this purpose.) After cleaning, cover all unpainted surfaces with a light film of good machine oil.

## INSTALLING THE MOTOR, MOTOR PULLEY AND BELT

1. Assemble the motor to the motor plate, as shown in Fig. 2.
2. Assemble the motor pulley (A) Fig. 2, to the motor shaft, with the outside groove of the motor pulley aligned with the high-speed pulley (B), and tighten the set screw that holds the motor pulley to the motor shaft.
3. Assemble the belt (C) to the two pulleys, as shown in Fig. 2, and adjust belt tension as explained under ADJUSTING BELT TENSION.
4. The "O" ring belt (D) Fig. 2, is shown assembled to the chip blower (E), which is available as an accessory, and to the round groove of the motor pulley.




Fig. 2

# Replacement Parts

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
**	426-05-355-5008	Upper Blade Guide (Current Models Only, See Note A) Const. Of:	72	426-04-400-5002	Lower Wheel, Incl:
1	901-03-010-0760	1/4-20 X 1-1/4" Hex Soc. Cap Scr.	73	901-01-060-0623	1/4-20 X 1" Hex Hd. Scr.
2	904-01-010-1617	Washer	74	904-02-020-1702	1/4" Split Washer
3	1203002	Plate	75	901-04-150-1133	1/2-20 X 3/4" Soc. Set Scr.
4	426-05-014-5036	Bracket	76	426-04-094-5002	Tire
5	426-05-380-5001	Roller Ass'y.	77	426-04-015-5003	Brake Drum
6	901-04-150-0206	5/16-18 X 5/16" Soc. Hd. Set Scr.	**	426-04-358-5001	Lower Wheel Headstock, Const. Of:
	426-05-354-5002	Blade Guard, Incl:	78	426-04-079-5005	Bearing Locknut
10 n	904-03-020-1775	#10 Lockwasher	79	426-04-079-5004	Spammer Nut
11	902-01-120-1203	10-32 Hex Nut	80	920-08-020-5340	Bearing
12	901-02-010-7562	10-32 X 5/16 Scr.	81	426-04-058-5002	Headstock
13 n	901-02-010-0558	8-32 X 1/4 Rd. Hd. Scr.	82	426-04-106-5006	Shaft
14	426-05-014-5020	Guard Bld.	83	920-08-020-5339	Bearing
15	901-01-060-0649	5/16-18 X 1" Hex Hd. Scr.	84	426-04-079-5006	Spec. Jam Nut
16	901-02-010-0558	8-32 X 1/4" Rd. Hd. Scr.	85	904-01-010-1615	13/32 X 13/16 X 1/16" Washer
17	1200464	Finger Guard	86	901-01-060-0648	3/8-16 X 1-1/4" Hex Hd. Scr.
18	1200465	Finger Guard Bld.	87	904-01-010-1606	7/16 X 1 X 5/64" Washer
19	904-03-030-1795	Shake Proof Lockwasher	88	902-01-040-1026	3/8-16 Hex Nut
20	902-01-120-1203	10-32 Hex Nut	89	901-01-060-0646	3/8-16 X 2" Hex Hd. Cap Scr.
21	901-02-140-0584	10-32 X 3/8" Binding Hd. Scr.	90	904-01-010-1606	7/16 X 1 X 5/64" Washer
22	904-01-010-1609	13/64 X 7/16 X 1/16" Washer	91	426-04-112-5001	Threaded Bushing
23	901-02-140-0584	10-32 X 3/8" Binding Hd. Scr.	92	927-03-010-2653	1/4 X 1/4 X 1-15/16" Key
24	426-04-110-5003	Guide Post	93	927-03-010-2620	1/4 X 1/4 X 1-1/2" Key
25	426-04-014-5011	Guide Post Bld.	94	1201866	2 Step Drive Pulley, Incl:
26	901-02-010-0593	10-24 X 3/8" Rd. Hd. Scr.	95	901-04-150-6202	5/16-18 X 3/8" Set Scr.
27	904-01-010-1615	13/32 X 3/16 X 1/16" Lockwasher	96	49-132	V-Belt
28	901-01-060-3102	3/8-16 X 3/4" Hex Hd. Scr.	97	1201865	Motor Pulley, Incl:
29	426-04-074-5002	Plug	98	901-04-150-1185	1/4-20 X 5/16" Soc. Set Scr.
30	928-01-041-3361	Spring	99	426-04-430-5001	Motor Pulley (1-1/8" Bore) Incl:
31	426-04-112-5002	Clamp Scr.	99	901-04-150-1185	1/4-20 X 5/16" Soc. Set Scr.
32	931-04-010-3635	Clamp Handle	99	926-01-042-5514	Lo Speed Drive Pulley
33	901-02-120-7528	1/4-20 X 1/2" Truss Hd. Scr.	100	901-04-150-6202	5/16-18 X 3/8" Set Scr.
34	426-04-112-5001	Treaded Bushing	101	926-05-022-5507	High Speed Drive Pulley
35	901-01-060-0617	3/8-16 X 1-1/2" Hex Hd. Scr.	102	901-04-150-6202	5/16-18 X 3/8" Set Scr.
36	426-04-400-5001	Up. Wheel, Incl:	103	49-132	Lo Speed Belt
37	426-04-094-5002	Tire	104	49-131	High Speed Belt
38	901-04-150-1133	1/2-20 X 3/4" Soc. Set Scr.	105	41-707	Motor Pulley (7/8" Bore) Incl:
**	426-05-358-5002	Up. Wheel Headstock, Const. Of:	106	901-04-150-0202	1/4-20 X 1/2" Hex Soc. Set Scr.
39	426-05-106-5005	Shaft	105	41-707	Motor Pulley (1 7/8" Bore) Incl:
40	406-03-079-0001	Bearing Nut	106	901-04-150-0202	1/4-20 X 1/2" Hex Soc. Set Scr.
41	920-04-020-5383	Bearing	107	426-04-014-5003	Bracket
42	426-04-079-5006	Spec. Jam Nut	108	901-01-060-0648	3/8-16 X 1-1/4" Hex Hd. Scr.
43	426-05-058-5002	Headstock	109	426-04-106-5001	Steel Pin
44	920-08-020-5336	Bearing	110	905-05-040-2101	3/32 X 5/8" Cotter Pin
45	902-01-201-2558	Spec. Hex Nut	111	928-05-001-5878	Spring Washer
46	901-11-010-2371	3/8-16 X 2-1/2" Sq. Hd. Bolt	112	426-04-079-5007	Retainer
47	904-01-010-1606	7/16 X 1 X 5/64" Washer	113	904-01-010-1615	13/32 X 13/16 X 1/16" Washer
48	928-01-041-4148	Spring	114	904-02-020-1704	3/8" Split Lockwasher
49	426-04-052-5001	Clb	115	902-02-040-1307	3/8"-6 Sq. Nut
50	904-02-020-1704	3/8" Split Lockwasher	116	426-04-315-5001	Brake Shoe w/Lining
51	901-01-060-0642	3/8-16 X 1" Hex Hd. Scr.	117	902-01-040-1005	3/8"-16 Hex Jam Nut
52	426-04-072-5009	Tension Scale	118	904-01-010-1606	7/16 X 1 X 5/64" Washer
53	901-02-010-0567	6-32 X 1/4" Rd. Hd. Scr.	119	426-04-108-5003	Brake Rod
54	426-05-084-5002	Slide	120	904-01-010-1606	7/16 X 1 X 5/64" Washer
55	901-04-530-6149	1/2-13 X 1-15/16" Soc. Set Scr.	121	928-01-301-8880	Spring
56	902-01-020-1266	1/2-13 Hex Jam Nut	122	904-01-010-1606	7/16 X 1 X 5/64" Washer
57	904-01-010-1606	7/16 X 1 X 5/64" Washer	123	426-04-067-5002	Treadle
58	426-05-409-5001	Extension Incl:	124	901-04-020-0345	1/2-13 X 5/8" Sq. Hd. Scr.
59	905-01-010-2704	1/8 X 3/4" Roll Pin	125	426-04-017-5001	Brass Bushing
60	426-04-072-5007	Slide Plate	126	905-05-040-2107	Cotter Pin
61	904-02-020-1705	1/2" Split Lockwasher	127	426-04-067-5001	Brake Lever
62	901-01-060-0628	1/2-13 X 1" Hex Hd. Scr.	128	901-04-150-0210	1/2-13 X 1/2" Soc. Set Scr.
63	928-01-041-4149	Spring	129	426-04-106-5008	Shaft
64	951-01-011-3992	Pointer	130	904-10-021-2096	Set Collar
65	426-04-074-5001	Plug	131	901-04-150-0206	5/16-18 X 5/16" Hex Soc. Set Scr.
66	901-01-060-0617	3/8-16 X 1-1/2" Hex Hd. Scr.	**		Upper Blade Guide (Early Model Only, See Note A) Const. Of:
67	426-04-112-5001	Treaded Bushing	132	901-03-010-0762	5/16-18 X 5/8" Soc. Hd. Cap Scr.
68	952-01-121-3268	Tension Screw (Early Model)	133	904-01-031-2926	Washer
		Threads One End Only	134	426-05-072-5021	Plate
68	1201927	Tension Screw (Current Model)	135	426-05-072-5020	Plate
		Threads Both Ends	136	426-05-014-5021	Bracket
69	905-01-010-2711	1/8 X 5/8" Roll Pin (Current Model Only)	137	1202640	Bearing Ass'y.
70	422-02-100-2001	Handwheel (Current Model)	138	901-04-150-0206	5/16-18 X 5/16" Soc. Hd. Set Scr.
70	931-03-991-4766	Knob Ass'y., (Early Model), Incl:	139	901-03-010-0770	5/16-18 X 1-1/4" Soc. Hd. Cap Scr.
70A	901-04-150-0206	5/16-18 X 5/16" Soc. Set Scr.			
71	902-01-010-5900	3/8-16 Hex Nut (Current Models Only)	**	NOT SHOWN ASSEMBLED	

## ADJUSTING BLADE TENSION

The blade is only under slight tension when the band saw is shipped from the factory. This is done to prevent weakening of the blade prior to its use. It is good practice to relax tension on the blade when the machine is not in use. To adjust blade tension, proceed as follows:

1. Turn the blade tension knob (A) Fig. 3, clockwise until the pointer (A) Fig. 4, is on the mark on the tension scale (B), which is equal to the blade width.
2. The tension scale (B) Fig. 4, is correct for standard blades used on average work. It is not affected by variations in blade length and is equally accurate when the blade has been shortened by welding or brazing. Experienced operators may rely upon the feel or tone of the blade for adjusting tension. We recommend the use of the scale to avoid blade breakage, by too much or too little tension. For a blade which is thicker than standard, run the tension pointer slightly higher than the mark on the scale.

## TRACKING THE BLADE

For accurate work and maximum blade life, it is important that the blade be centered on the upper wheel. When this adjustment has been properly made, the blade will "track". That is, it will run steadily in the same line. Before the tracking adjustment is made, both the upper and lower blade guides must be moved away from the blade. To "track" the blade, proceed as follows:

1. Disconnect the machine from the power source and make sure that correct blade tension is applied to the blade.
2. Revolve the upper wheel forward slowly by hand and turn the tracking adjustment hand knob (B) Fig. 3, until the blade travels in the center of the upper tire.
3. Connect the machine to the power source and jog the motor switch on and off to be certain that proper tracking is being maintained.
4. Then make any minor final adjustments that may be necessary at operating speed.




Fig. 3




Fig. 4

**NOTE:** To avoid the possibility of injury to the blade or operator, the initial tracking adjustment should not be made while the machine is under power, since at high speed the blade may run off the wheel almost instantly. THE TRACKING KNOB SHOULD BE ADJUSTED ONLY A FRACTION OF A TURN AT A TIME AS VERY LITTLE TILT OF THE UPPER WHEEL IS REQUIRED TO DRAW THE BLADE ACROSS THE WHEEL. Each blade has its own tendencies, especially after welding or brazing. The blade tracking adjustment must, therefore, be repeated whenever a new or repaired blade is installed, regardless of previous adjustments.




Rockwell  
International

# 28-340 20" WOOD/NON-FERROUS CUTTING BAND SAW

BS-3A

426-04-651-5004  
Revised 4-1-80



\* NOT ASSEMBLED WITH BASIC MACHINE



## ADJUSTING BLADE GUIDES

The upper and lower blade guides are to be adjusted only after the blade is tensioned and is tracking properly. The blade guide plates (A) Figs. 5 and 6, are fastened to the blade guide brackets as shown. A total of 28 individual guide plates are supplied to accommodate any blade width up to 1". Guide plates can be added or removed from the blade guide brackets depending on the width of the blade being used, as follows:

1. To add or remove guide plates (A) Figs. 5 and 6, remove the four screws and washers (B). Add or remove the necessary number of guide plates (A) until the front edge of the guide plates are just behind the bottom of the saw blade tooth gullets, leaving all of the set portion of the blade free of the guide. Then tighten the four screws (B). NOTE: This adjustment is critical since the teeth of the blade will be damaged if the guide plates are too far forward. If the guide plates are too far back the blade will not be adequately supported.

2. The upper and lower blade guide plates (A) Figs. 5 and 6, should be parallel to each other and as close as possible to the blade without binding it. Rotate the upper wheel by hand, causing the entire length of the blade to pass through the guide plates. This is done to be sure the weld or braze (where extra thickness may be found) will not bind. If necessary, separate the guide plates to accommodate the extra thickness.

## ADJUSTING BLADE SUPPORT BEARINGS

1. Loosen the bearing support screw (C) Fig. 5, and adjust the support bearing (D) to within  $1/64$ " of the blades rear edge. In essence, the blade support bearing (D) Fig. 5, should be adjusted as closely as possible to the rear edge of the blade so as not to rotate whenever the blade is running free without cutting. When the blade is cutting it will be pushed back to the rear and the support bearing will then rotate.

2. The lower blade support bearing (D) Fig. 6 is adjusted in the same manner.




Fig. 5




Fig. 6

## ADJUSTING BELT TENSION

The correct tension is obtained when the belt on the band saw can be flexed approximately  $1/4$  inch out of line, using 6 pounds of pressure at the center span of the pulleys.

To adjust belt tension:

1. DISCONNECT BAND SAW FROM POWER SOURCE.

2. Move the motor mounting plate (A) Fig. 7, to the right or left, by turning the adjusting nuts, one of which is shown at (B) Fig. 7, until correct tension is obtained.




Fig. 7

# ROCKWELL AUTHORIZED PARTS DISTRIBUTORS

The Authorized Rockwell Parts Distributors or Service Centers listed below stock a complete line of replacement parts. To save time and shipping costs, send your parts orders to your nearest Distributor or Rockwell Branch. In most cases they will be filled and shipped within 48 hours. Parts orders are not filled direct from the factory.



**ATLANTA, GEORGIA 30340**  
Rockwell International  
3500 McCall Place  
Phone: 404 458-2263

**BOSTON, MASSACHUSETTS 02134**  
Rockwell International  
414 Cambridge Street  
Phone: 617 782-1700

**BUFFALO, NEW YORK 14204**  
Karle Saw Company, Inc.  
138-150 Chicago St., Cor. So. Park Ave.  
Phone: 716 853-8053 or 8054

**CHICAGO, ILLINOIS 60610**  
Rockwell International  
4533 North Avenue  
Melrose Park, Illinois  
Phone: 312 345-8900

**CINCINNATI, OHIO 45215**  
Rockwell International  
1433 Glendale-Milford Road  
Phone: 513 772-1490

**DALLAS, TEXAS 75247**  
Rockwell International  
2934 Iron Ridge Street  
Phone: 214 631-1890

**DENVER, COLORADO 80207**  
Rockwell International  
4900 East 39th Avenue  
Phone: 303 388-5803

**DETROIT, MICHIGAN 48037**  
Rockwell International  
18650 W. Eight Mile Road  
Phone: 313 569-4333

**HONOLULU, HAWAII 96819**  
Rockwell International  
3209 Koapaka Street  
Phone: 808 847-2048

**N. KANSAS CITY, MISSOURI 64116**  
Rockwell International  
1141 Swift Avenue  
Phone: 816 221-2070

**LOS ANGELES, CALIFORNIA 90007**  
Rockwell International  
2400 South Grand Avenue  
Phone: 213 749-0386

**MILWAUKEE, WISCONSIN 53222**  
Rockwell International  
10700 W. Burleigh Street  
Phone: 414 774-3650

**NEW YORK, NEW YORK 10013**  
Rudolf Bass, Inc.  
175 Lafayette Street, Cor. Grand Street  
Phone: 212 226-4000

**PHILADELPHIA, PENNSYLVANIA 19120**  
Rockwell International  
4433-37 Whitaker Avenue  
Phone: 215 455-7907

**PITTSBURGH, PENNSYLVANIA 15208**  
Rockwell International  
400 N. Lexington Avenue  
Phone: 412 247-3600

**SAN LEANDRO, CALIFORNIA 94577**  
Rockwell International  
3039 Teagarden Street  
Phone: 415 357-9762

**SEATTLE, WASHINGTON 98101**  
Rockwell International  
1918 Minor Avenue  
Phone: 206 622-4576

**CANADA**  
**ROCKWELL INTERNATIONAL**  
**OF CANADA LIMITED**  
40 Wellington Street, P. O. Box 848  
Guelph, Ontario, Canada  
Phone: 519 822-2840

## YOUR ROCKWELL WARRANTY

Rockwell is proud of the quality of the power tools which it sells. The component parts of our tools are inspected at various stages of production, and each finished tool is subjected to a final inspection before it is placed in its specially designed carton to await shipment. Because of our confidence in our engineered quality, Rockwell agrees to repair or replace any part or parts of Rockwell Power Tools or Rockwell Power Tool Accessories which examination proves to be defective in workmanship or material. In order to take advantage of this guarantee, the complete portable power tool or accessory, or in the case of machinery, the part must be returned prepaid to the appropriate factory, Rockwell service center, or authorized service station for examination. This guarantee, of course, does not include repair or replacement required because of misuse, abuse, or normal wear and tear. Repairs made by other than our factory, service center, or authorized service station, relieves Rockwell of further liability under this guarantee. THIS GUARANTEE IS MADE EXPRESSLY IN PLACE OF ALL OTHER GUARANTEES OR WARRANTIES, EXPRESS OR IMPLIED, WITH RESPECT TO QUALITY, MERCHANTABILITY, OR FITNESS FOR A PARTICULAR PURPOSE.

# ROCKWELL

*...the name that stands for Service, Quality and Performance!*

## TABLE ADJUSTMENTS

The table may be tilted 45 degrees to the right and 12 degrees to the left. To tilt the table to the left, first tilt it to the right, swing the stop bar (A) Fig. 8, to the rear for clearance, and tilt the table to the left to the desired angle.

Although the table is adjusted at the factory to be at right angle with the blade, this adjustment should be checked out as follows:

1. With the blade under tension, place an accurate square on the table with one end of the square against the flat side of the blade to the rear of the tooth gullets.
2. If the table is not square, left to right, loosen nut (B) Fig. 8, and adjust the set screw (C) up or down as the case may be until the table is square and tighten nut (B).
3. When the table has been set at right angle to the blade, set the pointer on the tilt angle scale to read zero.




Fig. 8

## CHANGING SPEEDS

With a 1725 rpm motor you can obtain a cutting speed of 2000 fpm for non-ferrous cutting, and 4500 fpm for wood cutting.

When the belt (A) Fig. 9, is assembled to the outside groove of the motor pulley (B) and the small driven pulley (C), the cutting speed will be 4500 fpm.

For 2000 fpm, non-ferrous cutting, simply remove the belt (A) Fig. 9, and assemble the longer belt, which is supplied with your machine, to the center groove of the motor pulley (B) and the large driven pulley (D). Then adjust belt tension as explained under ADJUSTING BELT TENSION.




Fig. 9

## TABLE INSERT

The table insert is furnished with a little lug or protrusion that fits into the blade removal slot of the table and prevents the insert from vibrating loose and turning.

## BLADE REMOVAL SLOT

The blade removal slot of the table is furnished with a threaded plug. This plug is used for aligning the front and rear halves of the groove in the table of your band saw. CAUTION: CARE SHOULD BE TAKEN AGAINST EXCESSIVE TIGHTENING OF THIS PLUG SINCE THIS CAN CREATE STRESSES WHICH COULD RESULT IN THE TABLE BECOMING CRACKED.

Whenever the miter gage is used, the plug should be turned just far enough to allow the miter gage bar to slide freely in the table groove.

## WHEEL ALIGNMENT

Wheels are adjusted at the factory so that they are both in alignment. The upper wheel slide plate is fastened to the frame with three cap screws and one threaded bushing. This forms a three point mounting feature. If the two wheels are not parallel and in alignment when viewed from above, proceed as follows:

1. Loosen screw (64) page 8, and turn threaded bushing (65) in and out until the upper wheel is parallel to the lower wheel, then tighten cap screw.
2. The blade must ride in the center of the wheel (on the crown). The upper wheel as explained previously can be tilted for this reason. If the blade is not riding in the center of the lower wheel, the wheel can be tilted. The lower wheel mounting plate also contains the three point mounting features. To adjust, loosen Cap Screw (88) page 8, and turn threaded bushing (87) in or out the required amount, then tighten cap screw.

## REPLACING TIRES

When a tire needs replacing, first remove the old tire from the wheel. After removing, clean the surface of the wheel, and apply the new tire as follows:

1. Place one portion of the tire completely on the wheel and fasten using a clamp, as shown in Fig. 10.
2. Work the tire onto the wheel by hand as far as possible.
3. Pry the remainder of the tire onto the wheel using two screwdrivers or other suitable instruments, as shown in Fig. 11.

## MAINTENANCE

Clean tires frequently by scraping off accumulations of chips, gum and pitch.

Lubricate sliding parts with a few drops of light oil. All bearings and motors are lubricated for their life, sealed and required no further lubrication.




Fig. 10




Fig. 11