

MACH # 654

MANUAL 45

MACH 654

**TABLE TYPE
"D" SERIES**

1155 & 1843

NEWMAN 1844
MODEL 350T S/N 9300

**HORIZONTAL BORING, DRILLING
AND MILLING MACHINES**

**INSTRUCTION AND
PARTS MANUAL**



Giddings and Lewis Machine Tool Co.

Fond du Lac, Wisconsin, U.S.A. 54935

PH. 414-921-9400

GIDDINGS & LEWIS MACHINE TOOL COMPANY

**PARTS AND INSTRUCTION MANUAL
FOR**

**MODEL "D"
and (340-T) (350-T)**

HORIZONTAL BORING, DRILLING AND MILLING MACHINES

INSTRUCTIONS FOR ORDERING REPAIR PARTS

Your repair parts orders will receive the best service if, when ordering, the following information is clearly stated:

1. The quantity of each part required
2. The part name and the part number
3. The serial number of the machine. The serial number is stamped on a name plate which is found on the lower left hand corner of the spindle feed case. Orders cannot be accepted without this serial number.

COPYRIGHT 1958


GIDDINGS & LEWIS MACHINE TOOL COMPANY

Fond du Lac, Wisconsin, U.S.A.

PRICE \$25.00

INDEX

Section	Page No.
1 INSTALLATION	1
2 LUBRICATION	10
3 OPERATION	16
4 OPTIONAL ARRANGEMENTS	24
5 ADJUSTMENTS	28
6 REPAIR PARTS	Drawing No.
Manual Spindle Reversing	A-150-30-1
Transmission Control	A-150-31-1
Motor Drive and Reversing Clutch with Foot Mounted Motor	A-150-32-1 - 2 Dwgs.
Milling Feed Control	A-150-33-1
Column (340-T)	A-150-35-1
Column (350-T)	A-150-35-2
Headstock (340-T)	A-150-40-1
Headstock (340-T)	A-150-40-2
Headstock (340-T)	A-150-40-3
Headstock (340-T)	A-150-40-4
Headstock (340-T)	A-150-40-5
Headstock (340-T) (Spindle Feed)	A-150-40-6
Headstock (350-T)	A-150-40-7
Headstock (350-T)	A-150-40-8
Headstock (350-T)	A-150-40-9
Headstock (350-T)	A-150-40-10
Headstock (350-T)	A-150-40-11
Headstock (350-T) (Spindle Feed)	A-150-40-12
Table and Saddle (340-T)	330-A-5
Saddle Screw Reduction (340-T)	330-A-8
Milling Feed	330-A-10
Transmission	330-A-11
Feed Box	340-A-46
Table and Saddle (350-T)	350-A-6 (59)
Table Drive	350-A-25-B
Saddle Screw Reduction (350-T)	350-A-27
Headstock - Oil Piping	350-A-55
Anti-Friction End Support Assembly	350-A-84
Pendant Control	SK-1702
Automatic Positioning Master Switch	SK-1736-1



APPROXIMATE LIFTING WEIGHTS OF MAJOR UNITS
FOR 340-T AND 350-T MACHINES

	340-T	350-T
Headstock	4,000	<u>5,000</u>
48" Column	4,300	7,000
60" Column	4,800	7,700
72" Column	5,300	<u>8,400</u>
36" x 72" Table and Saddle	6,000	-
48" x 72" Table and Saddle	7,500	10,500
340-T and 350-T		
48" x 96" Table and Saddle	11,500	
48" x 120" Table and Saddle	<u>15,000</u>	
60" x 96" Table and Saddle	14,800	
60" x 120" Table and Saddle	16,200	
60" x 144" Table and Saddle	17,500	
72" Bed	10,000	
96" Bed	12,000	
120" Bed	<u>14,000</u>	
End Support	<u>3,000</u>	

Section I INSTALLATION

SHIPMENT AND TRANSIT

All Giddings and Lewis machines are completely assembled, run off, and inspected at the factory. Their size prohibits the shipping of them completely assembled and they have been carefully dismantled for this reason.

For domestic shipment, the machine units are placed on skids. All machined surfaces are coated with slushing compound and the entire machine is covered with waterproof paper and tarpaulins for shipment on flat cars. You will be billed for the tarpaulins, which are to remain the property of the Giddings and Lewis Machine Tool Company. You will receive full credit for them when they are returned.

For export shipments, all machines are disassembled into their various units and are shipped completely boxed and protected for ocean shipment.

When removing the machine components from flat cars or when lifting during assembly, heavy pads or wood blocks should be placed at all points where lifting cables or chains contact the machine. Be sure no chain or rope exerts strain on any projecting parts. **A CRANE OF SUFFICIENT CAPACITY SHOULD BE USED FOR LIFTING ALL MAJOR UNITS.** (See weight chart on opposite page.)

Carefully check all parts of the machine against the packing list included with each shipment. Report immediately any damage or shortages to the carrier and to the representative of our agent from whom the machine was purchased.

PREPARATION FOR INSTALLATION

Use gasoline, kerosene, or any non-inflammable cleaner to remove the slushing compound from each unit as it is needed during assembly. A Giddings and Lewis service representative is available on request to supervise the assembly of all domestic machines. If you require a service representative, clean all units thoroughly, and move them to a location near the machine's foundation prior to his arrival.

FOUNDATION

The G&L table type horizontal boring, drilling, and milling machines described in this manual are provided with a one piece bed of heavy box type, internally ribbed construction. Regardless of the rigidity obtained from this type of construction, however, these machines will perform most satisfactorily when placed on a solid foundation free from vibration. They should not be mounted on any individual anti-vibration devices of either spring or rubber pad construction.

The foundation should be a one piece solidly constructed reinforced concrete slab, insulated from the surrounding floor. The minimum recommended depth is shown on our foundation plans. The actual depth required will vary depending on the local soil conditions.

Hollow leveling screws, threaded into the bed flange, are used for leveling the machine. Separate hold-down bolts which extend through the leveling screw are used to maintain position and alignment. (See figure 1.)




Figure 1. Leveling Screw Arrangement

Small round leveling plates are furnished with the machine which are finished with a spherical seat to fit a mating radius on the leveling screws. These plates will be found in a box of auxiliary equipment and are to be placed over the hold-down bolts before setting the machine bed in place. The hold-down bolts, which are not furnished with the machine, should be set in the foundation as illustrated in figure 1. This method will allow the foundation to be completely finished before the machine arrives. A smooth surface on the concrete slab is desirable so the leveling screw plates will lie flat and level.

NOTE

When setting the machine on the foundation, it is recommended that you do not grout it in place. Periodic re-leveling and re-alignment will be necessary to insure continued accuracy of machine.

Before leaving the factory, each machine is tested under power for precision alignments and tolerances. These indicator tests are positive and can be re-established by proper leveling when the machine is set up on its own foundation. The G&L service representative who assists in the erection of your machine will make these alignment checks before turning the machine over to your operator.

BED

The initial step in the assembly of your horizontal boring machine is to place the bed over the hold-down bolts on your foundation. The bed and the leveling screws should be thoroughly cleaned of all slushing compound. The leveling screws should be extended approximately 1/2" below the machined pads on the bottom of the bed.

When lifting the bed casting, heavy steel bars should be placed through the holes at either end of the bed for ease of handling with chains or cable. Use mats or lumber to protect all machined and painted surfaces during the handling of the major castings, (figure 2).




Figure 2. Crane Hookup for Bed

After the bed is resting on the leveling screw plates, it should be completely leveled and retained with the hold-down bolts. This is accomplished with one or two precision levels graduated .0005" per foot per line. A ground or scraped parallel should be used to span the bed ways for leveling at right

angles to the bed length. At the rear of the bed, the levels may be placed directly on the scraped surface forming the seat for the machine column.

When the bed is leveled the auxiliary saddle support runways, if furnished, may be set in place in their respective troughs and leveled up individually. In doing this, the distance from the center of the runway to the edge of the bed way and the vertical distance between the two way surfaces should be held within 1/16" of the dimensions shown on the foundation drawings. These runways may be leveled by setting a precision level in both directions on the ground top surface.

On machines furnished with over-the-floor type saddle support runways, the runway castings should be bolted to the sides of the machine bed before the bed has been lowered in position over the hold-down bolts. The runway surface may then be leveled with the leveling screws and hold-down bolts along the edge of the casting.

COLUMN

Before placing the column on the bed, extreme care should be taken to make sure that both mating surfaces are perfectly clean and free from nicks. A fine file should be used to go over the surfaces lightly to remove any bumps or nicks which may have occurred in handling. The column should then be carefully set over the integral key on the bed and the two ground steel spacer shims (packed in a separate box) inserted immediately in front of the keys according to the numbers stamped thereon.

The set screws at the rear of the column should be partially tightened to draw the column back against the ground shims. The column may then be moved slightly to the right or left with a bumping bar or heavy timber to align the two tapered dowel pin holes. Care should be taken that these holes are in exact alignment before seating the dowel pins. The set screws which pull the column against the ground shims may now be fully tightened and all cap screws inserted and secured.

NOTE

Column may be lifted as shown in figure 3.

HEADSTOCK

The headstock should be thoroughly cleaned and the head and column ways carefully checked for nicks or bumps. Remove vertical pivot pins and the two headstock inner clamps for cleaning. The clamps should be installed and set in position toward the center of the headstock. The pivot pins may be inserted after the head is in place on the column.




Figure 3. Lifting Column

The headstock may now be lifted with two chains or cables as shown in figure 4. Chains should be adjusted to hold the head in an exact horizontal position. Adjustment of the spindle position in or out, to aid in balancing the head, can be accomplished with the hand wheel. Care should also be taken to protect the head from damage resulting from chains or cables.

The headstock may be moved into position on the column ways making sure they are adequately oiled in the process. The outer clamp strips may then be bolted tightly to the head and the four gibs inserted and held loosely in place by retaining screws. The head should be lowered on the column and set to rest on a 4" x 4" wood block about 18" high. Place block on bed directly adjacent to the rear column way. The headstock gibs may now be loosely adjusted and the hoisting chains removed.

Immediately following the hanging of the headstock, the felt and brass wiper parts should be assembled to the top and bottom of the head to prevent accumulation of any foreign matter in the wiper recesses. These parts will be found in small shipping bags in the box of auxiliary equipment.




Figure 4. Mounting Headstock on Column

For installations where there is sufficient room overhead, the headstock may be lowered over the top of the column ways. This will make it possible to install the outer clamp strips before the head is mounted on the column. The inner clamps may also be left in position with the pivot pin in place.

When mounting the head in this manner, an assembler should sit on top of the column to assist in guiding the head over the column ways.

COUNTERWEIGHT

After the column is bolted in place, the counterweight chain should be fastened to the main counterweight and the weight lowered into the column cavity, (figure 5). A heavy timber should be inserted through the opening at the rear of the column to support the weight until it is hooked up to the headstock. If any auxiliary weights are supplied, they should now be placed on top of the main counterweight.



Figure 5. Lowering Counterweight into Column

SHEAVE BRACKET

The counterweight sheave bracket may now be placed in position on top of the column taking care to thread the counterweight chain over the two sheaves, (figure 6). The two taper dowel pins and all bolts should be inserted in place and secured.



Figure 6. Mounting Sheave Bracket on Column

The two bearing caps on the sheave bracket should be removed and the elevating screw and vertical drive shaft lowered in place, (figure 7). The bearings on these shafts should not have to be removed for assembly unless the shafts must be inserted from the bottom. If this is necessary, make sure that the bearings are seated firmly against the shoulder on the shafts at reassembly.

It will be necessary to thread the elevating screw through the nut on the headstock and down into the splined socket in the bed. After initial engagement in the splined socket is made, the screw can be turned down the rest of the way by using the safety hand crank on the bed. The headstock may then be cranked upwards on the column so the counterweight chain can be attached and the wood block beneath the head removed.

The elevating screw bearing retainer cap may now be bolted in place. The vertical drive shaft has a




Figure 7. Installing Elevating Screw

self aligning bearing at its upper end and the proper alignment of it can be assured by tightening the bearing retainer cap only after the headstock is moved to a position near the top of the column. This can be accomplished after power is applied to the machine.

When the elevating screw bearing retainer cap is in place, the headstock may be lowered on the column with the safety hand crank to elevate the counterweight. This will permit the wood blocking beneath the counterweight to be removed from the column.

The headstock gibs should now be given a final adjustment. This is done by drawing up the gib retaining bolts until they are snug making sure the smaller set screws are completely free. The retaining bolt should then be backed off one-quarter turn and the set screw tightened down to back out the gib slightly.

CONTROLS

The control panel may be bolted in place on the column. The swinging pendant arm should be mounted on top of the sheave bracket and all the wiring to the panel properly connected. The wiring diagrams for the machine will be found in an envelope inside the control panel.

TABLE AND SADDLE

The table and saddle assembly should be thoroughly cleaned and the saddle way surfaces carefully inspected for nicks or bumps. The bed ways should also be cleaned and covered with a generous film of oil. The table and saddle may now be lifted using a double sling arrangement, (figure 8), and set on the bed ways about midway between the column and end of the bed. The table clamp lever and table feed engagement lever should be on the side facing the machine column. When lowering the saddle, it should be held tightly against the guiding edge of the bed ways (i.e. edge nearest operator's position) so the long brass gib may be inserted on the opposite side. The long clamps on each side of the saddle and the saddle clamp mechanism may be installed after the saddle is set on the bed ways. The felt and brass wipers should also be attached to all surfaces as soon as possible.

The bearing bracket on the end of the bed should now be removed and cleaned. The saddle feed screw, the table drive spline shaft and the end support drive shaft should be placed in position and supported at the end of the bed by tying or wiring them to a brace




Figure 8. Crane Hookup for Table and Saddle

laid across the bed ways. The bearing bracket can now be replaced over the bearings on the ends of the three shafts. The saddle feed nut should be bolted loosely in place and should be tightened only after power has been applied and the saddle moved to the end of the bed where the nut can assume the proper alignment.

NOTE

Do not attempt to move the table on the saddle by hand or power until the four shims placed at each corner beneath the table clamp strips are removed.

SADDLE SUPPORTS

If the machine is supplied with auxiliary saddle supports, these units may now be bolted to the bottom side of the saddle. To do this, the saddle supports should be set on the auxiliary runways in the proper position to roll them into place. Each support is stamped with a number corresponding to an identical number on the mounting pad beneath the saddle for proper location. The rollers under the saddle supports should be adjusted so the units will roll underneath the saddle. After bolting the units in place, the rollers should not be lowered to rest on the rails until the rest of the machine has been completely leveled.

END SUPPORT

The end support unit can now be assembled to the machine. An I-bolt is attached to the top of the end support column for lifting, (figure 9). There are two clamp plates on the underside of the column for holding it to the bed. The plates have elongated holes which permit them to be pulled back to clear the edges of the bed ways. The two bolts and clamp lever on each side must be loosened to allow them to be moved. There is a flat gib on the front way aligning the end support to the bed laterally. The two socket head adjusting set screws should be loosened so the gib will lie flat against the end support column casting. After the ways are cleaned and oiled, the end support may be lowered onto the bed and the clamps positioned and tightened under the bed ways.

NOTE

When lowering the end support the pinion used for moving the end support on the bed must be meshed into the rack. This can be accomplished by turning the pinion with the safety hand crank.




Figure 9. Lowering End Support on Bed

The machine headstock should now be positioned to the same elevation as the end support bearing block. This can be checked by reading the respective vernier scales. After this is done, the bevel gear attached to the end support drive shaft can be bolted to the column, (figure 10). This provides the power for moving the bearing block simultaneously with the headstock.

After moving the two units up and down several times, their respective heights should be checked again. If they are out of alignment by more than .030", the bevel gear bracket should be loosened




Figure 10. End Support Lower Works

and disengaged while the headstock is positioned to the correct position. The bracket can then be bolted in place. A final precision alignment is described under "Adjustments", page 31.

COOLANT SYSTEM

If a coolant system is supplied, the pump and piping and the coolant trough can now be mounted on the machine and wired into the control panel, (figure 11).

LEVELING

After completion of the machine installation, it is necessary to check and adjust the machine for its level condition and take all machine alignments to assure the maximum accuracy in machining operations. This should be accomplished after the machine is completely wired and lubricated (see instructions in lubrication section, page 10).




Figure 11. Coolant System

All of the hold down bolts should be loosened and the saddle moved to a position toward the end support end of the bed. For proper leveling, it will be necessary to obtain a precision machine level having a vial accuracy of 10 seconds with one division equalling one-half thousandth of an inch per foot. Two levels of this type are actually more desirable so one may be used in each direction though it is possible to interchange a single level if that is all that is available. In addition to this, it is necessary to obtain an accurate parallel 1" or more wide and long enough to bridge across the bed ways.

The levels should first be placed on the leveling pads on the two rear sides of the column, (figure 12). The leveling screws around the operator's end of the bed should be adjusted to bring the reading on these two level positions to within one line on the level. Care should be taken to be sure all leveling screws are carrying an equal amount of load in this operation. The anchor or hold down bolts should be tightened as the leveling screws are adjusted. The lock nut on the leveling screw itself should not be tightened until the entire leveling job is completed.




Figure 12. Leveling Column End of Bed

The parallel should now be placed across the bed ways as close to the column end of the bed as possible making sure that both the ways and the parallel are free from burrs or nicks. Its position on the bed ways should be indicated on the parallel with a pencil or crayon so it can always be set in the same relative location. One precision level may now be placed on the parallel and the other on and parallel to the bed way on the operator's side of the machine, (figure 13). These readings should be checked and compared and leveling adjustments made with the screws on either side of the bed.




Figure 13. Level Arrangement on Bed

The bed should be raised or lowered gradually by using the screws nearest the level and the next several sets of leveling screws. Do not try to accomplish all the necessary adjustments on one leveling screw as this will tend to leave that particular section extremely high or low compared with the rest of the bed.

The parallel should then be moved to a position over the next pair of leveling screws and the level be placed on it in the same location. The other level should be moved further down the bed way between the next pair of leveling screws and appropriate adjustments made in each direction. This procedure should be repeated along the entire length of the bed. It will be necessary to move the table and saddle back and forth on the bed to keep clear of the desired leveling area. It will probably also be necessary to repeat this procedure two or three times to correct errors which were created in the continuous leveling operation.

After the bed ways are completely leveled, the level should again be placed on the leveling pads at the rear sides of the column and the leveling screws adjusted to obtain a proper reading. Care should be taken that all of the adjustment is not made on any one leveling screw in order not to affect the level condition established for the rest of the bed. When using the leveling pads on the column, extreme caution must be exercised to make sure that they are not nicked and that the level is setting on them properly. These pads are scraped at the time of final machine assembly to a level reading after the machine alignments have been taken with an indicator and cylindrical post. These pads are quite vulnerable to damage in shipment and in handling and it will occasionally be necessary to recheck the machine alignments by indicating the travel of the headstock. This will be explained later in this section.




Figure 14. Spindle Sleeve Sweep to Column

When the machine is perfectly level, the locking nuts on the leveling screws should all be tightened. It is not necessary to make these nuts extremely tight as too much pressure might actually affect the level condition of the machine.

The saddle support rails should be leveled in a similar manner using two levels set parallel and at right angles respectively to the length of the rail. When leveling these rails for the first time, it is necessary to gauge the vertical distance from the top of the bed ways and hold it to within 1/16" of the dimension shown on the machine foundation plan. After these rails are completely leveled, the saddle supports should be adjusted so they will carry part of the weight of the table and table load. To do this, the table should be run out flush with the end of the saddle and a level set on the end of it parallel to the saddle ways. The saddle support should then be adjusted until this level reads 1/2 line high on the end of the table. This will allow for slight amount of settling when the table is extended beyond this position or when an extremely heavy load is moved out over the saddle support. The supports should then be firmly locked in this position with the clamp bolts on the inside of the unit.

ALIGNMENTS

The final alignment checks should now be made on the machine to assure that it has been erected and leveled properly and that the ultimate in machining accuracy can be accomplished. The first check which should be made is a sweep of the spindle sleeve to the column ways below and above the headstock casting. This is done with a special sweep bar bolted to the sleeve as shown in figure 14. An indicator is mounted to the sweep bar and a zero setting is established on the front face of the column way below the headstock. When doing this, it is best to indicate over a small ground parallel block to assure a more uniform reading in all positions. After the zero setting has been established at the bottom, the sweep is rotated to a position above the headstock and an identical reading taken on the column way using the same parallel block. This reading should be from 0 to plus .001" on top to indicate that the spindle is tilted up a very slight bit. This alignment has proven to be the best for the overall accuracy of the machine and will allow for a slight sag in the spindle at extended positions.

If this check does not fall within this tolerance, first be sure that the sweep bar is completely rigid as this can have a very great effect on the final reading. If this is all right, then the headstock wiper should be removed and the guiding way checked with a feeler gauge as there may have been some dirt or foreign matter underneath the ways during assembly which will require the removal of the headstock.

The other alignment checks to make are the vertical travel of the headstock as indicated against a square or cylindrical post set on the center of the machine table. This square should be indicated both in a direction parallel to the bed ways and perpendicular to the bed ways to assure that the column is standing completely vertical, (figure 15). The toler-




Figure 15. Indicating Headstock Travel

ance on this reading is .001" in 48" and correction of this reading can be made by adjusting the leveling screws underneath the column end of the bed.

The final alignment check to make is the parallelism of the spindle travel with the bed ways. Before this can be accomplished, it is necessary to run the machine headstock approximately 15 minutes until it warms up to operating temperature. To make this check it is necessary to extend the spindle approximately 18" and clamp an indicator to a magnetic base set on the front edge of the machine table, (figure 16). This indicator should be positioned against the side of the spindle. Next, rotate the spindle and pick up the high point of the spindle runout. Then adjust the headstock up and down slightly to make sure the highest point of the spindle is contacting the indicator button. The headstock should be clamped in this position. The saddle should now be traversed over a length of 12" and the indicator reading taken at extreme limits of this travel. The reading on this measurement should be within .0002" over 12" of travel. This will actually govern the straightness of a boring operation when using the spindle or saddle travel. If this check does not fall within the required tolerance, it will be nec-

essary to loosen the column bolts holding it to the bed and grind a small amount of stock off of one or the other of the two ground shims which locate it against the integral key on the bed.




Figure 16. Checking Spindle Alignment to Bed Ways

Section 2 LUBRICATION

The life and service of a precision machine tool depends greatly upon the care and maintenance it receives. The best way to care for a machine is to see that it is frequently, thoroughly and properly lubricated.

To simplify this problem, all Giddings & Lewis machines are equipped with various automatic oiling systems. These systems require attention only at infrequent intervals though there are some daily hand oiling operations required. Complete information on the proper lubrication of your machine is given below.

A chart listing the lubrication recommendations for your machine is shown in figure 17, and also on a metal plate attached to the machine.

LUBRICATION

ELEMENT	METHOD	Gargoyle LUBRICANT RECOMMENDED
Headstock	Circ. System	Gg. D. T. E. Oil Light
Bed Base	Splash System	Gg. D. T. E. Oil Light
Table Drive Unit	Grease Packed	Gargoyle Grease Sovarex No. 1
	Oil Packed	Gargoyle Cylinder Oil 600W
Table & Saddle Ways	Bijur System	Gargoyle Vactra Oil No. 2
End Support Block	Oil Reservoirs	Gg. D. T. E. Oil Heavy Medium
Coolant Pump	Grease Packed	Gargoyle Grease Sovarex No. 1
Miscellaneous Bearings	Grease Cup	Gargoyle Grease Sovarex No. 1
Electric Motors	Grease Packed	Gargoyle Grease Sovarex No. 1
Table Hand Feed Gear Box	On Model 350 Only	Gargoyle Cylinder Oil 600W
Misc. Oil Cups & Oilers on Saddle	Hand Oiled	Gg. D. T. E. Oil Heavy Medium

The above are Socony-Vacuum products.
They or their equivalent are suggested.

Figure 17. Lubrication Chart

SIGHT FEED OILER FOR
ELEVATING SCREW BEARING

CUP OILER FOR OIL RESERVOIR IN
BEARING BLOCK. LUBRICATES END SUPPORT
WAYS AND BEARING BLOCK BUSHING AND
END SUPPORT NUT

CUP OILERS FOR
BEVEL GEAR DRIVE
TO ELEVATING SCREW

SIGHT FEED OIL GLASS,
SHOW ACTUAL FLOW OF OIL
TO MAIN SPINDLE BEARINGS.

OIL RESERVOIR FOR LUBRICATION OF
ENTIRE TABLE AND SADDLE UNIT
INCLUDING SADDLE FEED UNIT

ALEMITE FITTINGS FOR DRIVE
SHAFT BEARING AND FOR
COUNTERWEIGHT CHAIN
SPROCKET WHEELS

OIL FILLER COVER
FOR HEADSTOCK


HEADSTOCK OIL LEVEL
SIGHT GLASS

HEADSTOCK OIL DRAIN

OIL FILLER COVER
FOR BED

BED OIL DRAIN

BED OIL LEVEL
SIGHT GLASS






Figure 18. Headstock Lubrication

HEADSTOCK

The headstock on the 30 Series table type horizontal boring machines contains its own oil reservoir. The gears and bearings as well as the headstock ways are lubricated from an automatic distribution system within the head leading from a gear driven pump located in a sump at the bottom of the casting. One line from this pump directs oil to the sight feed pocket at the front of the head where it runs down into the front spindle sleeve bearings, (figure 18). The sight feed glass is used to indicate that the pump is working properly. The flow of oil in the glass can be regulated by removing the glass and adjusting the set screw. This flow should be limited to 40 to 60 drops per minute to prevent it from running out the front bearing cover.

Before running the head, it should be filled with oil through a pipe plug hole in the top of the ram guide immediately to the right of the vertical drive shaft, (figure 19). Oil should be poured into the head until it reaches the half way mark on the oil sight gauge near the bottom of the headstock. The head should then be started up and allowed to run while more oil is added until the running level reaches

the gauge line. For draining the headstock when changing oil, a plug is provided in the underside of the casting near the oil pump.




Figure 19. Headstock Lubrication




Figure 20. Bed Lubrication

BED

All of the mechanism in the bed of this machine is oiled through a splash lubrication system. The oil may be poured into the bed through the opening over the feed and rapid traverse clutch, (figure 20). This compartment should be filled until the level reaches the half way mark on the oil sight gauge. The amount and recommended type of lubricant is noted on the lubrication chart.

TABLE AND SADDLE

All the bearings, ways and moving parts of the table and saddle unit are automatically lubricated. A pressure pump submerged in an oil pocket in the saddle is operated by a cam whenever the feed and rapid traverse lever is engaged. The oil is piped to the various bearings and the proper amount of oil supplied to each bearing is controlled by drip type filter fittings. By moving the table to the extreme position away from the operator, the filter cap is exposed so that the pocket can be filled with oil, (figure 21). About three quarts of oil are required to fill the pocket. It should be inspected occasionally and refilled with oil when the oil does not appear above the bottom of the strainer screen.

On the No. 340-T machine, the hand feed shaft bearings for the table hand feed are readily lubricated by running the table back a short distance and oiling through the four small oilers immediately

above the hand feed shaft. The four oilers are located--two outside and two between the saddle ways.

On the No. 350-T machine only, a separate compartment, which holds approximately one quart of oil, is provided for oiling the gears and bearings for hand feeding the table. The table must be run back to expose the pipe plug for filling, (figure 21).




Figure 21. Table and Saddle Lubrication




Figure 22. End Support Lubrication

END SUPPORT

The end support block is lubricated from a small chamber in the top, (figure 22). This chamber should be filled with oil to the top of the oiler. This oil level should be maintained and frequent inspection is advised to make sure of this requirement. The compartment holds approximately one pint of oil. There is another compartment at the base of the end support which holds approximately one-quarter pint and takes care of lubricating two bearings on the shafts. This compartment is filled with oil to the top of oiler. This level should also be frequently inspected so that the compartment is kept constantly filled with oil. Bowen oilers on the bed way wipers should be filled at least once a day. A wick-fed oiler, (figure 23), on top of the end support is used for lubricating the bearing on top of the elevating screw. This oiler should be frequently inspected and filled.




Figure 23. Elevating Screw Bearing Lubrication

GENERAL

In addition to the major units there are a number of small oilers on the hand feed shafts and other isolated moving parts which must be lubricated daily. The motors should be lubricated according to the chart on the machine.

CHANGING OIL

The oil in the headstock reservoir and compartment of the bed of the machine should be removed after the first two or three weeks. These reservoirs should then be filled with flushing oil and the machine operated for 3 to 5 minutes. Disassemble the oil pump by removing the flange screws underneath the headstock next to the drain plug and thoroughly clean any sediment from the headstock reservoir. The flushing oil can then be withdrawn and the reservoirs filled with a supply of fresh, clean oil as previously mentioned. After this first change, it is advisable to repeat this cleaning every four to six months, depending upon the amount of use given the machine. It is very necessary to periodically flush out the machine as described above. The oil in the machine is subject to heat and wear the same as that in an automobile. If the practice of carefully lubricating and periodically cleaning is observed, no lubrication difficulties should ever develop in your Giddings & Lewis Horizontal Boring, Drilling, and Milling Machine.

Section 3

OPERATION

The following instructions should be carefully studied and thoroughly understood before any attempt is made to start the machine. Do not place any tools or any other articles on top of the bed immediately under the headstock because these two units come very close together when the headstock is all the way down.

MOTOR AND CONTROL

There is one motor that drives the spindle, table, headstock, saddle, and end support bearing block. The drive motor is rated at 20 horsepower on the 340-T machine and 25 horsepower on the 350-T machine.

Overload protection is provided for the motor on the machine. The circuits are arranged so that in the event of an overload, all motion of the machine is stopped.

The control of the drive consists of a reversing type across-the-line starter and an electric brake for stopping. It should be noted that inching the motor at frequent intervals will trip the main motor overloads. Therefore, discretion should be used in the number of times the main motor is started and stopped repeatedly.

The pendant control houses a number of push buttons and selector switches, (figure 24). These are used to accomplish the following functions:

1. Stop and start the main drive motor.
2. Change rotative direction of the motor.
3. Jog the motor manually.


All machines have a built-in ammeter mounted in the pendant control. This ammeter enables the operator to determine the amount of power being consumed so he can safely stay within the capacity of the machine. As a protection against overloading, it will be necessary to limit the horsepower consumed to 1 horsepower per revolution of the spindle between the speeds of 10 and 20 rpm on the 340-T machine and 7.5 and 25 rpm on the 350-T machine. This limitation is indicated on the face of the ammeter.

WARNING

Care should be exercised so that continuous feed facing heads, star feed facing heads and other off balance rotating accessories and attachments are not operated at spindle speeds in excess of those called for on attachment noteplate.



Figure 24. Pendant Control Station
(350-T Illustrated)



PENDANT CONTROL

ADJUSTABLE VERNIER

ROTARY SELECTOR AND BACK GEAR LEVERS FOR 45 SPINDLE SPEEDS

SPINDLE FINE HAND FEED

ADJUSTABLE VERNIER

SPINDLE HIGH AND LOW RANGE SELECTOR LEVER

HEADSTOCK CLAMP

TABLE
LEFT ↔ RIGHT

SPINDLE FEED REVERSE LEVER

ROTARY SELECTOR AND BACK GEAR FOR 18 SPINDLE FEEDS

TURNSTILE

DEPTH GAUGE DIAL AND CLAMP

GIDDINGS

VISIBLE OIL LEVEL

MAIN SPINDLE RAM CLAMP

ADJUSTABLE HEADSTOCK LIMIT TRIP

↑ UP
↓ HEADSTOCK
DOWN

ROTARY SELECTOR AND BACK GEAR FOR 18 MILLING FEEDS TO TABLE, SADDLE AND HEADSTOCK

POWER FEED ↔ RAPID TRAVERSE

PUSH BUTTON CONTROL FOR COOLANT PUMP

VISIBLE OIL LEVEL

SADDLE CLAMP

TABLE CLAMP

TABLE HAND FEED

SADDLE LIMIT TRIPS

SADDLE AUXILIARY FEED REDUCTION FOR EXTRA FINE BORING

LEVELING SCREW AND HOLD DOWN BOLT

SPINDLE
START ↔ REVERSE
STOP

SADDLE
LEFT ↔ RIGHT

SADDLE HAND FEED

HEADSTOCK HAND FEED

LEVER FUNCTIONS

FEATURES

DIRECTIONAL CONTROL

Eliminates operator fatigue and saves time - no need to concentrate on which way to move the levers - just move them the way you want the machine unit to go.

CENTRALIZED CONTROL

No climbing around the machine to get at the controls - everything within convenient reach of the operator.

SCALES AND ADJUSTABLE VERNIERS

Accurate measurement to .001" on table and head-stock units. Adjustable vernier eliminates decimal figuring.

MICROMETER HAND ADJUSTMENT

Adjustable dials, graduated to .001" allow accurate setting of all units by hand.

VISIBLE OIL LEVELS

Positive assurance of proper lubrication.

ROTARY DIALS AND SELECTORS

Simply turn the crank to select proper speeds and feeds for all units - quickly and precisely.

Figure 25. Control Functions Chart




Figure 26. Bed Controls

STARTING, STOPPING, REVERSING

When the machine is idle, the start, stop and reverse lever is approximately 10 degrees to the left of vertical. This lever controls the two multiple disc clutches for the main drive. Throwing this lever to the left causes the spindle to rotate right hand, i.e., the direction for drilling, (figure 26).

Throwing it to the right of the neutral position causes the spindle to rotate in the opposite direction.

The stop, start, reverse lever can be used for inching the spindle in either direction but avoid running the spindle when this lever is not in either of its extreme positions. A partially engaged clutch will slip and slipping causes wear.

At the low end of the start, stop, reverse lever a projection is provided and directly below the lever an adjustable safety knob is arranged so that it may be turned in three different positions. When the machine is used for tapping, which requires that the spindle must be quickly reversed, the safety knob is turned to the middle or lowest position to allow the projection on the end of the lever to pass from the forward to the reverse position without any interference. For safety purposes, when the machine is normally used with the spindle rotating to the right,

such as using right hand milling cutters, it is advisable that the knob be turned to the left. In the event the machine must be quickly stopped, the lever can then be jerked to the neutral position without going into reverse.

MILLING FEED AND RAPID TRAVERSE

A complete feed mechanism for milling is located in the bed of the machine at the column end. Incorporated in this feed unit is a rapid traverse to all units. This feed and rapid traverse unit controls the movement of the headstock and end support block up and down, the table forward and backward on the saddle and the saddle movement to the left and right along the bed of the machine. The feed and rapid traverse is selected through the feed and rapid traverse lever. When this lever is pushed to the left, the feed train of the gears is engaged. When it is pushed to the right, the rapid traverse is engaged. The engaging of this lever into the feed or rapid traverse does not of itself apply the feed or rapid traverse to any of the units. This is controlled independently for each unit. The feed and rapid traverse are always in the same direction.

The eighteen milling feeds are obtainable through two levers. One of them is a rotary lever geared to a dial having all the milling feeds in inches per

minute. The other is a back gear lever to which is attached a slide having an opening which exposes to view the actually engaged feed corresponding to the position of the levers. A milling feed note plate shows all the feeds in the order that they are obtained by turning the rotary lever.

There is no feed reverse in this unit as the direction of the feed and rapid traverse is taken care of independently for each of the units. With this directional control of the feed and rapid traverse on each unit, it is not necessary to bring any unit back by hand after it has gone on to the safety limit trips. All that is necessary is to pull the directional engagement lever in the opposite position.

FINE SADDLE FEEDS FOR BORING

When extremely fine feeds are needed for boring large holes, using the slower spindle speeds, the saddle reduction lever is shifted to the right, applying a forty to one reduction to the regular saddle feeds. A spring loaded clutch permits the rapid shifting of the lever without waiting for the clutch teeth to engage. A note plate is attached near the lever showing the fine feeds available. As the saddle rapid traverse is also reduced forty to one, the lever should be shifted to the left to obtain 120" per minute rapid traverse to the saddle.

IMPORTANT

Machine must be running, feed lever must be engaged for either direction and feed and rapid traverse lever must be engaged to the left before shifting saddle reduction lever.

HEAD TRAVERSE

The application of the feed or rapid traverse in either direction to any of the units is controlled independently. The headstock power traverse lever is for moving the head up and down on the column. This lever moves in a vertical plane. When lever is moved up, the head travels up for either feed or rapid traverse. When the lever is moved down, the head travels down. This lever can be engaged into either position without slowing down the feed or speed or otherwise interfering with the progress of the cut being taken. Do not engage this lever into either position with the rapid traverse running. Headstock hand traverse shaft is for the hand movement of the headstock up and down on the column. This, of course, will be used only for final adjustment of the head for an accurate boring operation. This is operated by a safety hand crank referred to later in these instructions.

SADDLE TRAVERSE

A saddle power traverse lever applies feed or rapid traverse in either direction for the movement

of the saddle back and forth on the bed ways. This lever moves in a horizontal plane and the same directional control of this unit is obtained as mentioned for the headstock movement on the column. This unit will move in the direction the lever is pushed for either feed or rapid traverse. This lever can be engaged into either position without slowing down the feeds or speeds or otherwise interfering with the progress of the cut being taken. Do not engage this lever into either position with the rapid traverse running. The saddle hand traverse shaft is for moving this unit back and forth by hand. This saddle hand feed will be used only for the final adjustment of the table along the bed for some accurate position. It, too, is operated by a safety hand crank handle referred to later in these instructions.

SPEED CHANGING

All the speed changes on these machines are located in the head and are obtainable through three levers, (figure 27). Of these three levers, one is the spindle high and standard or low range selector. This lever has three positive shifts; high range to the right, neutral in a vertical position and standard range to the left. After selecting the desired speed range, the exact speed can be obtained through one of two rotary back gear levers. A spindle speed plate shows all the spindle speeds obtainable. The rotation of the rotary levers obtains the speeds in the order in which they are shown on the speed plate.

If it is desired to operate the spindle feed without rotating the spindle, the high and standard range lever can be shifted to the neutral position.

CAUTION

While these speed change levers shift very easily and the gears controlled by them will mesh at lower speeds, it is advisable not to shift them under power. It is suggested that the start, stop and reverse lever be engaged and pulled out again, and while the machine is still coasting, the speed change levers can be shifted to the desired positions.

POWER FEED TO SPINDLE

The entire feed mechanism for the spindle is contained in the head and all spindle feed changes are obtainable through two levers. One of these is a rotary lever geared to a dial having all the spindle feeds. The other is a back gear lever to which is attached a slide having openings which expose to view the actually engaged high and standard range spindle feeds, corresponding to the positions of the high and standard range lever. A spindle feed plate shows all the feeds in the order in which they are obtained by operating the rotary lever. Feed is




Figure 27. Headstock Controls

applied to the spindle by pulling the quick motion turnstile handles toward the operator.

CAUTION

Do not apply power feed to spindle when in extreme in or out position. Spindle should be started from extreme position by means of turnstile handles before applying power feed.

SPINDLE FEED REVERSE

The spindle feed reverse lever controls the direction of the spindle feed and when it is straight up and down, it is in the neutral position. When pushed to the right, the power feed moves the spindle out when it is rotating right-hand as for drilling.

When pushed to the left, the power feed moves the spindle in. When the spindle is reversed as in the backing out of a tap, the direction of feed is also reversed.

HAND FEED TO SPINDLE

If it is desired to feed the spindle feed hand wheel, it is necessary that the spindle feed reverse lever be in the neutral position. Spindle hand wheel rotates so that the top of it comes toward the operator and moves the spindle out, irrespective of spindle rotation.

For hand feed as well as for power feed to the spindle, the quick motion turnstile handles should be pulled toward the operator.

SPINDLE CLAMP

The spindle can be clamped at any position of its travel. A lever clamps the spindle by pulling it toward the operator.

CAUTION

Do not apply feeds to spindle while clamped.

HEADSTOCK CLAMP

Before attempting to move any unit by hand or power, care should be taken that the clamp for that unit has been released. The headstock clamp lever, by means of a cam and multiplying levers, securely clamps the head to the column on the back inside edge of the column ways. The head is clamped to the column by pulling lever toward the operator.

DEPTH GAUGE FOR SPINDLE FEEDS

In connection with the spindle feed unit, an arrangement is provided so that the feed to the spindle may be automatically disengaged at any predetermined point within six inches of travel. Any tools attached to the spindle should first be set to the starting position of the feed. This is done by means




Figure 28. Table and Saddle Controls

of the turnstile handles. The adjustable dial which is graduated in sixteenths of an inch up to six inches, is turned so that the distance the spindle is to be fed lines up with the zero stamped on the turnstile hand hub. The dial is then clamped with the clamp lever and the feed is engaged by pulling turnstile handles toward the operator. When the dial is clamped, the spindle feed will always be automatically disengaged when the zero on the hub lines up with the zero on the adjustable dial.

TABLE TRAVERSE

Table power traverse lever, (figure 28), applies feed or rapid traverse in either direction to the movement of the table back and forth on the saddle. This lever moves in a horizontal plane and the same directional control of this unit is obtained as mentioned for the above movement of the headstock up and down on the column. The unit will move in the direction the lever is moved for either feed or rapid traverse. This lever can be engaged into either position without slowing down the speed or feed or otherwise interfering with the progress of the cut

being taken. Do not engage this lever into either position with the rapid traverse running. The table hand traverse shaft is for moving the table back and forth on the saddle by hand. The table hand feed will be used only for final adjustment of the table on the saddle for some accurate position. It is also operated by the safety hand crank referred to later in these instructions.

TABLE CLAMP

The table is clamped to the saddle by pulling lever upward into a horizontal position. An interlock is provided in connection with this clamp so that the table feeds cannot be operated when the table is clamped.

SADDLE CLAMP

By actuating two toggles the saddle clamp lever securely clamps the saddle to the ways of the bed of the machine on both the front and rear ways. When the saddle clamp lever is at right angles to the bed, it is in the unclamped position. The clamp is applied by pulling the lever toward the operator.




Figure 29. End Support Controls

END SUPPORT TRAVERSE

The end support is moved back and forth on the bed of the machine by the end support traverse, (figure 29). This is operated by the safety crank handle referred to later in these instructions.

END SUPPORT REMOVAL

When long work requires the removal of the end support, this unit can be taken off the machine. To facilitate removal and replacement of this unit, the following instructions should be closely observed:

The head and end support block should be moved up until the edge of the way scraper lines up with the zero mark on the outside of the left way of the column. This mark is approximately one-third the distance from the top of the column. In this position, the end support block should be clamped, using the clamp lever. The Allen socket head set screws for adjusting the flat gib on the front of the bed should be loosened about two turns. The flat clamp plates at the bottom are provided with slotted holes so that they may be pulled back to clear the bed by merely loosening the cap screws and the clamp levers but without removing them entirely from the end support column. The bevel gear bracket at the bottom should then be removed from the end support column and attached to the pin on the bracket at the end of the bed. The complete end support can then be lifted from the bed and the machine is ready for operation.

To replace the end support, the head should be brought up to the zero mark again and the above sequence of operations reversed.

END SUPPORT BLOCK CLAMP

The end support block clamp is operated by pulling lever toward the operator.

END SUPPORT CLAMPS

There are two end support clamp levers, one on the front way and one on the rear way of the machine. The end support should be clamped to the bed of the machine whenever it is in use.

SAFETY TRIPS

The movements by power feed or rapid traverse of the headstock on the column, the saddle on the bed, and the table on the saddle are protected by means of safety trips to insure that the respective feed or rapid traverse is thrown out of engagement when the limit of travel is reached. Adjustable trip collars attached to a vertical trip rod are provided for the headstock movement on the column in order that the feed or rapid traverse can be disengaged at any point in the travel either up or down. Similar trip dogs for the table movement provide settings to disengage the feed or rapid traverse at any point within the range of the table movement. These dogs are attached to a flat table gib on the left side of the table. Adjustable disengagement features are intended as a convenience in production milling.

HAND FEED DIALS AND SAFETY CRANK

All the hand feed dials are graduated in thousandths of an inch. These graduated dials ride free on their respective shafts and can be clamped in any position by the knurled screw on the end of the shaft. All hand adjustments of the machine are made by a safety crank handle. To move any of the units with this safety crank handle, it is necessary to keep it pressed into the jaw clutch against a spring load. With this arrangement, as soon as the hand is removed from the crank handle, it is disengaged and swings free on the shaft. This prevents possible injury to the operator and damage to the machine if through oversight the crank handle should not be removed before applying feed or rapid traverse. Nevertheless, it is advisable to remove the crank handle when not in use.

Section 4

OPTIONAL ARRANGEMENTS

THREAD LEAD DEVICE

With a built-in thread lead device, any thread leads can be applied to the spindle through a change gear quadrant compartment and an accurately cut feed screw, (figure 30). A separate chart, attached to the compartment cover, is provided showing the proper gearing on the quadrant for each thread lead. The direction of the spindle movement should be determined and set by means of the screw feed reverse lever. This setting should not be changed during the thread cutting operation. The thread cutting feed is applied by pushing in the spindle feed selector lever and shifting it to the left. This engages half nuts to the screw which are always running when the lever is in engagement and the spindle is running. After a cut is taken in a thread, the tool is first backed out of the thread, then the lever is pulled out and shifted to the left and the spindle can be quickly backed out of the cut by means of turnstile handles. To facilitate picking up the thread for the next cut, a dial is provided having sixteen divisions, the alternate divisions being numbered one to eight. This dial rotates continuously when the half nuts are disengaged and the feed screw running, and stops as soon as the half nuts are engaged by means of the spindle feed selector lever.

For even threads, or those divisible by 2, such as 2, 4, 6, 8, engagement can be made on any of the sixteen divisions, each division representing $1/2$ " of the spindle travel. For odd threads, such as 3, 5, 7, engagement can be made on alternate divisions representing 1" of spindle travel. For threads such as $2-1/2$ and $11-1/2$ engagement can only be made on divisions quartering the dial, representing 2" of spindle travel. Safety trips are provided so that the half nuts are thrown out of engagement when the limit of travel is reached in either direction.

BUILT-IN ROTATING TABLE

On machines having a built-in rotating table, (figure 31), the table feed lever controls the direction of the cross travel of the rotating table on the saddle. To apply power cross feed, first shift feed and rapid traverse lever to the left and then table feed lever in the desired direction of feed. Rapid traverse is applied by shifting feed and rapid traverse lever to the right. When table feed lever is in a neutral position, hand cross feed may be applied by using the safety hand crank.




Figure 30. Precision Thread Lead Attachment




Figure 31. Built-in Rotary Table Controls

The table may be clamped against cross movement by pulling table clamp lever upward.

To apply power rotary feed to the table, first shift feed and rapid traverse lever to the left and then rotary table directional lever in the direction the table is to be turned. Rapid traverse rotary movement is applied by shifting feed and rapid traverse lever to the right.

When rotary table directional lever is in a neutral position, rotary hand feed may be applied by using the safety hand crank.

The table may be clamped against rotary movement by using the safety hand crank.

WARNING

Do not apply power rotary movement while table is clamped.

The table is graduated in $1/2^\circ$ for the complete 360° . Micrometer dial stops, however, are provided for accurate adjustment of the table to four positions 90° apart. The micrometer dial is located immediately to the right of the clamp. A small lever with a spring is used to throw the micrometer stop into the path of the four index stops. The table is then rotated by hand until the pointer on the micrometer dial reads zero and then the table may be clamped.

NOTE

A special safety arrangement is incorporated in dial indicator housing to safeguard indicator against damage.

For example, if table is rotated too far against dial indicator, indicator arm is cammed out of position until it clears indicator stop. Indicator then returns to its normal position against a cushioned stop. Table should then be reset by means of safety hand crank. Turn table to the left far enough to pick up indicator arm and then reverse movement to bring indicator to zero reading. Lock table clamp.

The entire table and saddle unit is automatically lubricated and instruction plates giving full instructions for filling oil reservoirs are attached.

AUTOMATIC POSITIONING DEVICE

The positioning device consists essentially of a master switch for the table and a second one for the headstock, (figure 32), a motor driven reduction gear box for each unit, and a solenoid declutching device for the directional clutch of each unit. In principle, the table and headstock units are essentially alike.

Positioning of the table and headstock is individually controlled, and it is, therefore, possible to operate the units separately or simultaneously. A selector switch is provided in the pendant station




Figure 32. Automatic Positioning Device

to set up the machine for automatic positioning or for operation of the machine without the positioning device being used. See figure 32.

The measuring mediums are standard precision end measuring rods and an inside micrometer such as used on our standard measuring devices, or special job rods bored for stop pins for repetitive production.

The procedure for setting up a positioning device equipped boring machine to bore a number of holes in a workpiece is as follows:

With a workpiece fastened in position on the machine table, the machine units are moved to locate the spindle at some suitable starting point on the workpiece, such as the point from which the holes to

be bored are dimensioned. Next, place a micrometer, which should be set to read zero, in the rod trough. Loosen the lock nut of the adjustable stop block, (figure 32) and move along the trough toward the master switch box so that it pushes the micrometer into the master switch actuator until the dial indicator reads zero. Lock the stop block in this position. With the selector switch set for automatic positioning, the machine should now reposition to this starting point when desired. To move to the next desired position which, for example, might be 6.300" away, rapid traverse the machine unit to move the stop block and the micrometer away from the master switch. If standard end measures and micrometer heads are to be used, place a 6.000" long end measure in the rod trough. Set the micrometer to read .300" and place it back into the rod trough. With the machine set for its highest feed rate, engage the feed

to move the machine unit towards the master switch box. The machine unit will automatically stop at the desired new position.

Briefly, an explanation of a positioning cycle is this: After the desired end measures and micrometer are in the trough, the operator engages the feed which causes the machine unit to move toward the master switch unit, carrying with it the stop block, the measuring rod, and the micrometer. The micrometer contacts the operating plunger of the master switch unit, which operates a micro switch that energizes a solenoid to disengage the directional control clutch. The machine unit then goes past the point at which the operating plunger closes the master switch. The closing of the master switch starts the motor driven, fine feed unit and energizes the magnetic clutch, which then connects the fine feed unit to the feed screw of the machine unit. The machine unit moves back to the point where the master switch opens, de-energizing the magnetic clutch which disconnects the fine feed unit from the feed screw. The machine unit will come to an instantaneous stop, due to the low feed rate of the fine feed unit. The precision dial indicator in the master switch box will indicate that the correct position has been attained.

For traversing a long distance, it is sometimes desirable to move most of the way in rapid traverse, shifting to feed shortly before contacting the master switch. The machine can be set up to operate using rapid traverse entirely, but experience has shown this to be a savings of time only on certain jobs. Due to inherent variations in the amount of coast, after disengaging the directional control clutches, the positioning device must be set up so that the distance which it moves the machine back in fine feed is always more than the greatest variation in

the amount of coast. Naturally the variations in coast will be greater when using rapid traverse than when using a high feed rate. When using a high feed rate, a positioning device can be adjusted for a much shorter length of travel in fine feed, resulting in considerable savings of time. When it is desired to operate on rapid traverse only, the positioning device must be adjusted for the greater over-travel or coast.

POWER DRAW BOLT

This arrangement is operated by a small torque motor in the rear end of the ram guide and is controlled by a switch from the pendant station, (figure 33). The procedure for assembling an arbor or boring bar is as follows:

First, make sure shank of the arbor and the taper in the spindle are clean. Next, position the arbor in the spindle, lining it up on the spindle nose keys. There is approximately $3/32$ " engagement by the spindle nose keys to prevent the tool from turning in the operator's hand. Turn switch to the in position and arbor will be drawn into the spindle.

NOTE

The spindle drive is interlocked to prevent the spindle from being driven by the draw bolt motor.

Removal of the arbor is accomplished by turning the out switch. Positive ejection will leave the arbor partially engaged on the spindle nose keys. Then remove the arbor.

An added feature is the removable and spring-loaded hand crank, for operating the draw bolt in case of power failure.




Figure 33. Power Draw Bolt

Section 5

ADJUSTMENTS

The number of adjustments on the different units of this machine has purposely been kept to a minimum. Whenever adjustments are necessary during the life of the machine, every effort has been made to allow them to be made easily and quickly.

DRIVING CLUTCHES

There are two multiple-disc friction clutches in the main drive that are controlled by the start, stop and reverse lever (figure 34). They are accessible through the opening on top of the bed to the right of the column. The clutches should be adjusted to trip evenly when the start, stop and reverse lever is in either of its extreme positions. The clutches should not drag when the lever is in its neutral position. The rapid traverse clutch is of the same design and is accessible through the opening, (figure 34), on top of the bed behind the feed and rapid traverse lever.

The adjustment of the multiple disc friction clutches requires no wrench, screw driver or any other tool. A sectional drawing with adjustment instructions for the clutches are shown on a plate attached to each of the openings.

SPINDLE BEARINGS

The main spindle sleeve is mounted in a precision Timken bearing supporting the rear end and one or two precision Timken bearings supporting the front

end. The bearings of the main spindle sleeve are properly adjusted before the machine is shipped and no readjustment should be required for a long period of time.

SPINDLE SLEEVE BEARING ADJUSTMENT

To adjust the spindle sleeve bearings, the following procedure should be followed:

1. Remove ram guide end cover and loosen nuts that secure Timken bearings on rear end of spindle.
2. Remove vernier from headstock.
3. Loosen cone point set screw at lower end of scale shaft and remove scale shaft from machine.
4. Remove jam nut on spindle hand feed wheel shaft. Remove hand feed wheel. Adjust dial lock screw to neutral position and remove dial from shaft. Now, turn lock screw in to force out lock pin in shaft sufficiently to allow it to be pulled out of the dial sleeve with the fingers. Remove dial sleeve.
5. Remove the four socket head screws from cast iron bearing retainer plate and remove plate.
6. Spindle hand feed shaft may now be withdrawn from the headstock.




Figure 34. Clutch Locations in Bed

7. Remove all socket head screws from the spindle feed unit. Withdraw taper dowel pins and remove unit from headstock.

8. Remove the dog point set screw from the bearing adjusting nut located on the rear end of the spindle sleeve.

9. Turn bearing adjustment nut clockwise to tighten bearings. Care should be taken to make sure that the bearings are not set up too tightly. To determine setting of bearings, the following test in step No. 10 should be made.

10. Attach a piece of round bar stock 40" long directly to the machine spindle. Insert bar through draw key slot or front slot of spindle. The center of the bar should be in line with the center of spindle and locked in place with wooden wedge. File a notch in bar exactly 19" from center. Hang a weight on bar at this notch. Spindle sleeve bearings should be adjusted just tight enough so that the weight just barely turns the spindle.

To determine the amount of weight to hang on bar, consult the following table:

For No. 340-T Machine - 4 to 5 lbs. at 19" radius

For No. 350-T Machine - 5 to 6 lbs. at 19" radius

After bearings have been properly adjusted, re-drill sleeve for dog point screw. Lock bearing adjusting nut.

After spindle sleeve bearings have been adjusted, the bearings on rear end of spindle in spindle ram should be preloaded. Turn nuts just tight enough to support the following added weight on bar across face of spindle sleeve. For No. 340-T Machine the added weight should be - 1 lb. For No. 350-T Machine the added weight should be - 1-1/2 lbs.

11. Reassemble machine in the reverse order in which it was taken apart.




Figure 35. Headstock Clamp

HEAD CLAMP

The adjustment of this clamp is rather sensitive and should be made accordingly. Loosen the Allen socket head screws in bracket, (figure 35), about two turns. Insert a pin into one of the holes of the nut behind the bracket. To tighten the clamp, turn the adjusting sleeve slightly to the left and tighten the Allen socket head screw. This adjustment should be continued until the head is securely clamped to the column by pulling the head clamp lever toward the operator but should not be so tight that the clamp is not free in the released position.

NOTE

An adjusting screw will be found at the top of the vertical clamp lever behind the headstock to take up all lost motion.

SPINDLE FEED CLUTCH

There is an adjustment provided for the internal gear segments of the spindle feed clutch that is controlled by moving the quick motion turnstile handles in and out, (figure 36). Two lock nuts placed over two Allen socket head screws are provided on the hub disc of the turnstile handles. To adjust this unit, the two lock nuts must be loosened and the Allen socket screws tightened so that when the internal gear clutch of the spindle feed mechanism is engaged, the expanding internal gear segments fit snugly into the internal gear on the worm wheel.




Figure 36. Spindle Feed Trip Adjustment

NOTE

The above two adjustments are extremely sensitive and independent. They are provided mainly for G&L assembling convenience and it is suggested that they be left strictly alone unless adjustment is absolutely necessary. This adjustment most likely will not have to be made during the life of the machine, except in such cases where parts are broken by accident and have to be replaced.

SPINDLE TRIP FEED

The two Allen socket head screws in the graduated dial ring are for adjusting the dog that trips the feed when the automatic depth gauge is used, (figure 37). The two set screws have cone points which fit into vee slots in the dog that are a little further apart than the set screws. Adjust the dog to take care of any wear that might be caused by the dog riding over the contact point on the inside of one of the quick motion turnstile handles. To move this dog in toward the center, the inside screw nearest the hub should be loosened only very little and the outside one tightened. This adjustment is very sensitive and should be made accordingly. The adjustment is provided for G&L assembling convenience and it is possible that further adjustment will not be required during the life of the machine. Unless adjustment becomes absolutely necessary, it is suggested that it not be tampered with.




Figure 37. Spindle Feed Clutch Adjustment

SPINDLE TRAVEL

The spindle is arranged so that when the spindle reaches the limits of travel either way, the movement of the spindle will stop. A ram attached to the spindle, has rack teeth which mesh with a gear driven by the feed mechanism. When the limits of travel are reached, the gear runs off the rack. A loose or floating tooth arrangement, however, is provided at each end of the rack, making it unnecessary to push the rack back into engagement.

CAUTION

Do not apply a reverse power feed to the spindle when the spindle ram is in extreme in or out position. Use the turnstile to make sure rack teeth are properly engaged before using power feed.

SADDLE CLAMPS

The only other adjustment that may be required on the machine from time to time is for the saddle clamps. The saddle clamp lever clamps the saddle on the front way and also on the rear way through toggle joints. Referring to figure 38, the saddle clamp lever, through the toggle joints, draws the clamp screws up against the flat gib that runs along the way of the bed the full length of the saddle. This flat gib is provided with eight small holes around the hole through which the clamp screw works. The clamp screws are provided with three screw holes so positioned that only one of them at any time is in line with one of the holes. By turning the clamp screws clockwise, the clamp is tightened. With eight holes and three holes, twenty-four fixed positions are possible with each revolution of the clamp screws.

When adjustment is required, the Allen socket head set screw, which is in one of the holes, should be removed and the clamp screws turned far enough to securely clamp the saddle when the saddle clamp lever is at 45° to the bed. The Allen socket head screw can be placed in one of the holes that line up with the holes in the clamp strip.

TABLE CLAMP ADJUSTMENT

The table clamp lever clamps the table to the saddle by means of a toggle operated wedge block. When in the clamped position, the wedge block is forced against the tapered edge of the front table clamp plate that runs the full length on the underside of the table. The adjustment of the table clamp consists of the adjustment of this wedge block to compensate for wear. On the #340-T machine this adjustment is provided by means of a 5/8" set screw located on the front side of the saddle midway between the bed ways. On the #350-T machine the adjustment is provided by means of a 1" set screw located on the front underside of the saddle midway between




Figure 38. Saddle Clamp Adjustment

the bed ways. In each case the set screw is locked in place with a hex jam nut. To adjust the clamp it is necessary to first loosen the hex jam nut on the set screw and then turn the set screw clockwise until effective clamping action is obtained. After the adjustment is made the set screw should be locked firmly in place by tightening the hex jam nut.

END SUPPORT BLOCK

Due to the uneven wear on the headstock and end support elevating nuts, it is occasionally necessary to adjust the vertical position of the block to maintain proper alignment of the end support bearing or bushing with the main spindle. For this purpose, the end

of the screw is supported in an adjustable sleeve at the top of the end support column, (figure 39). The block may be raised or lowered by means of the adjusting nuts at each end of this sleeve until proper alignment is obtained.

Final precision alignment of the block with the headstock can be made by adjusting the two set screws located on the underside of the block, (figure 40).




Figure 39. End Support Bearing Block Adjustment




Figure 40. End Support Bearing Block Adjustment

Section 6
REPAIR PARTS


INSTRUCTIONS FOR ORDERING REPAIR PARTS

Your repair parts orders will receive the best service if, when ordering, the following information is clearly stated:


1. The quantity of each part required
2. The part name and the part number
3. The serial number of the machine. The serial number is stamped on a name plate which is found on the lower left hand corner of the spindle feed case. Orders cannot be accepted without this serial number.



**ANTI-FRICTION
END SUPPORT**



**TABLE DRIVE
UNIT**



**340-T BASE SIZE MACHINE
WITH OPTIONAL TABLE CROSS SLOTS**

PICK-OFF GEARS





Figure 41. Location of Assembled Units


LOCATION OF ASSEMBLED UNITS

PICK-OFF GEARS


SPINDLE FEED UNIT
(REAR VIEW)




HEADSTOCK



RAM GUIDE



MOTOR DRIVE UNIT
AND SPINDLE REVERSING CLUTCH




MILLING FEED AND
TRANSMISSION UNIT


SIZE MACHINE
ABLE CROSS SLOTS

of Assembled Units


Part Number	Part Name	Part Number	Part Name
5405-8	Cover (340)	35759	Shifter Shaft (340)
5412-2	Cover	35760	Shifter Shaft (350)
5421-1	Shifter Lever	35761	Clutch Housing
5600-2	Feed Case	35762	Clutch Shaft
5601-3	Transmission Case	35778	Shifter Shoe
5684	Stud	35779	Shifter Shaft
5728-2	Shifter Lever	35780	Shifter Lever
5729-1	Shoulder Screw	35781	Shoulder Screw
5769	Coupling	35782	Shifter Shaft
7180-1	Feed Clutch Housing (340)	35783	Cover
7181-1	Feed Clutch Housing	19-668	Drilled Hex. Hd. Cap Screw
7182	Shaft (340)	19-832	Washer
7183	Shaft (350)	19-833	Washer
7184	Bracket	19-1467	Twin Disc Clutch
7215-1	Link	19-1668	Note Plate
10761-6	Cover (350)	19-2067	Ball
13490-1	Lever	19-2119	Copper Disc
13493-2	Lever	19-2701	Straight Pin
35751	Pin	19-2704	Straight Pin
35752	Shaft	19-3890	Taper Pin
35753	Shifter Rod	19-8064	Spring
35754	Pin	19-8518	Taper Pin
35757	Shifter Fork	19-9643-2	Note Plate




ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS



SECTION A-A




SECTION B-B



DWG. #A-150-30-1
Manual Spindle Reversing
G & L and Hypro Division


25

Part Number	Part Name
4475	Clutch Ring
4802	Dial Clamp
4825-1	Dial Clamp Screw
5430-3	Idler Gear
5431-2	Gear
5432-2	Gear
5433-1	Shaft
5434	Ball Shifter
5435-2	Shifter Lever
5436	Shifter Lever Cap
5437-1	Idler Shaft
5683-2	Shifter Arm
5828	Dial Clamp Pin
8797	Micro Dial
13481	Shifter Lever Cap
13482-1	Shifter Lever
13483	Ball Shifter
14216	Bushing
14258	Clutch
35809	Bracket
35858	Transmission Control Box
35859	Scale Strip Base
35859-1	Scale Strip Base
19-2704	Straight Pin
19-2711	Straight Pin
19-7664-1	Ball Handle
19-7919	Spring
19-8959	Bushing



SECTION B-B

ALWAYS GIVE MACHINE **SERIAL NUMBER** WHEN ORDERING PARTS



SECTION C-C

- 5683-2
- 13483
#19-7919 SPRING (1)
#3X1 1/2 TAPER PIN (1)
- 13481 (FIT AT ASSEM.)
1/2-20X 1/2 SOC. HD. CAP. SCR. (4)
- 13482-1
#19-2711 1/2 X 1/2 STR. PIN (1)
#19-7664-1 BALL HANDLE (1)

- 340-T-350-T SCALE & VERNIER 35859 (SHOWN)
- 340-T-350-T MEASURING DEVICE 35859-1
- 340-T-350-T POSITIONING DEVICE 35809


- 35858
#19-2704 1/2 X 1 PIN (2)
1/2-13X 3/4 SOC. HD. CAP. SCR. (3)
1/2-13X 1 SOC. HD. CAP. SCR. (3)
1/2-16X 1/2 FULL DOG PT. SET SCR. (2)
1/2-16X 1/2 FLT. PT. SET SCR. (2)
1/2 DIA. WELCH PLUG (2)

- 5434
#3X1 1/2 TAPER PIN (1)

- 5436 (FIT AT ASSEM.)
1/2-20X 1/2 SOC. HD. CAP. SCR. (4)

- 5435-2
#19-7664-1 BALL HANDLE (1)

- 5433-1 (2)
#207-M M.R.C. BALL BRG. (2)
#207-MF M.R.C. BALL BRG. (2)
#19-7919 SPRING (2)
#N-03 LOCKNUT (2)
#W-03 LOCKWASHER (2)




SECTION A-A

- 14258 (2)
1/2-20X 1/2 FLT. PT. SET SCR. (2)
1/2-20X 1/2 CONE PT. SET SCR. (2)

- 5430-3 (2)


- 19-8959 (2)

- 5437-1
1/2-18X 1/2 DOG PT. SET SCR. (1)



36

Part Number	Part Name
12492-11	Bed
35650	Motor Shim
35694	Clutch Driver - 49T
35699	Bevel Gear - 30T
35701	Bevel Gear Shaft
35730-1	Drive Housing
35761	Clutch Housing
35762	Clutch Shaft
35778	Shifter Shoe
35779	Shifter Shaft
35780	Shifter Lever
35781	Shoulder Screw
35782	Shifter Shaft
35783	Cover
35786	Guard (Motor Drive)
35787	Oil Seal Retainer
35788	Spacer
35789	Spacer
19-827	Washer
19-832	Washer
19-1467	Clutch
19-1529	Lovejoy Coupling
19-2067	Steel Ball
19-2330	Round End Key
19-3890	Tapped Taper Pin
19-8064	Spring
19-8509	Threaded Taper Pin
19-9518	Threaded Taper Pin



ALWAYS GIVE MACHINE **SERIAL NUMBER** WHEN ORDERING PARTS

- 35761
• 8000-393 TRUARC SNAP RING (2)
19-2067 STEEL BALL (1)
19-9064 SPRING (1)
1/4-13 X 1 1/2 LB. SOC. HD. FLAT PT. SET SCR. (1)
1/4-13 X 1 1/2 LB. SOC. HD. FLAT PT. SET SCR. (1)
1/8-16 HEX. JAM NUT (2)
19-8509 • 7 X 2 1/2 LB. THREADED TAPER PIN (2)
1/4-13 X 1 1/2 LB. SOC. HD. CAP SCR. (8)

- 35730-1
19-9518 • 9 X 2 1/2 LB. THREADED TAPER PIN (1)
1/4-10 X 1 1/2 LB. SOC. HD. CAP SCR. (15)

- 35786
• 10-24 X 1/2 LB. BUTTON HD. SCR. (7)

19-1529 COUPLING

35788
FIT AT ASSY.

FIT AT ASSY.

35789

FIT AT ASSY.

- 35787
275128 PERFECT OIL SEAL (1)
1/4-20 X 1 1/2 LB. SOC. HD. CAP SCR. (4)

- 35701
19-2350 KEY (1)
M-11 LOCKNUT (1)
W-11 LOCKWASHER (1)
20211 HD BEARING (2)

NOTE:
SEE SHEET 2 FOR
MOTOR CHANGES

340-T 20 HP FRAME 286U

60 CYCLE

- 19-827 1/2 WASHER (4)
1/4-13 X 1 1/2 LB. HEX. HD. CAP SCR. (4)

390-T 25 HP FRAME 324U


- 35650 (4)
1/4-16 X 1 1/2 LB. SOC. HD. CAP SCR. (8)

35650


DWG. #A-150-32-1
Motor Drive and Reversing Clutch
with Foot Mounted Motor - Sheet #1
G & L and Hypro Division

Part Number	Part Name	Part Number	Part Name
7180-1	Feed Clutch Housing (340)	35767	Spacer
7181-1	Feed Clutch Housing (350)	35769-1	Bevel Gear - 26T
7182	Shaft (340)	35770-1	Bevel Gear - 25T (350)
7183	Shaft (350)	35771	Spur Gear - 19T
7197-3	Gear - 19T	35774	Bevel Gear - 28T (340)
10654	Spacer	35775	Bevel Gear - 28T (350)
12492-11	Bed	35777	Coupling
35690	Bevel Gear - 27T (350)	35786	Guard (Motor Drive)
35691	Gear - 33T	35787	Oil Seal Retainer
35692	Spacer	35788	Spacer
35693	Clutch Driver - 49T	35789	Spacer
35694	Clutch Driver - 49T	35842	Shaft (340)
35696	Spacer	35843	Shaft (350)
35697	Bevel Gear - 27T (350)	35844	Cover
35699	Bevel Gear - 30T (340)	35845	Spacer
35701	Bevel Gear Shaft - 25T (340)	35846	Brake Guard
35730-1	Drive Housing	35847	Brake Cover
35746-1	Shaft	19-693	Drilled Hex. Hd. Cap Screw
35750	Bearing Retainer	19-871	Washer
35761	Clutch Housing	19-1466	Electric Brake
35762	Clutch Shaft	19-1467	Twin Disc Clutch
35765	Spacer	19-1529	Lovejoy Coupling
35766	Spacer	19-2501	Round End Key
		19-2547	Round End Key

MOTOR HP	CYCLE	LOAD P.M.	FRAME SIZE	SHAFT DIA.	COUPLING	MOTOR BRACKET	MOTOR SHIM
20	50	1750	286 U	7 1/2	19-1529 C-99	35730-1	35650
	50	1460	324 U	8 1/2	19-1528 C-99	35730-1	
	42	1200	365	9 1/2		35730	35851
	25	1460	404 S	10 1/2		35730	35702-1
25	60		324 U	8 1/2	19-1528 C-99	35730-1	35702
	50		326 U	8 1/2	19-1528 C-99	35730-1	
	42		404 S	10 1/2		35730	
	25		405 S	10 1/2		35730	
30	60		404 S	10 1/2		35730	
	50		405 S	10 1/2		35730	
	42		405 S	10 1/2		35730	
	25		405 S	10 1/2		35730	
40	60		405 S	10 1/2		35730	
	50		444 S	11 1/2		35730	
	42		444 S	11 1/2		35730	
	25		444 S	11 1/2		35730	



ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS



FRAME SIZE	D	SHAFT DIA.	COUPLING	MOTOR	MOTOR
				BRACKET	SHIM
286 U	7	1 1/2	19-1529	35730-1	35650
324 U	8	1 1/2	19-1528	35730-1	
365	9	1 1/2		35730	3582
404 S	10	1 1/2		35730	35702-1
324 U	8	1 1/2	19-1528	35730-1	35702
326 U	8	1 1/2	19-1528	35730-1	
404 S	10	1 1/2		35730	
405 S	10	1 1/2		35730	
404 S	10	1 1/2		35730	
405 S	10	1 1/2		35730	
405 S	10	1 1/2		35730	
405 S	10	1 1/2		35730	
405 S	10	1 1/2		35730	
444 S	11	2		35730	
444 S	11	2		35730	



CYCLE	DRIVER	DRIVEN
80	38701 80-T	38699 80-T
80	38690 87-T	38687 87-T
80	-T	-T
80	38690 87-T	38687 87-T

20 H.P. FRAME 286U 340-T
60 CYCLE


25 H.P. FRAME 324U 380-T
60 CYCLE



DWG. #A-150-32-1
Motor Drive and Reversing Clutch
with Foot Mounted Motor - Sheet #2
G & L and Hypro Division

Part Number	Part Name	Part Number	Part Name
5287	Pinion	13839	Lever
5288-2	Feed Dial Gear	20769	Detent Plate
5290	Pin	35790	Feed Indicator
5405-8	Cover	35791	Cover
5417-1	Shifter Lever	35792	Shifter Lever
5705-2	Shifter Shaft	35793	Shifter
5708-2	Shifter Shaft	35794	Shifter Rod
5712-3	Shifter Shaft	35796	Spacer
5714-3	Gear Shifter	35797	Feed Control Box
5715-2	Gear Shifter	35798	Pinion
5732-1	Gear	19-833	Washer
5733-1	Gear	19-2068	Ball
10637	Crank	19-2798	Straight Pin
10749	Pin	19-2831	Straight Pin
10761-6	Cover	19-5211-1	Dial
10764	Shifter Lever	19-5213-1	Note Plate
10765	Shifter Lever	19-7427-1	Rockwood Sprinkler Handle - Plain
10766-1	Crank	19-7918	Spring
10768	Pin	19-8514	Thread Taper Pin




ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS






AL NUMBER WHEN ORDERING PARTS




DWG. #A-150-33-1
 Milling Feed Control
 G & L and Hypro Division

Part Number	Part Name
5422-2	Cover
5503	Column Spacer Key (Long)
5504	Column Spacer Key (Short)
5509	Column Spacer Key (Short)
7222-1	Coupling
10319	Bearing Housing
10320-1	Bearing Housing Cap
10325	Collar
10372	Trip Shaft
13258-9	Scale Shaft
33610	Swivel Bracket
35938	Column
35956	Plate
35958	Cover - Sheave Bracket
35960	Sheave Bracket
35962	Bracket
35963	Scale Shaft Bracket
35964	Sheave
35965	Sheave Shaft
35966	Bearing Cap
35967	Cover
35972	Eye Bolt
35976	Elevating Screw
35982	Vertical Drive Shaft
35996	Counterweight
36002	Guide Iron
37068	Aux. Counterweight
65993	Chain
19-838	Washer
19-2726	Straight Pin
19-2776	Straight Pin

Part Number	Part Name
19-7177	Scale
19-8503	Threaded Taper Pin
19-8510	Threaded Taper Pin
19-8514	Threaded Taper Pin




37068 AUX.
35958 COVE
-18 X 1 1/4 LG.
-13 EYE BOLT
35964
35965
65993 CHA
35960 SHE
35964 SHE
35965 SHE
35963 SCA
-16 X 1 1/4 LG. C
-18 HEX. JAM
-13 X 1 1/4 LG. S
19-8014 THREA




ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS


Part Number	Part Name	Part Number	Part Name
5422-2	Cover	35965	Sheave Shaft
5503	Column Space Key - Long	35966	Bearing Cap
7222-1	Coupling	35967	Cover
10319	Bearing Housing - Drive Shaft	35971-1	Counterweight
10320-1	Bearing Housing Cap	35976-1	Elevating Screw
10325	Collar	35982	Vertical Drive Shaft
10325-1	Collar	35987	Chain
10372	Trip Shaft	36002	Guide Iron
10375-8	Scale Strip	36077	Aux. Counterweight
33610	Swivel Bracket	45146	Eye Bolt
35943	Column	19-839	Washer
35957	Plate	19-2726	Straight Pin
35959	Sheave Bracket Cover	19-2759	Straight Pin
35961	Sheave Bracket	19-8503	Threaded Taper Pin
35962	Bracket	19-8507	Threaded Taper Pin
35963	Scale Shaft Bracket	19-8510	Threaded Taper Pin
35964	Sheave	19-8514	Threaded Taper Pin



SECTION A-A



SECTION B-B



35943
 - 9 X 3 1/2 LG SOC HD CAP SCR
 - 9 X 4 1/2 LG SOC HD CAP SCR
 - 11 HEX JAM NUT (2)
 - 10 X 1 1/2 LG SOC HD FLT PT
 19-2759 1/2 X 4 1/2 LG STR PIN
 19-8503 THD TAPER PIN (1)
 19-8507 THD TAPER PIN (1)
 19-839 WASHER (14)

35959
 - 18 X 1/2 LG SOC HD CAP SCR
 - 1/2" WILLIAMS EYE BOLT (1)

35964

35965

35967

35968

35961

35964

35965

35963
 - 16 X 1 1/2 LG CONE PT SET SCR
 - 18 HEX JAM NUT (1)
 - 16 HEX JAM NUT (2)
 - 13 X 1 1/2 LG SOC HD CAP SCR
 19-8514 THD TAPER PIN (2)

ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS

35943
 3 - 9 X 3 LG SOC HD CAP SCR (3)
 3 - 9 X 4 LG SOC HD CAP SCR (11)
 1 - 11 HEX JAM NUT (2)
 1 - 10 X 1/2 LG SOC HD FLT PT. SET SCR (2)
 19-2759 1/2 X 4 1/2 LG STR PIN (2)
 19-8503 THD TAPER PIN (1)
 19-8507 THD TAPER PIN (1)
 19-839 WASHER (14)

35967 (4)
 1 - 20 X 1/2 LG SOC FLT HD SCR (32)

35959
 1 - 18 X 1/2 LG SOC HD CAP SCR (11)
 1 - 20 WILLIAMS EYE BOLT (1)

35964

35965

35987


35957

35961

35964

35965

35963
 1 - 16 X 1/2 LG CONE PT. SET SCR (1)
 1 - 18 HEX JAM NUT (2)
 1 - 13 X 1/2 LG SOC HD CAP SCR (4)
 19-8514 THD TAPER PIN (2)



10375-8
 19-2726 1/2 DIA X 1/2 LG STR PIN (2)
 08-32 X 1/2 LG SOC FLT HD SCR (4)

10325
 1 - 16 X 1/2 SOC HD CAP SCR (1)
 7222-1
 5/16 X 1/2 TAPER PIN (1)

3422-2
 1 - 20 X 1/2 SOC HD CAP SCR (1)


WHEN ORDERING PARTS

DWG. #A-150-35-2
 Column (350-T)
 G & L and Hypro Division

Parts List for DWG. #A-150-40-1

Headstock



Part Number	Part Name	Part Number	Part Name
5080-1	Cover	35050	Pinion Shaft - 14T
5169	Clamp Sleeve	35051	Gear - 40T
5171	Retaining Plate	35052	Pinion Shaft - 14T
6208-1	Spacer	35053	Gear - 40T
6209-1	Nut	35055-4	Gear - 21T
7395	Clamp L. H. Adj. Sleeve	35056-5	Gear - 36T
7396	Clamp R. H. Adj. Sleeve	35098	Collar
10436-2	Bevel Gear	35099	Spacer
10494	Cover	35104	Nut
10537	Clamp Lever	35105	Cover
10539	Plate	35107-3	Spindle Sleeve
11668	Key	35108-1	Lock Nut
11684-1	Trip Tooth	35109-4	Bull Gear
11688-1	Shaft	35113-1	Oil Retainer
11704-1	Front Spindle Bushing	35114	Spindle Key
11705-1	Rear Spindle Bushing	35115	Oil Retainer
11711	Wiper Ring	35116	Spindle Sleeve Cover
11712	Spindle Wiper	35118-1	Shaft
11713	Key	35119	Main Spindle Guard
11853-3	Trip Tooth Guide	35126-1	Bearing Retainer
11908-2	Bevel Pinion	35130-4	Headstock
11909-4	Bevel Gear	35140	Auxiliary Spindle Cover
11910-7	Pinion	35141-4	Pinion Shaft - 21T
11916	Thrust Washer	35142-2	Gear
11955-1	Spindle - #5MT - Slot Type	35143-4	Gear
11980-4	Main Ram	35146-3	Gear - 28T
11987	Drive Shaft Tube	35224	Key
13915	Spacer	35226	Key
14143	Bearing Retainer Plate	35228	Retainer Ring
14569	Spacer	35245	Bearing Retainer
16369	Cover	38250	Spacer
16370	Cover	38251	Spacer
17436	Miter Gear - 18T	38252	Spacer
19283	Rack	38255	Bearing Retainer
19522	Adapter	38256	Clamp Screw
19523	Nut	38258	Bevel Pinion
19524	Clamp Ring	38260	Bearing Retainer
21684	Spacer	38261	Ram Guide Cover
24537-1	Bearing Retainer	38262	Spindle Guard
35029	Retainer	38282	Ram Guide
35032	Spacer	19-663	Drilled Hex. Hd. Cap Screw
35034	Bevel Gear	19-670	Cap Screw
35035	Shaft	19-675	Drilled Hex. Hd. Cap Screw
35037-3	Shaft	19-702	Drilled Hex. Hd. Cap Screw
35040	Gear - 29T	19-2199	Rd. End Key
35041	Gear - 33T	19-2316	Rd. End Key
35042	Gear - 30T	19-2705	Straight Pin
35043	Gear - 35T	19-2733	Straight Pin
35044	Gear - 28T	19-2750	Straight Pin
35045	Gear - 32T	19-2789	Straight Pin
35046	Gear - 31T	19-2830	Straight Pin (Cyonide)
35047	Gear - 31T	19-7988	Spring
35048	Gear - 24T	19-8530	Lock Nut
35049	Gear - 39T		




19283
 19-2788 1/4 x 1/4 PIN (2)
 1/4-20 x 1/4 SOC. HD. CAP SCR. (22)


11684-1
 19-2830
 19-7988

11853-1
 1214 SW
 1/4-20 x
 19-2788





ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS



38261
1/4 X 6 SOFT IRON WIRE
19-703 1/4-18 X 1/2 DR. HEX. HD. SCR. (2)
1/4-18 X 1/2 SDC. HD. CAP. SCR. (8)

11906-2



35224 (FIT AT ASSEM.)
1/4 X 4 SOFT IRON WIRE
19-678 1/4-20 X 1/2 DR. HEX. HD. CAP. SCR. (2)

11909-4
5J-8446 RBC BRG. (1)

11910-7

38255
1/4-18 X 1/2 SDC. HD. CAP. SCR. (4)
2" DIA. WELSH PLUS (1)
B 2420 TORRINGTON BRG. (2)

11668



14143
19-670 1/4-13 X 1/2 DR. HEX. HD. CAP. SCR. (6)
1/4 X 1/8 SOFT IRON WIRE

38282

38262
1/4-18 X 1/2 SDC. HD. CAP. SCR. (10)

DWG. #A-150-40-1
Headstock (340-T)
G & L and Hypro Division

ALWAYS GIVE MACHINE

SPINDLE FEED REVERSE LEVER

ROTARY SELECTOR & BACK
GEAR LEVERS FOR 45
SPINDLE SPEEDS

SPINDLE FINE HAND FEED

SPINDLE HIGH & LOW RANGE
SELECTOR LEVER

ROTARY SELECTOR
BACK GEAR FOR
SPINDLE FEEDS

G&L AND

DEPTH GAUGE
DIAL & CLAMP

TURNSTILE


HEADSTOCK CLAMP

REMOVE PUMP
TO CLEAN SCREEN


VISIBLE OIL LEVEL 1716x3

340 - 38292
350 - 38246

OPERATORS VIEW



ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS




Part Number	Part Name
19-1168	Note Plate
19-1475	Note Plate
19-1655	Note Plate
19-5201-2	Note Plate
19-5308-2	Note Plate
19-6522	Note Plate
19-6523	Note Plate
19-6527	Note Plate
19-7198	Note Plate
19-7661-1	Note Plate


OPERATORS VIEW

DWG. #A-150-40-2
Headstock (340-T)
G & L and Hypro Division


Part Number	Part Name	Part Number	Part Name
4802	Dial Clamp	35093-1	Shaft
4825-1	Dial Clamp Screw	35094	Shifter Shoe
5101-1	Clamp Lever Bracket	35095	Shifter Shoe
5110-1	Headstock Clamp Lever	35096	Shifter Rod
5122-1	Cover	35107-3	Spindle Sleeve
5179	Shaft	35109-4	Bull Gear
5226	Hand Wheel	35118-1	Shaft
5228	Bushing	35119	Main Spindle Guard
5229	Dial	35121	Shaft
5230	Plate	35122	Shaft
5231	Dial Clamp Pin	35123	Shifter Rod
5232	Coupling	35124	Shifter Shoe
5733-1	Gear	35125-1	Shifter Shoe
6217	Speed Dial Gear	35130-4	Headstock
6218	Gear	35141-4	Pinion Shaft
10561	Shaft	35143-4	Gear
11688-1	Shaft	35226	Key
11705-1	Rear Spindle Bushing	35228	Retainer Ring
11955-1	Spindle - #5MT - Slot Type	35231	Shifter Crank Plate
11968-3	Head Gib - Left	35234	Pin
11980-4	Main Ram	35235	Link
13839	Lever	35241	Shifter
14052	Gear	35245	Bearing Retainer
20107	Shifter Pin	35403	Housing
20769	Detent Plate	35404	Cover
35001-1	Bracket	35405	Gear
35035	Shaft	35406	Gear
35037-3	Shaft	35407	Link
35040	Gear - 29T	35408	Slide
35041	Gear - 33T	35444	Shifter Cam
35042	Gear - 30T	35445	Shifter Handle
35043	Gear - 35T	35446	Shifter Hub
35044	Gear - 28T	35447	Spring Plunger
35045	Gear - 32T	35449	Shifter Crank
35050	Pinion Shaft - 14T	35450	Shifter Stub
35053	Gear - 40T	38265	Shifter Gib
35055-4	Gear - 21T	38289	Shifter Bar
35056-5	Gear - 36T	38290	Shifter Plate
35066	Gear	38291	Shifter
35067-1	Pin	38294	Headstock Cover
35068-1	Shifter Disc	19-675	Drilled Hex. Hd. Cap Screw
35069-2	Gear	19-1475	Note Plate
35070-3	Shaft	19-2067	Steel Ball
35071	Shaft End	19-2068	Steel Ball
35072	Gear	19-2733	Straight Pin
35073-1	Shaft	19-2736	Straight Pin
35074	Gear	19-2789	Straight Pin
35075-1	Pinion Shaft	19-2852	Straight Pin
35076	Shifter Disc	19-3053	Straight Pin
35077	Shifter Disc	19-3057	Straight Pin
35078	Pin	19-3107	Straight Pin
35083	Shifter Block	19-6526	Speed Dial
35084	Shifter Block	19-7427-1	Rockwell Sprinkler
35086-2	Shifter Rod		Handle - Plain
35087-1	Shifter Rod	19-7915	Spring
35088-1	Shifter Rod	19-7918	Spring
35089	Shifter Block	19-7919	Spring
35090	Shifter Lever	19-7978	Spring
35091	Shifter Lever	19-8502	Taper Pin
35092	Shifter Lever	19-8982	Bushing




ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS



SECTION R-R



OPERATORS VIEW WITH COVER REMOVED






SECTION N-N

44

ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS

Part Number	Part Name	Part Number	Part Name
4825-1	Dial Clamp Screw	11987	Drive Shaft Tube
5080-1	Cover	13839	Lever
5093-1	Headstock Clamp	16365	Screw Tube
5122-1	Cover	16370	Cover
5192	Wiper Plate	17656-1	Taper Gib - Left Clamp
5193	Felt Wiper	17657-1	Taper Gib - Right Clamp
5226	Hand Wheel	19283	Rack
5228	Bushing	20769	Detent Plate
5229	Dial	21684	Spacer
5230	Plate	35034	Bevel Gear
5251	Dial Bearing	35119	Main Spindle Guard
5252-7	Dial	35130-4	Head Stock
5256-1	Lever	35404	Cover
5293-1	Shifter Lever	38249	Cover
5353-1	Lever	38251	Spacer
5849	Shoulder Screw	38252	Spacer
5854	Wiper Plate	38258	Bevel Pinion
5855	Wiper Felt	38260	Bearing Retainer
5869-1	Filler Block	38261	Ram Guide Cover
5870-1	Filler Block	38262	Spindle Guard
7380-1	Headstock Clamp Lever	38263	Cover
10433	Pin	38267	Cover
10434	Pin Support	38282	Ram Guide
11605	Trip Shaft Tube	38283	Spindle Feed Case
11955-1	Spindle - #5MT - Slot Type	38284	Cover
11968-3	Head Gib - Left	38294	Headstock Cover
11969-3	Head Gib - Right	19-2712	Straight Pin
11971-1	Clamp - Right	19-7930	Spring
11972-1	Clamp - Left	19-9756	Oil Pump Assembly
11980-4	Main Ram		






DWG. #A-150-40-4
 Headstock (340-T)
 G & L and Hypro Division

Parts List for DWG. #A-150-40-5


Headstock

Part Number	Part Name	Part Number	Part Name
4560-1	Headstock Button	35087-1	Shifter Rod
5101-1	Clamp Lever Bracket	35088-1	Shifter Rod
5110-1	Headstock Clamp Lever	35105	Cover
5127	Adjusting Bushing	35107-3	Spindle Sleeve
7380-1	Headstock Clamp Lever	35116	Spindle Sleeve Cover
10436-2	Bevel Gear	35118-1	Shaft
11688-1	Shaft	35119	Main Spindle Guard
11713	Key	35126-1	Bearing Retainer
11955-1	Spindle - #5MT - Slot Type	35122	Shaft
11972-1	Clamp - Left	35130-4	Headstock
11974-1	Clamp Rod - Short	35132	Pin
11980-4	Main Ram	35133	Yoke
11981-1	Oil Pipe	35140	Aux. Spindle Cover
17432-1	Cover	35141-4	Pinion Shaft - 21T
17433-2	Shaft	35142-2	Gear
17435	Screen	35226	Key
17436	Miter Gear - 18T	38257	Coupling
17437	Miter Gear - 18T	38287	Long Clamp Rod
17440	Spacer	38288	Clamp Rod Tubing
17656-1	Taper Gib - Left Clamp	38289	Shifter Bar
17721	Oil Feed Sleeve	38292	Cover
35029	Retainer	38294	Headstock Cover
35035	Shaft	19-2221	Round End Key
35050	Pinion Shaft - 14T	19-2825	Straight Pin
35051	Gear - 40T	19-9105	Bushing
35052	Pinion Shaft - 14T	19-9527	Threaded Taper Pin

ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS




SPINDLE END VIEW




SECTION THRU CLAMPING

ALWAYS GIVE MACHINE **SERIAL NUMBER** WHEN ORDERING PARTS



SECTION THRU CLAMPING




SECTION THRU OIL PUMP

DWG. #A-150-40-5
Headstock (340-T)
G & L and Hypro Division



Parts List for DWG. #A-150-40-6

Headstock


Part Number	Part Name	Part Number	Part Name
5251	Dial Bearing	10715-9	Gear - 23T
5252-7	Dial - English	10716-2	Feed Gear
5253-2	Clutch	10717-2	Gear
5254	Clutch Plate	10718-2	Gear
5255	Lever Plate	10719	Spacer
5256-1	Lever	10720-1	Gear
5257	Worm Gear	10721-1	Gear
5262-2	Pinion Shaft	10722-1	Gear
5263-5	Worm Shaft	10723	Retainer
5264-4	Pinion Shaft	10724	Retainer
5272	Shifter Lever	10725-2	Gear
5274-1	Shifter Shoe	10726-2	Gear
5275-1	Shifter Shoe	10736	Gear
5286	Shifter Lever	10737	Gear
5287	Pinion	10738	Pin
5288-1	Feed Dial Gear	10739-1	Shifter Block
5293-1	Shifter Lever	10740-1	Shifter Block
5294-2	Shifter Lever	10741-1	Shifter Shaft
5295-1	Feed Indicator	10742-1	Shifter Shaft
5297	Clutch	10743-1	Shifter
5298	Stud	10744-1	Shifter
5299	Clamp	10745-2	Shaft
5300	Dial Guide	10749	Pin
5301	Clamp Nut	10964	Spacer
5302	Clamp Lever	13839-1	Lever
5303	Clutch Plunger	16518-1	Gear - 16T
5305	Retaining Plate	16519-1	Gear - 32T
5306	Worm	19312	Gear - 24T
5307-1	Thrust Washer	35130-4	Headstock
5315	Bearing Retainer	38263	Cover
5317	Bearing Retainer	38283	Spindle Feed Case
5318	Pin	38284	Cover
5319-4	Pinion Shaft	38292	Cover
5320-6	Shaft	19-666	Drilled Hex. Hd. Cap Screw
5321-1	Shaft	19-811	Washer
5322-1	Shaft	19-838	Washer
5328-2	Cluster Gear	19-2067	Ball
5330-2	Gear	19-2068	Ball
5331-2	Gear	19-2072	Ball
5333-2	Gear	19-2182	Round End Key
5335-2	Gear	19-2708	Straight Pin
5336-2	Gear	19-2774	Straight Pin
5337	Spacer	19-2792	Straight Pin
5339	Spacer	19-2899	Straight Pin
5342	Spacer	19-7427-1	#1 Rockwood Quick Action Handle
5343	Collar		
5344	Spacer	19-7909	Spring
5345	Clutch Adj. Pin	19-7918	Spring
5346	Clutch Adj. Pin	19-8502	Threaded Taper Pin
5348	Feed Knockout Pin	19-8523	Lock Nut
5353-1	Lever	19-8524	Lock Nut
6270	Spacer	19-8860	Bushing
10668-2	Bevel Gear	19-8985	Bushing
10712-3	Bracket	19-8990	Bushing




SECTION S-S




SECTION U-U





ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS






SECTION U-U

RIAL NUMBER WHEN ORDERING PARTS



POSITION GEARS AND CRANK AS SHOWN



DWG. #A-150-40-6
Headstock (340-T) (Spindle Feed)
G & L and Hypro Division


Parts List for DWG. #A-150-40-7

Headstock


Part Number	Part Name	Part Number	Part Name
4037	Key	35045	Gear - 32T
5080-1	Cover	35046	Gear - 31T
5169	Clamp Sleeve	35047	Gear - 31T
5171	Retaining Plate	35048	Gear - 24T
6208-1	Spacer	35049	Gear - 39T
6209-1	Nut	35050	Pinion Shaft - 14T
7395	Clamp L. H. Adj. Sleeve	35051	Gear - 40T
7396	Clamp R. H. Adj. Sleeve	35052	Pinion Shaft - 14T
9251	Wiper Ring	35053	Gear - 40T
9517	Spacer	35055-4	Gear - 21T
9518	Bearing Retainer	35056-5	Gear - 36T
10415-3	Spindle Key	35058-5	Bull Gear
10417-2	Spindle Bushing	35098	Collar
10418-1	Spindle Bushing	35099	Spacer
10429	Spindle Wiper	35101-2	Shaft
10436-2	Bevel Gear	35103	Spacer
10496-1	Bevel Pinion - 24T	35104	Nut
10497-4	Bevel Gear - 40T	35105	Cover
10505	Trip Tooth - Main	35140	Aux. Spindle Cover
10537	Clamp Lever	35141-5	Pinion Shaft
10539	Plate	35142-2	Gear
10576	Main Spindle Guard	35143-5	Hi-Speed Gear
10580-9	Main Ram	35146-2	Gear
10580-10	Main Ram (Metric)	35157-1	Spacer
10581-1	Spindle - #6MT - Slot Type	35222-1	Bearing Retainer
11668	Key	35225	Key
11688-3	Shaft	35226-1	Key
11853-2	Trip Tooth Guide	35228-1	Retainer Ring
11916-1	Thrust Washer	35245	Bearing Retainer
13911-5	Pinion	38241	Ram Guide
14569	Spacer	38244	End Housing
16369	Cover	38245	Cover
16370	Cover	38247	Cover - Ram Pinion
17436	Miter Gear - 18T	38248	Bearing Retainer
19281	Clamp Ring	38250	Spacer
19282	Rack	38251	Spacer
19520	Adapter	38252	Spacer
19521	Nut	38255	Bearing Retainer
21684	Spacer	38256	Clamp Screw
24537-1	Bearing Retainer	38258	Bevel Pinion
35000-7	Headstock	19-663	Drilled Hex. Hd. Cap Screw
35025	Nut	19-675	Drilled Hex. Hd. Cap Screw
35027-1	Nut	19-680	Drilled Hex. Hd. Cap Screw
35028	Bearing Retainer	19-702	Drilled Hex. Hd. Cap Screw
35029	Retainer	19-703	Drilled Hex. Hd. Cap Screw
35031	Spindle Sleeve Cover	19-2199	Key
35032	Spacer	19-2316	Round End Key
35034	Bevel Gear	19-2705	Straight Pin
35035	Shaft	19-2727	Straight Pin
35036	Oil Retainer	19-2750	Straight Pin
35037-3	Shaft	19-2758	Straight Pin (Cyanide)
35038-5	Spindle Sleeve	19-2789	Pin
35040	Gear - 29T	19-7988	Spring
35041	Gear - 33T	19-8504	Taper Pin
35042	Gear - 30T	19-8530	Hex Lock Nut
35043	Gear - 35T	19-9756	Oil Pump Assembly
35044	Gear - 28T		

Type 350
9300


ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS



SECTION B-B



SECTION OF RAM S



SPINDLE ADAPTER

ROTARY SELECTOR & BACK
GEAR LEVERS FOR 45
SPINDLE FEEDS

SPINDLE FINE HAND FEED

SPINDLE HIGH & LOW RANGE
SELECTOR LEVER

ROTARY SELECTOR & BACK GEAR
FOR 18 SPINDLE FEEDS

SPINDLE FEED REVERSE LEVER

CAUTION
DO NOT ENGAGE
POWER SPINDLE
FEED WHEN
SPINDLE IS IN
EXTREME
OUT POSITION

19-5308-2

19-7151

19-5201-2

SPINDLE SPEEDS IN
REV. PER MINUTE

STANDARD HIGH

19-7152-6

CAUTION
BEFORE SHIFTING THIS LEVER
PRESS STOP BUTTON
IF NECESSARY TOUCH INCH BUTTON
BEFORE SLIDING GEARS INTO MESH

19-1168

19-1475



19-7661-1

DEPTH GAUGE
DIAL & CLAMP


TURNSTILE

REMOVE PUMP
TO CLEAN SCREEN

19-7198

VISIBLE OIL LEVEL

HEADSTOCK CLAMP




GIDD

ROTARY SELECTOR & BACK GEAR
FOR 18 SPINDLE FEEDS

SPINDLE FEED REVERSE LEVER

Part Number	Part Name	Part Number	Part Name
19-1168	Note Plate	19-7151	Note Plate
19-1475	Note Plate	19-7152-6	Note Plate
19-1655	Note Plate	19-7661	Note Plate
19-5201-2	Note Plate	19-7198	Note Plate
19-5308-2	Note Plate		

ALWAYS GIVE MACHINE **SERIAL NUMBER** WHEN ORDERING PARTS








DWG. #A-150-40-8
Headstock (350-T)
G & L and Hypro Division

Parts List for DWG. #A-150-40-9

Headstock


Part Number	Part Name	Part Number	Part Name
4802	Dial Clamp	35084	Shifter Block
4825-1	Dial Clamp Screw	35085-1	Shifter Rod
5101-1	Clamp Lever Bracket	35086-3	Shifter Rod
5110-1	Headstock Clamp Lever	35087	Shifter Rod
5179	Shaft	35088	Shifter Rod
5226	Hand Wheel	35089	Shifter Block
5228	Bushing	35090	Shifter Lever
5229	Dial	35091	Shifter Lever
5230	Plate	35092	Shifter Lever
5231	Dial Clamp Pin	35093	Shaft
5232	Coupling	35094	Shifter Shoe
5733-1	Gear	35095	Shifter Shoe
6217	Speed Dial Gear	35096	Shifter Rod
6218	Gear	35101-2	Shaft
10460	Screw Tube	35143-5	Gear
10561	Shaft	35231	Shifter Crank Plate
10576	Main Spindle Guard	35234	Pin
10580-9	Main Ram	35235	Link
10581-1	Spindle - #6MT - Slot Type	35241	Shifter
11688-3	Shaft	35245	Bearing Retainer
13839	Lever	35402-3	Headstock Cover
14052	Gear	35403	Housing
20107	Shifter Pin	35404	Cover
20769	Detent Plate	35405	Gear
35000-7	Headstock	35406	Gear
35001	Bracket	35407	Link
35035	Shaft	35408	Slide
35037-3	Shaft	35444	Shifter Cam
35038-5	Spindle Sleeve	35445	Shifter Handle
35040	Gear - 29T	35446	Shifter Hub
35042	Gear - 32T	35447	Spring Plunger
35043	Gear - 35T	35448	Spacer
35044	Gear - 28T	35449	Shifter Crank
35045	Gear - 32T	35450	Shifter Stud
35046	Gear - 31T	35976	Elevating Screw
35050	Pinion Shaft - 14T	38242	Shifter
35053	Gear - 40T	38264	Shifter Plate
35055-4	Gear - 21T	38265	Shifter Gib
35056-5	Gear - 36T	38266	Shifter Bar
35058-5	Bull Gear	19-675	Drilled Hex. Hd. Screw
35066	Gear	19-1475	Note Plate
35067-2	Pin	19-2067	Ball
35068-1	Shifter Disc	19-2068	Ball
35069-2	Gear	19-2733	Straight Pin
35070-4	Shaft	19-2736	Straight Pin
35071	Shaft End	19-2789	Straight Pin
35072	Gear	19-2852	Straight Pin
35073	Pinion Shaft	19-3022	Straight Pin
35074	Gear	19-3057	Straight Pin
35075	Pinion Shaft	19-3107	Straight Pin
35076	Shifter Disc	19-7915	Spring
35077	Shifter Disc	19-7918	Spring
35078	Shifter Disc	19-7919	Spring
35081	Shifter Shoe	19-7978	Spring
35082-1	Shifter Shoe	19-8502	Threaded Taper Pin
35083	Shifter Block	19-8982	Bushing



OPERATORS VIEW WITH COVER REMOVED

VE MACHINE SERIAL NUMBER WHEN ORDERING PARTS


DWG. #A-150-40-9
Headstock (350-T)
G & L and Hypro Division



SECTION C-C

NOTE:
 SAME WIPER PLATES, FELTS & BLOCKS
 USED ON BOTTOM EXCEPT USE
 5854 - 5855 - 5869-1 AT THIS POINT


ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS



Part Nu
4560-1
4825-1
5080-1
5122-1
5226
5228
5229
5230
5251
5252-7
5256-1
5299

ORDERING PARTS

Part Number	Part Name	Part Number	Part Name	Part Number	Part Name	Part Number	Part Name
4560-1	Headstock Button	5302	Clamp Lever	10420-2	Head Gib - Right	10581-1	Spindle - #6MT - Slot Drive
4825-1	Dial Clamp Screw	5353-1	Lever	10430	Headstock Clamp	10600-10	Spindle Feed Case
5080-1	Cover	5849	Shoulder Screw	10433	Pin	10639-2	Cover
5122-1	Cover	5854	Wiper Plate - 1-3/4" Long	10434	Pin Support	10657-1	Shifter Lever
5226	Hand Wheel	5855	Wiper Felt - 1-3/4" Long	10441-1	Clamp - Left	13839	Lever
5228	Bushing	5869-1	Filler Block	10442-1	Clamp - Right	16370	Cover
5229	Dial	5870-1	Filler Block	10448	Wiper Plate	17668	Taper Gib
5230	Plate	6247	Wiper Plate	10449	Wiper Felt	17669	Taper Gib
5251	Dial Bearing	6248	Felt Wiper	10494	Cover	19282	Rack
5252-7	Dial - English	7320-1	Shifter Lever	10575	Trip Shaft Tube	20769	Detent Plate
5256-1	Lever	7380-1	Headstock Clamp Lever	10576	Main Spindle Guard	21684	Spacer
5299	Clamp	10419-1	Head Gib - Left	10580-9	Main Ram	35000-7	Headstock



Part Number	Part Name
35034	Bevel Gear
35403-2	Housing
35404	Cover
38241	Ram Guide
38243	Cover
38244	End Housing
38245	Cover
38247	Cover - Ram Pinion
38248	Bearing Retainer

Part Number	Part Name
38249	Cover
38251	Spacer
38252	Spacer
38253	Tube Drive Shaft
38254	Cover
38258	Bevel Pinion
38267	Cover
19-2712	Straight Pin
19-7930	Spring



DWG. #A-150-40-10
Headstock (350-T)
G & L and Hypro Division

Parts List for DWG. #A-150-40-11

Headstock

Part Number	Part Name	Part Number	Part Name
4037	Key	35038-5	Spindle Sleeve
4560-1	Headstock Button	35050	Pinion Shaft - 14T
5101-1	Clamp Lever Bracket	35051	Gear - 40T
5110-1	Headstock Clamp Lever	35052	Pinion Shaft - 14T
5127	Adjusting Bushing	35055-4	Gear - 21T
5155-1	Tubing - Clamp Rod	35056-5	Gear - 36T
7380-1	Headstock Clamp Lever	35058-5	Bull Gear
10431-1	Clamp Rod - Long	35081	Shifter Shoe
10436-2	Bevel Gear	35085-1	Shifter Rod
10441-1	Clamp - Left	35086-3	Shifter Rod
10452-1	Oil Pipe	35087	Shifter Rod
10576	Main Spindle Guard	35088	Shifter Rod
10580-9	Main Ram	35101-2	Shaft
10581-1	Spindle - #6MT - Slot Type	35105	Cover
11688-3	Shaft	35132	Pin
11974-1	Clamp Rod - Short	35133-2	Yoke
17432-1	Cover	35140	Auxiliary Spindle Cover
17433-1	Shaft	35141-5	Pinion Shaft
17435	Screen	35142-2	Gear
17436	Miter Gear - 18T	35143-5	Gear
17437	Miter Gear - 18T	35402-3	Headstock Cover
17440	Spacer	38242	Shifter
17669	Taper Gib	38246	Cover
17721	Oil Feed Sleeve	38257	Coupling
35000-7	Headstock	38266	Shifter Bar
35001	Bracket	19-2221	Rd. End Key
35029	Retainer	19-2825	Straight Pin
35031	Spindle Sleeve Cover	10-9104	Bushing
35035	Shaft	19-9527	Taper Pin


ALWAYS GIVE MA



SPINDLE END VIEW

SECTION THRU CLAMPING

ALWAYS GIVE MACHINE **SERIAL NUMBER** WHEN ORDERING PARTS



U CLAMPING




SECTION THRU PUMP

DWG. #A-150-40-11
Headstock (350-T)
G & L and Hypro Division

Parts List for DWG. #A-150-40-12


Headstock

Part Number	Part Name	Part Number	Part Name
5232	Coupling	10618-1	Shaft
5251	Dial Bearing	10620-1	Back Shaft
5252-7	Dial - English	10621-1	Gear - 20T
5253-2	Clutch	10622-2	Gear - 24T
5254	Clutch Plate	10623-1	Gear - 30T
5255	Lever Plate	10624-2	Gear - 25T
5256-1	Lever	10625-1	Gear - 24T
5257	Worm Gear	10629	Shifter Lever
5258-7	Bevel Gear	10630-1	Pin
5263-2	Worm Shaft	10632	Shifter Block
5272	Shifter Lever	10633	Shifter Block
5287	Pinion	10634	Lever
5288-1	Feed Dial Gear	10635	Lever
5290	Pin	10636	Shifter
5297	Clutch	10637	Crank
5298	Stud	10638	Crank
5299	Clamp	10639-2	Cover
5300	Dial Guide	10643	Shifter
5301	Clamp Nut	10646	Feed Indicator
5302	Clamp Lever	10651	Shifter Shaft
5303	Clutch Plunger	10654	Spacer
5305	Retaining Plate	10657-1	Shifter Lever
5306	Worm	10658	Sleeve
5307-1	Thrust Washer	10659	Shaft
5315	Bearing Retainer	10660	Sleeve
5318	Pin	10661	Spacer
5337	Spacer	10749	Pin
5345	Clutch Adj. Pin	10958	Shaft
5346	Clutch Adj. Pin	10964	Spacer
5348	Feed Knockout Pin	13839	Lever
5353-1	Lever	16516-1	Gear - 18T
5624-1	Gear	16517-1	Gear - 36T
5680	Cover	19300	Feed Gear
5732-1	Gear	35000-7	Headstock
5733-1	Gear	38246	Cover
7106-1	Feed Gear - 19T	19-663	Drilled Hex. Hd. Cap Screw
7107-1	Feed Gear - 22T	19-666	Drilled Hex. Hd. Cap Screw
7108-1	Feed Gear - 25T	19-812	Washer
7109-2	Feed Gear - 37T	19-2067	Ball
7110-1	Feed Gear - 30T	19-2068	Ball
7112-2	Feed Gear - 33T	19-2072	Ball
7113-1	Feed Gear - 40T	19-2182	Key
7114-1	Feed Gear - 32T	19-2708	Pin
7115-3	Shaft	19-2781	St. Pin
7117-1	Feed Gear - 42T	19-2786	St. Pin
7127	Thrust Washer	19-2792	St. Pin
7128	Thrust Washer	19-2808	St. Pin
7203	Retainer	19-2809	St. Pin
7205	Retainer	19-2831	Pin
7320-1	Shifter Lever	19-7909	Spring
7321	Shifter Shoe	19-7918	Spring
7323	Shifter Lever	19-8502	Taper Pin
10600-10	Spindle Feed Case	19-8522	Lock Nut
10601-1	Spindle Feed Bracket	19-8860	Bushing
10602-4	Gear - 37T	19-8928	Bushing
10603	Shaft	19-8929	Bushing
10604	Spacer	19-8930	Bushing
10606-1	Shaft	19-8931	Bushing
10608	Spacer	19-8957	Bushing
10616-1	Shaft		







SECTION T-T

SECTION U-U



VIEW S-S



- 5255
- 5300 (2)
- 5251
- 5252-7
- 5302
- 5303
- 5346 (2)
- 5318 (4)
- 5345 (2)
- 5348
- 5254
- 10600-10
- 19-2809 (1/2 X 10 1/2 STR. PIN) (1)
- 19-8502 TAPER PIN (2)
- 18 HEX JAM NUT (2)
- 11 X FLY. PT. SET SCR. (1)
- 18 X DOG PT. SET SCR. (3)
- 18 X FLY. PT. SET SCR. (3)
- 13 X 4 SOC. HD. CAP SCR. (2)
- 13 X 1/2 SOC. HD. CAP SCR. (1)
- 13 X 1/2 SOC. HD. CAP SCR. (12)

ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS




DWG. #A-150-40-12
Headstock (350-T) (Spindle Feed)
G & L and Hypro Division

Parts List for DWG. #330-A-5

Table and Saddle

Part Number	Part Name	Part Number	Part Name	Part Number	Part Name
3636	Trip Cam Stud	5853	Felt Wiper	10934	Shifter Shaft
3643-B	Horizontal Rod End	5854	Wiper Plate	10936-B	Bevel Gear
3644	Rod End Pin	5855	Felt Wiper	10937-B	Shaft
4475	Clutch Ring	5856	Wiper Plate	10937-C	Shaft
4532	Plate	5857	Felt Wiper	10938-B	Shaft
4802	Dial Clamp Pin	5858	Wiper Plate	10938-C	Shaft
4825-A	Dial Clamp Screw	5859	Felt Wiper	10939-B	Trip Shaft
5421	Shifter Lever	5862	Taper Gib 30x60 Table	10945-B	Table 48x72
5775-C	Table 30x60	5869-A	Filler Block	10946-A	Wedge
5776-C	Table 36x72	5870-A	Filler Block	10948	Shifter Lever
5777-F	Saddle 30x60	5873-B	Table Clamp L. H. 72" Long Table	10949	Shaft
5778-G	Saddle 36x72	5874-B	Table Clamp R. H. 72" Long Table	10950-A	Bracket Clamp Lever
5778-H	Saddle 48x72	5876	Taper Gib 72" Long Table or Saddle	10951-A	Bracket Clamp Lever
5782	Cover	5877	Taper Gib 72" Long Table	10952	Pump Bracket
5783-F	End Bracket	5900-D	Table Drive Housing	10953	Pump Lever
5785	Cover	5901-C	Housing Cover	10954	Pull Rod
5786-A	Trip Dog	5903-A	Table Cross Feed Nut	10955	Collar
5789-C	Lever	5934-A	Pump Rocker Arm	10956	Screen
5789-E	Lever	6930-I	Vernier Holder	10963	Pin
5792-A	Table Screw (30x60 Table)	6932-A	Vernier Bracket	14216	Bushing
5795-C	Lever	6982	Vernier Bracket	14258	Clutch
5796-A	Nut - Long Feed	10862-A	Lever	14460	Pin
5797-B	Table Clamp R. H. 30x60 Table	10863	Pin	14813	Coupling
5798-B	Table Clamp L. H. 30x60 Table	10870	Lever Table Clamp	17724	Guard
5799-B	Clamp Stud	10870-B	Lever Table Clamp	17725	Pin
5802	Pivot Block	10878	Rod End Pin	17726	Disc
5803-C	Clamp Lever - Rear	10879-A	Toggle	17729	Pivot Nut
5804-C	Clamp Lever - Front	10882	Lever	17733	Dial Extension
5805	Spacer	10890	Stud	17744	Gib Retainer
5806-A	Plate	10890-B	Stud	S-803	Washer
5807-B	Shaft	10901-C	Table Clamp	S-2066	Base
5808-A	Lever	10902-D	Table Clamp	S-2116	Disc
5809	Shaft	10903-B	Link	S-2191	Key
5813	Trip Lever Link	10904-B	Lever	S-2371	Key
5816	Dog Adjustment	10905-A	Bracket	S-2704	Pin
5817	Dog - Rear	10906-B	Shaft	S-2707	Pin
5818	Dog - Front	10907-A	Lever	S-2779	Straight Pin
5821-D	Bevel Pinion	10908-A	Link	S-2805	Pin
5824	Bushing	10912-A	Shaft	S-2806	Straight Pin
5825	Micro Dial	10916-B	Clamp - Rear	S-2865	Straight Pin
5826	Micro Dial	10917-A	Clamp - Front	S-7131	Table, Vernier, Body Assembly
5828	Dial Clamp Pin	10919	Lever	S-7203	Bushing
5829	Taper Gib 30x60 Table	10919-A	Lever	S-7901	Spring
5846-A	Nut	10920-A	Link	S-7915	Spring
5847	Shim	10932	Screw Table 36x72, and 48x72	S-7919	Spring
5848	Shim	10933-A	Shaft	S-7930	Spring
5849	Shoulder Screw			S-7931	Spring
5849-A	Shoulder Screw			S-7938	Spring
5851	Coupling			S-8209	Nut
5852	Wiper Plate			S-8514	Pin
				S-8518	Taper Pin
				S-8524	Nut

NOTE - SEE 350 TABLE B SADDLE ASSEMBLY FOR LOCATION OF OIL LINES FOR BIJUR PUMP




ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS

3- FRONT - 3/8-16 X 1 1/4 HEX. HD. SCR.
3- ADJUSTABLE
3- REAR
3- 3/8-16 HEX. NUT (1)
5873-B 36 X 72
5798-B 30 X 60
5873-B 48 X 72

NOTE - SEE TABLE B SADDLE ASSEMBLY FOR LOCATION OF OIL LINES FOR BIJUR PUMP

5- 8-11 X 1 1/4 SOCKET HD.
4- 20 X 4 SOCKET HD. CAP SCR. (6)
6 X 1 1/4 TAPER PIN (2)
4532
4- 20 X 8 RD. HD. SCR. (4)
5- 16-18 X 2 DOG PT.
5847 SHIM
SPRING 3 S-7931
17726
16 X 9 WIRE (2)
10938-B
5824
5826
14216
14238
330-1 1/4-20 X 1/4 FLAT PT. SET SCREW
1/4-20 X 3/8 CONE PT. SET SCR.
4475
5828
4825-A
10938-B (30 X 60) (36 X 72)
10938-C (48 X 72)
DIAL EXTENSION 17733 (2) (48 X 72 ONLY)
3/8-16 X 7/8 SOCKET HD. (4)



5792-A (30 X 60) (S-2191 KEY) TABLE SCREW
10932 (36 X 72) (S-2191 KEY) TABLE SCREW
10932 (48 X 72) (S-2191 KEY) TABLE SCREW

NOTE: 5903-A TABLE CROSS FEED SCREW NUT USED ON ALL TABLES

10870 (30 X 60) (36 X 72)
10870-B (48 X 72) } TABLE CLAMPING LEVER
5789-E (30 X 60) (36 X 72)
5789-C (48 X 72) } TABLE DIRECTIONAL FEED LEVER


10919 (30 X 60) (36 X 72)
10919-A (48 X 72) } SADDLE CLAMPING LEVER

S-7131 TABLE VERNIER BODY ASSEMBLY

5/8-11 X 1/2 FLAT PT. SET SCR.
S-7938 SPRING
S-2066 BALL
5/16-18 X 3/4 SOC. HD. SCR.
5/16-18 X 1 SOC. HD. SCR. (4)
S-2704 1/4 X 1 ST. PIN (2)

END OF TABLE

5807-B
5805
5806-A
3/16 X 1 1/2 RD. HD. IRON RIVET (4)
10950-A
S-2805
5/8 X 1 1/4
5/16-18 X 1 3/4 SOC. HD. CAP SCR. (2)
3/8-16 HEX. JAM NUT
3/8-16 X 1 3/4 FLAT PT. SET SCR.
5799-B
10916-B
3/4-10 X 2 HE X. HD. SCR. (4)
17744
V2-13 X 1 SOC. HD. CAP SCR. (2)
10-32 X 3/8 FLT. HD. MACH. SCR. (3)
5786-A
3/8-16 X 3/8 FLAT PT. SET SCR.
3/8-16 X 3/8 DOG PT. SET SCR.




17729
5807-B
5805
5806-A
3/16 X 1 1/2 RD. HD. RIVET (4)
5802
5803-C
5856 PLATE
5857 FELT
5799-B
5869-A
5849 S-7930
5858
5859
10917-A
5854 3/4-10 X 2 HEX. HD. SCREW (4)
5855
3/4-10 X 2 HEX. HD. CAP SCREW (4)
5799-B
3/8-16 X 3/8 FLAT PT. SET SCR.
3/8-16 X 3/8 DOG PT. SET SCR.

DWG. #330-A-5
Table and Saddle
G & L and Hypro Division

54

Part Number	Part Name	Part Number	Part Name
5398-A	Nut	13436-A	Gear
5405-E	Cover	13437-C	Gear
5412-B	Cover	13438	Spacer
5414-E	Bearing Bracket	13439-B	Clutch
5419-A	Shifter Lever	13443-A	Bracket
5420-A	Shifter Lever	13445	Cover
5680	Cover	13448	Spacer
13404-B	Saddle Screw	13449	Spacer
13404-C	Saddle Screw (Metric)	13450-B	Shifter
13405-B	Saddle Screw	13458	Retaining Plate
13405-C	Saddle Screw (Metric)	13459	Spacer
13406-B	Saddle Screw	13468-A	Shaft
13406-C	Saddle Screw (Metric)	13486	Plate
13407-B	Saddle Screw	13487	Pin
13407-C	Saddle Screw (Metric)	13488-A	Crank
13412-C	Saddle Screw	13490-A	Lever
13412-D	Saddle Screw (Metric)	18002-A	Saddle Screw
13427-E	Gear	S-675	Cap Screw
13428-B	Gear	S-2219	Round Ends Key
13429-A	Gear	S-2709	Straight Pin
13430-A	Bracket	S-2710	Straight Pin
13431	Pin	S-2783	Straight Pin
13432-A	Gear	S-2848	Straight Pin
13433-A	Gear	S-8994	Bushing
13434	Shaft		

ALWAYS GIVE MACHINE **SERIAL NUMBER** WHEN ORDERING PARTS



SADDLE SCREWS:-

METRIC	ENGLISH
13404-C	13404-B (60) 76" LONG OVERALL
13405-C	13405-B (72) 88" LONG OVERALL
13406-C	13406-B (96) 112" LONG OVERALL
13407-C	13407-B (120) 136" LONG OVERALL
13412-D	13412-C (84) 100" LONG OVERALL
	18002-A (08) 124" LONG OVERALL

DWG. #330-A-8
Saddle Screw Reduction
G & L and Hypro Division

Parts List for DWG. #330-A-10

Milling Feed


Part Number	Part Name	Part Number	Part Name
5315	Bearing Retainer	7186-B	Clutch Gear - 27T
5444-B	Shifter Rod	7187-C	Clutch Gear - 24T
5567	Stud	7188-A	Spacer
5600-B	Feed Case	7189	Idler Shaft
5637-D	Gear	7190-A	Spacer
5639-B	Gear	7192-A	Spacer
5641-B	Rapid Traverse Clutch Drive	7193-B	Thrust Washer
5680	Cover	7194-A	Spacer
5684	Stud	7195-B	Shaft
5705-B	Shaft	7196-B	Bevel Gear - 22T
5708-B	Shaft	7197-C	Gear - 19T
5712-C	Shaft	7199	Spacer
5714-C	Shifter Shoe	7203	Retainer
5715-B	Shifter Shoe	7205	Retainer
5725	Shifter Lever	7214	Needle Bearing
5727	Pin	7215	Link
5728-B	Shifter Lever	7217	Idler Shaft
5729-A	Shoulder Screw	7219-A	Stud
5769	Coupling	7224	Shifter Shaft
6178-B	Idler Gear	7224-A	Shifter Shaft
7105-B	Feed Shaft	8155	Spacer
7106-A	Feed Gear - 19T	12245	Spacer
7107-A	Feed Gear	12270	Clutch Body
7108-A	Feed Gear - 25T	17269	Pin
7109-B	Feed Gear - 37T	19300	Feed Gear
7110-A	Feed Gear - 30T	19302	Spacer
7111-B	Shaft - 15T Gear	S-663	Cap Screw
7112-B	Feed Gear - 33T	S-666	Cap Screw
7113-A	Feed Gear - 40T	S-668	Cap Screw
7114-A	Feed Gear - 32T	S-833	Washer
7115-C	Feed Shaft	S-2119	Copper Disc.
7127	Thrust Washer	S-2704	Straight Pin
7128	Thrust Washer	S-2841	Straight Pin
7180-A	Feed Clutch Housing	S-7981	Spring
7181-A	Feed Clutch Housing	S-8502	Taper Pin
7182	Shaft 335	S-8518	Threaded Taper Pin
7183	Shaft	S-8928	Bushing
7184	Bracket	S-8929	Bushing
7185-B	Cluster Gear	S-8930	Bushing
		S-8931	Bushing

Parts List for DWG. #330-A-11

Transmission


Part Number	Part Name	Part Number	Part Name
3929	Collar	5682-A	Shifter
5398-A	Nut	5683-B	Shifter Arm
5404-A	Shifter Lever	5684	Stud
5405-E	Cover	5685-B	Shifter Shaft
5409-A	Cover	5686-A	Shifter Fork
5411-A	Cover	5687-A	Shifter
5413-A	Shifter Lever	5688	Shifter Lever
5414-E	Bearing Bracket	5689	Shaft
5422-B	Cover	5690	Shifter Arm
5424-E	Cover	5691-B	Trip Shaft
5601-C	Transmission Case	5692-B	Trip Shaft
5603-C	Clutch Rapid Traverse	5693-A	Shaft
5620	Spacer	5694	Shifter Lever
5624-A	Gear	5695	Shaft
5632-C	Pinion Shaft	5696	Shifter Lever
5641-B	Rapid Traverse Clutch Drive	5697	Pin
5643-C	Clutch	5698	Link
5645-A	Thrust Washer	5699-A	Shifter
5647-A	Thrust Washer	5700-G	Shifter Lever
5649-D	Gear	5701-D	Shaft
5651-D	Shaft	5702-A	Shifter Lever
5652-B	Cluster Gear	5703	Shifter Lever Pin
5653-B	Gear	5704-B	Shifter
5654-A	Spacer	5705-B	Shaft
5655	Spacer	5731	Shifter Lever Pin
5656-A	Coupling	7115-C	Feed Gear - 15T
5657-A	Gear	7116-B	Back Gear - 14T
5658	Shaft	7117-A	Back Gear - 42T
5659-B	Gear	7118-A	Feed Shaft
5660-B	Gear	7200	Spacer
5661	Clutch	7201	Thrust Washer
5662-A	Shaft	7202	Spacer
5663	Thrust Washer	7204-B	Gear - 32T
5664-A	Thrust Washer	7206	Spacer
5665-B	Bevel Gear	7207-B	Gear - 20T
5666-B	Bevel Gear	7208-D	Clutch Safety
5667-B	Bevel Gear	7209-D	Clutch Safety
5669-B	Gear	7210-A	Spring Plate
5670-B	Gear	7211-C	Clutch Nut
5672	Bevel Gear	7212-A	Clutch Pin
5673-A	Bevel Gear	7213-A	Shaft
5674-A	Shaft	7218-B	Clutch Driver Ring
5675-B	Gear	7220	Thrust Washer
5676-C	Gear	7221-C	Clutch Hub
5677-C	Shaft	7222-A	Coupling
5680	Cover	7225-A	Sleeve
5681	Gear Retainer	8166	Spacer

ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS






THIS FRICTION CLUTCH CAN BE EITHER CARLYLE-JOHNSON OR TWIN DISC.

Part Number	Part Name
37928	End Bracket
37929	Main Housing
37939	Cover
37940	Cover
37950	Mounting Block
37951	Shaft
37952	Worm Gear 30T
37953	Worm Gear 48T
37954	Shaft
37955	Shaft
37956	Oil Splasher
37957	Spacer
37958	Spacer
37959	Spacer
37960	Coupling
37961	Bearing Retainer
37962	Spacer
37963	Spacer
37964	Cover
37965	Cover
37966	Cover
37967	Spacer
37968	Cover
37970	Cover
37971	#825 Clutch
37994	Cable Housing
37995	Cover
37996	Terminal Insulator
37997	Boston Worm H L-1407
37998	Boston Worm H L-1076
S-2181	Key
S-2243	Key
S-2252	Key
S-2266	Key
S-2317	Key
S-7754-C	Oil Lever Plate



ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS





DWG. #340-A-46
Feed Box
G & L and Hypro Division



Parts List for DWG. #350-A-6

Table and Saddle

Part Number	Part Name	Part Number	Part Name	Part Number	Part Name
3643-B	Horizontal Rod End	6488	Taper Gib	10894-C	Table Clamp -
3644	Rod End Pin	6489	Taper Gib		Right (48x84)
4475	Clutch Ring	6930-E	Vernier Holder	10895	Table Clamp -
4802	Dial Clamp	6982	Vernier Bracket		Left (48x84)
4825-A	Dial Clamp Screw	8796	Micro Dial	10896	Table Screw (48x84)
5783-F	End Bracket	8797	Micro Dial	10930-D	Table (48x72)
5785	Cover	10850-C	Saddle 146" for	10932	Screw - Table 36x72
5786-A	Trip Dog		48x96 Table		and 48x72
5795-C	Lever	10851-D	Table	10950-A	Bracket - Clamp Lever
5796-A	Nut - Long Feed	10854	Table Clamp	10951-A	Bracket - Clamp Lever
5799-B	Clamp Stud		Left 48x96	10952	Pump Bracket
5802	Pivot Block	10855-A	Table Clamp	10953	Pump Lever
5803-C	Clamp Lever - Rear		Right 48x96	10954	Pull Rod
5804-C	Clamp Lever - Front	10856	Lever	10955	Collar
5805	Spacer	10857-A	Lever	10956	Screen
5806-A	Plate	10858-C	Shaft	10963	Pin
5807-A	Shaft	10859	Saddle Clamp - Front	14085	Wiper Felt
5808-A	Lever	10860	Saddle Clamp - Rear	14086	Wiper Plate
5809	Shaft	10861-A	Trip Lever	14216	Bushing
5810-B	Lever	10862-A	Lever	14258	Clutch
5813	Trip Lever Link	10863	Pin	15597	Coupling
5814-B	Trip Shaft	10864-C	Saddle 96" for	17724	Guard
5816	Dog - Adjusting		48x84 Table	17726	Disc.
5817	Dog - Rear	10865	Housing - Table	17729	Pivot Nut
5818	Dog - Front		Hand Feed	17744	Gib Retainer
5819-A	Shaft	10866	Cover	S-803	Washer
5820-B	Bevel Gear	10867-B	Gear	S-2066	Steel Ball
5821-I	Bevel Pinion	10868	Shaft	S-2116	Copper Disc.
5822-A	Shaft	10869-A	Bracket	S-2191	Round Ends Key
5828	Dial Clamp Pin	10870	Lever Table Clamp	S-2371	Square End Key
5846-A	Nut	10872-A	Link	S-2704	Straight Pin
5847	Shim	10873-A	Lever	S-2727	Straight Pin
5848	Shim	10874-A	Clamp Shaft	S-2779	Straight Pin
5849	Shoulder Screw	10875-A	Bracket	S-2805	Straight Pin
5850-A	Shifter Shaft	10876-A	Lever	S-2806	Straight Pin
5851	Coupling	10877	Link	S-2865	Straight Pin
5854	Wiper Plate	10878	Rod End Pin	S-7131	Table Vernier
5855	Felt Wiper	10879-A	Toggle		Body Assembly
5856	Wiper Plate	10880-A	Table Clamp	S-7919	Spring
5857	Felt Wiper	10881-B	Table Clamp	S-7930	Spring
5858	Wiper Plate	10882	Lever	S-7931	Spring
5859	Felt Wiper	10884	Table Screw	S-7938	Spring
5864-A	Shaft		48x96 Table	S-8050	Spring
5869-A	Filler Block	10888-E	Table 48x84	S-8209	Tee Bolt
5870-A	Filler Block	10890	Stud	S-8373	Bushing
5873-A	Table Clamp L. H.	10890-A	Stud	S-8501	Special - Dowel
5874-B	Table Clamp R. H.	10891	Shaft		Water Pump
5876	Taper Gib for	10892	Taper Gib -	S-8505	Taper Pin
	36x72 Table		Front (48x84)	S-8514	Threaded Taper Pin
5877	Taper Gib for	10893	Taper Gib -	S-8524	Slotted Hex. Nut
	36x72 Table		Rear (48x84)	S-8942	Bushing
5922	Shifter Shaft				



ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS




DWG. #350-A-6
Table and Saddle
G & L and Hypro Division


Parts List for DWG. #350-A-25-B

Table Drive

Part Number	Part Name
5661-2	Clutch
5902	Shifter Shoe
5918-3	Gear
5936	Shaft
10803	Guard
40420-2	Table Drive Housing
40421	Housing Cover
40422-1	Bearing Retainer
40423	Pump Bracket
40424	Rocker Arm
40425-1	Shaft
40426	Thrust Washer
40427	Thrust Washer
40428	Cam
40429	Cam Rod
40430-1	Spacer
40431	Spacer
40432	Bearing Retainer
40433-1	Bearing Retainer
40434	Gear
40435	Bevel Gear
40436	Bevel Gear
40437	Bevel Gear
40438-1	Bevel Gear
40439-1	Shaft
40440	Spacer
S-2905	Plug
S-8083	Spring
S-8946	Bushing
S-8951	Bushing



ALWAYS GIVE MACHINE SERIAL NUMBER




SERIAL NUMBER WHEN ORDERING PARTS


DWG. #350-A-25-B
Table Drive
G & L and Hypro Division

Part Number	Part Name	Part Number	Part Name
5398-A	Nut	13446	Cover
5412-B	Cover	13447	Spacer
5419-A	Shifter Lever	13448	Spacer
5420-A	Shifter Lever	13449	Spacer
5680	Cover	13450-B	Shifter
5703	Shifter Lever Pin	13451	Pin Retainer
10761-D	Cover	13458	Retaining Plate
13427-B	Gear	13459	Spacer
13428-B	Gear	13468	Shaft
13429-A	Gear	13486	Plate
13430-A	Bracket	13487	Pin
13432-A	Gear	13488-A	Crank
13433-A	Gear	13490-A	Lever
13435	Shaft	S-2219	Round Ends Key
13436-A	Gear	S-2701	Straight Pin
13437	Gear	S-2709	Straight Pin
13437-C	Gear	S-2710	Straight Pin
13438	Spacer	S-2783	Straight Pin
13440-B	Clutch	S-2848	Straight Pin
13441-B	Sleeve	S-8994	Bushing
13444-A	Bracket		


ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS



DWG. #350-A-27
 Saddle Screw Reduction
 G & L and Hypro Division



Part Number	Part Name
5207	Oil Tube - Ways
5242	Oil Plug
10452-A	Oil Pipe
17721	Oil Feed Sleeve
S-5423	Oil Pipe
S-9756	Oil Pump



5207
BEND UP ABOUT 10°

WICKING
DIA.

1/2" C SUNK HD
PIPE PLUG (2)

ALWAYS GIVE MACHINE **SERIAL NUMBER** WHEN ORDERING PARTS

1/8" DRILL

5242

1/2" TUBING

TUBING CLIP #A-760

PARKER HBB #5 1/16" TUBE

5242

1/4" PIPE COUPLING

5-5429 IRON PIPE






PUMP PARTS

DWG. #350-A-55
Headstock - Oil Piping
G & L and Hypro Division

Parts List for DWG. #350-A-84

Anti-Friction End Support Assembly


Part Number	Part Name	Part Number	Part Name
132	Clamp Lever	8448	Crank Shaft
676	Clamp Nut	8449	Equalizer
1914	Wiper Felt	8463	Vert. Screw Adj. Sleeve
4474	Clutch	8464	Adj. Sleeve Nut
4475	Clutch Ring	10309-5	Guide Block
4634	Gib	10310	Base Clamp
4945	Bevel Pinion	10311	Screw - Gib Retainer
4946	Bevel Gear	10312	Stop Stud
5477	Bearing Cover End	10313-A	Bevel Gear Driver
5480	Socket	10314-A	Bevel Pinion Driver
5484	Cover - Oil Chamber	10315-B	Bevel Pinion Bracket
5485	Shaft - Crank	10368-A	Shaft
5486	Rack Pinion	10755-C	End Bracket
5490	Wiper Plate	19556	Nut (Elev. Screw)
5493-1	Clamp Screw	32919	Housing - Nut
5498	Guide Block Clamp	32920-2	End Support Nut
5581	Sleeve	37317	Vernier Holder
5582	Cover	37404	End Support Column
5583	Nut	19-2753	Pin
5585	Spacer	19-2931	Pin
5774	Bushing	19-2934	Pin
5897	Key	19-6003	Vernier
6053-E	End Support Screw	S-811	Washer
6918	Adj. Vernier Body	S-812	Washer
6921-1	Spacer	S-2119	Copper Disc
7622	Vernier Adj. Knob	S-2207	Key
8243	Bevel Gear	S-2581	Tit Key
8431-3	Clamp Plate	S-2769	Pin
8432	Cover	S-2865	Straight Pin
8433	Cam Bracket - Upper	S-3512	Lock Wire
8434	Cam Bracket - Lower	S-3527	Lock Wire
8435	Cam	S-7425	Machine Handle
8438	Crank	S-7934	Spring
8439	Connecting Link	S-7973	Spring
8440	Clamp - Drawbar	S-8332	Bushing
8441	Equalizer Seat	S-8403	Nut
8442	Toggle	S-8409	Lock Nut
8443	Strap	S-8417	Lock Nut
8444	Toggle Sleeve	S-8505	Taper Pin
8445	Toggle Plate	S-8958	Bushing
8446	Clamp Pin		



DWG. #350-A-84
 Anti-Friction End Support Assembly
 G & L and Hypro Division

Part Number	Part Name
24954-A	Bracket
31635	Clutch Body
31636	Pin
33600-C	Control Station Panel
33600-D	Control Station Panel
33601	Cover
33601-B	Cover
33602-A	Shaft
33603	Nut
33604	Shaft
33605	Spacer
33606	Cover
33607	Spring Anchor
33608	Spring Anchor
33609	Clutch Housing
33610	Swivel Bracket
33612	Bushing
33614	Washer
33615	Washer
33616	Bushing
33624-B	Conduit
33624-C	Conduit
S-8096	Spring
S-8097	Extension Spring

ALWAYS GIVE MACHINE SERIAL NUMBER WHEN ORDERING PARTS





DWG. #SK-1702
Pendant Control
G & L and Hypro Division

Parts List for DWG. #SK-1736-1


Automatic Positioning Master Switch

Part Number	Part Name	Part Number	Part Name
37831-A	Spring Blade	37993-B	Contact Point
37833-A	Dial Actuator	38126	Bushing
37973	Cover	38127	Adjusting Screw
37974	Gasket	38128-A	Nut
37975	Indicator Cover	38194-2	Guard
37978-A	Push Rod	38206	Gasket
37979-A	Screw Pivot Shoulder	120719	Seal - Dial Actuator
37980	Pivot Bushing	120720	Retainer - Dial Actuator Seal
37981	Pivot Arm	S-2081	Steel Ball
37983	Mounting Plate	S-2935	Straight Pin
37985	Side Cover	S-3043	Straight Pin
37986	Actuator Pin	S-3054	Straight Pin
37987	Guide Screw	S-3147	Straight Pin
37988	Adjusting Clamp	S-7961	Spring
37989	Switch Actuator	S-7988	Spring
37990	Adjusting Rod	S-7998	Spring
37991	Terminal Block Housing	S-8075	Spring
37992-A	Indicator Housing		





DWG. #SK-1736-1
 Automatic Positioning
 Master Switch
 G & L and Hypro Division



Parts List for Drawing No. 150-40-75 & 150-40-76

Part No.	Description	Part No.	Description	Part No.	Description	Part No.	Description	Part No.	Description	Part No.	Description
600-01603-00	Spacer - Motor Shaft	38318	Bearing Locknut	019-670	Drilled Hex Screw	38362-1	Cover	19-8010	Spring	38376	Spacer
600-01604-00	Motor Shaft	38342-4	Spindle	19-676	Drilled Hex Screw	38359	Cover	19-40831	Oilite Bushing	38423	Spacer
600-01466-00	Stator - Rotor Unit - 50 c.p.s.	38344-1	Drawbolt Driver	19-850-2	Hardened Washer	38384-1	Shifter	13999-10	Spindle	38540	Motor Housing
109-00391-05	Spacer	38352-3	Spindle Nut	19-2257	Round End Key	38368	Clutch Driver	38361-01	Spacer	38541	End Housing
1668-3	Key	38352-4	Spindle Nut	19-2282	Round End Key	38365-1	Bearing Retainer	38308	Spacer - Bearing - 5" Spindle Machine	38542-01	Cover
1668-4	Key	38353	Gear - 18T	19-2292	Round End Key	38369	Clutch Shaft	38309	Spacer - Pre-Load - 5" Spindle Machine	38543	Cover
9718-2	Bearing Retainer	38354	Gear - 42T	19-3214	Straight Pin	38370	Bearing Retainer	38311	Spacer - Bearing - 5" Spindle Machine	38544	Clutch Shaft
14143	Bearing Retainer Plate	38355	Gear - 22T	19-3874	Tapped Taper Pin	38372-1	Shaft	38312	Bearing Locknut	38547	Solenoid Bracket
10580-9	Main Ram	38356	Gear - 48T	19-7233	Bushing	38372-4	Shaft	38315	Spacer - Pre-Load - 4" Spindle Machine	38548	End Housing
11987-4	Main Ram	38357	Thrust Collar	19-7971	Compression Spring	38374	Idle Shaft	38316	Spacer - Bearing - 4" Spindle Machine	38551	Shifter Lever
						38375	Bushing	38317	Spacer - 4" Spindle Machine		

GIDDINGS & LEWIS MACHINE TOOL COMPANY
A DIVISION OF GIDDINGS & LEWIS, INC.

TITLE **POWER OPERATED DRAWBOLT ARRANGEMENT**

DRAWING NUMBER **150-40-75**
150-40-76