


Faycott

Division of *WCI* White Consolidated Industries, Inc.

366



Reid

**HYD and HYD/DF HYDRAULIC
SURFACE GRINDERS**

INSTALLATION & START-UP INSTRUCTIONS

REID-O-MATIC
618 HYT, HYD and HYD/DF

INSTALLATION & START UP INSTRUCTIONS

GENERAL

Your REID grinder was given a thorough inspection prior to shipment. All machine elements were correctly aligned and adjusted. After inspection, the hydraulic oil was removed from the reservoir. All critical components were properly blocked and a protective coating was applied to all finished surfaces. The machine was skidded, completely covered and then crated for shipment.

INSTALLATION PROCEDURE

1. Remove the protective crating and covers from the machine.
2. Examine the machine to insure that no damage has occurred during shipment. Notify both your carrier and your local REID representative immediately upon discovery of any damages.
3. Remove all boxes and extra material from the skid. Check the contents against the shipping list enclosed. Notify your local REID representative if any discrepancies exist.
4. Place the machine on a firm foundation.

NOTE: We advise the use of vibration isolators for the following conditions:

- a. The surface finish must be accurate.
 - b. Unevenness of floor where accurate shimming is impossible.
 - c. Where neighboring machines might yield a tremendous amount of vibration or shock.
5. Remove the wooden blocks used to brace the moving components.
 6. Using a clean petroleum solvent and clean, lint-free rags, remove all protective coating from the finished surfaces. Apply a light coat of machine oil to the cleaned surfaces.
 7. Fill the hydraulic reservoir with clean oil. We recommend MOBIL DTE LIGHT or an equivalent.
 8. Check the lubrication reservoir, if required add clean oil. We recommend MOBIL VACTRA NO. 2 or an equivalent. Pull plunger upward for immediate distribution of oil. This system is designed to automatically distribute a metered amount of oil every 27.7 minutes. Consult the Lubrication Section of this manual for more detailed information.

START UP PROCEDURE

1. Connect the main power lines. Refer to the electrical diagram provided with your machine.
2. With all functions in the manual (hand) mode, check for proper rotation of the motors. (NOTE: All motors were phased before shipment. Only the main power line should be adjusted to correct motor rotation.)
 - A. Press HYDRAULIC START.
 - B. Compare the rotation of the hydraulic pump motor with the arrow located on the top.
 - C. Press SPINDLE START.
 - D. Check to see that the grinding wheel is rotating in a clockwise motion.
 - E. If improper rotation is observed, STOP IMMEDIATELY, reverse two phases of the three phase connection at the main disconnect.
 - F. Repeat above procedure.
3. Due to settling of the lubricant in the Spindle during transportation or extended idle periods, the following start up procedure must be adhered to:
 - A. JOG three (3) or four (4) times for one (1) minute.
 - B. Run for ten (10) minutes, shut down and allow to cool for one (1) hour.
 - C. Run again for ten (10) minutes and check with pyrometer. If temperatures exceed 120° F shut down and allow to cool for one (1) hour.
 - D. Repeat Step C.
 - E. If Spindle continues to operate at elevated temperatures after several cycles, stop running and refer to the Spindle Section of your manual. Notify your local REID representative immediately if operating temperature exceeds acceptable level.

START UP PROCEDURE

4. Your new REID-O-MATIC was adjusted prior to shipment to assure the proper operation of the various hydraulic components. Before operation of the power modes, follow the procedure below:

A. TABLE

1. Rotate the TABLE SPEED CONTROL KNOB to the OFF position by turning clockwise.
2. Manually traverse the Table to the center position.
3. Position the TABLE LIMIT DOGS three (3) to four (4) inches either side of the TABLE REVERSING SWITCH.
4. Press HYDRAULIC START button.
5. Position TABLE MODE LEVER to POWER.
6. Slowly turn TABLE SPEED CONTROL KNOB counterclockwise until the table begins to move.
7. Increase table speed gradually for 15 minutes of operation.
8. After 15 minutes, the dogs can be set for 20 inches of stroke. Overtravel in table will increase slightly as oil in the system warms up. If, at this period, maximum recommended length is used, overtravel will increase to full limit of the cylinder stroke and a thumping may occur. CAUTION: If so, relocate TABLE LIMIT DOGS closer together to avoid damage to the cylinder.

NOTE: Do not reset end play on cylinder rods, thermal expansion must be considered. End play is set for approximately .010" to .015" after oil in system has become thoroughly heated.

9. STOP Table by repositioning TABLE MODE LEVER to HAND.

B. CROSS SLIDE (MODELS HYD & HYD/DF)

1. Position CROSS SLIDE LIMIT DOGS three (3) to four (4) inches apart.

START UP PROCEDURE

2. Start Table by moving TABLE MODE LEVER to POWER.
3. Adjust Table speed to a moderate rate.
4. Rotate INCREMENT KNOB to the middle range.
5. Place the CROSS SLIDE TRAVERSE LEVER in FEED (Increment).
6. Shift CROSS SLIDE MODE LEVER to POWER.
7. Note that the cross feed increment will be at each reversal of the table.
8. Cycle for five (5) minutes and observe cross feed reversals.

NOTE: A small amount of end play on the nut which fastens piston rod to Cross Slide is necessary. This avoids deflection in rod which, if excessive, could cause damage to seals and bearings.

9. Stop Table.
10. Slowly rotate CROSS SLIDE TRAVERSE LEVER clockwise to observe increasing rate of Cross Slide speed through DRESS and RAPID positions.
11. Return the CROSS SLIDE TRAVERSE LEVER back to the FEED (Increment) position. Check to make sure it is firmly in this position.

C. AUTOMATIC DOWNFEED

1. It is not necessary to test cycle the Automatic Down-feed mode on your REID grinder. However, before using this feature, the operator should become familiar with the controls. Refer to the "Explanation of Controls" and "Operating Instruction" sections of this manual.

EXPLANATION OF CONTROLS

REID-O-MATIC ALL HYDRAULIC

① CROSS FEED
HANDWHEEL

● TABLE
HANDWHEEL

③ TABLE LEVER
HAND-POWER

④ CROSS FEED
LIMIT DOGS

⑤ RAPID TRAVERSE,
WHEELDRESS LEVER

⑥ CROSS FEED
INCREMENT KNOB

⑦ CROSS SLIDE
HAND, POWER
LEVER

⑧ TABLE
SPEED CONTROL

● ⑨ OIL LEVEL
SIGHT GAUGES

⑩ TABLE LIMIT
DOGS (HAND)

⑪ TABLE LIMIT
& REVERSING
SWITCH (POWER)


⑫ SPINDLE,
HYDRAULIC,
ON-OFF

⑬ HEAD ELEVATING
HANDWHEEL

⑭ HEAD ELEVATING
HANDWHEEL
FRICTION BRAKE

⑮ ONE SHOT
LUBRICATING, (HAND)

● ⑯ HYDRAULIC
TANK DRAIN



REID-O-MATIC
618 HYT, HYD and HYD/DF

EXPLANATION OF CONTROLS

TABLE CONTROLS

TABLE HANDWHEEL

Located in the front, left side of the machine and used for manual operation of the Table. Clockwise rotation will traverse the Table to the right.

TABLE SPEED CONTROL KNOB

Located on the front of the machine below the Cross Slide Mode Lever. Table speed is adjustable from approximately 10 to 140 surface feet per minute.

TABLE MODE LEVER

Located on the top of the Cross Slide above the Table Handwheel. Shifting the lever into the MANUAL position mechanically engages the handwheel assembly and electrically disconnects the Table Reversing Switch for manual operation. Shifting the lever to the POWER position reverses the procedure for power operation.

TABLE LIMIT DOGS

Located on the front face of the Table and used only in the power mode for infinite adjustment of the table stroke (20 inch maximum). In the manual mode, the reversing switch has been de-energized and the table dogs are insignificant.

CROSS SLIDE CONTROLS

CROSS SLIDE HANDWHEEL

Located on the front of the machine between the table and elevating handwheels and used for manual operation. Turn clockwise for inward motion, i.e., away from the operator.

CROSS SLIDE MODE LEVER

Located on the front of the machine below the Cross Slide Handwheel. Shifting the lever into the MANUAL position mechanically engages the Cross Slide Half Nut and electrically disconnects the Increment Valve for manual operation. Shifting the lever in the NEUTRAL or POWER position reverses this procedure for power operation. The lever should be shifted to

CROSS SLIDE CONTROLS

CROSS SLIDE MODE LEVER (Cont'd)

the NEUTRAL position when the Cross Slide is locked down.

SPECIAL NOTE: WHEN ENGAGING THE HANDWHEEL FOR MANUAL OPERATION, USE CAUTION IN THE ENGAGEMENT OF HALF NUT AND SCREW. SLIGHT ROTATION OF THE HANDWHEEL MAY BE NECESSARY.

CROSS SLIDE TRAVERSE LEVER

Located on the Feed Panel to the left of the Cross Slide Mode Lever and allows operation of the Cross Slide in either the FEED, DRESS or RAPID modes. In the FEED mode the cross slide will increment at each table reversal. The DRESS mode allows the operator to true the grinding wheel from the table. (This mode is usually not used in conjunction with table travel.) The RAPID mode allows quick positioning and set-up.

INCREMENT KNOB

Located below the Cross Slide Mode Lever and allows adjustment the magnitude of increment. Smaller increments are realized by turning the Knob in a clockwise rotation. The typical increment range is .005" to .250" per Table reversal.

CROSS SLIDE LIMIT DOGS

Located on the left side of the machine on the base and used only in the power mode for infinite adjustment of the cross slide stroke (7 inches maximum). In the manual mode, the Cross Slide Reversing Switch has been de-energized and the Cross Slide Dogs are insignificant.

SPECIAL NOTE: Model HYT, having hydraulic power only to the Table, is not equipped with the Cross Slide Mode Lever, Cross Slide Traverse Lever, Increment Adjustment nor Cross Slide Limit Dogs.

VERTICAL CONTROLS

DOWNFEED (ELEVATING) HANDWHEEL

Located on the front, right side of the machine and used for manual operation of the vertical traverse. Clockwise rotation will traverse Head (Grinding Wheel) downwards.

AUTOMATIC DOWNFEED HANDWHEEL CONTROLS

DOWNFEED INCREMENT ADJUSTMENT

Located on the Auto Downfeed Unit, refer to Item 40 on the exploded view drawing in this manual. By loosening the Knob and raising or lowering it, the downfeed increment is reduced or enlarged. A Pointer and Scale are provided for this adjustment. Tighten at desired scale reading.

DOWNFEED RANGE ADJUSTMENT


The range of downfeed is adjusted by rotating the Graduated Rim, Reference No. 27 on the exploded view drawing of the Auto Downfeed Unit, clockwise a direct reading amount from the shut-off point (zero).

ENGAGEMENT KNOB


Reference No. 33 on the exploded view drawing of the Auto Downfeed Unit. Loosening this knob disengages the downfeed mechanism from the Handwheel. This permits observation of the mechanism without actual downfeed and also permits manual feeding without changing other controls or switches. Tightening this Knob mechanically engages the downfeed.

HANDWHEEL DRAG ADJUSTMENT


Reference No. 20 on the exploded view drawing of the Auto Downfeed Unit. This Knob provides control of the handwheel rotation, "feel" or "torque" and is used with the Auto Downfeed mechanism to prevent over-spin of the handwheel when incrementing.



BASIC MACHINE ARRANGEMENT



**COLUMN SHOWING HEAD
AND MOTORIZED SPINDLE ARRANGEMENT**



MIDDLE SECTION...SHOWING HEAD ELEVATING ARRANGEMENT & HYDRAULIC CROSS FEED

* See Drawing No. 473830 effective Machine S/N 21781. For machines with Micrometer Fine Elevating Feed, refer to separate section.

** See Drawing No. 373934 for Model HYD/DF machines S/N 21960, 21981 and 22069 and after. Drawing No. 373934 also applies for Model HYD with Power Vertical Traverse.

ELEVATING HANDWHEEL ASSEMBLY
DRAWING NO. 473830
EFFECTIVE MACHINE S/N 21781

| <u>Part No.</u> | <u>Description</u> | <u>Quantity</u> |
|-----------------|--|-----------------|
| 170017 | Bearing Cap | 1 |
| 170038 | Bearing | 1 |
| 170055 | Handle | 1 |
| 170067 | Spring | 1 |
| 170586 | Lock for Cross Shaft Crank | 1 |
| 170812 | Adjusting Screw for Elevating Brake | 1 |
| 170905 | Nylok Round HD 1/4 - 20P x 3/4 | 1 |
| 172632 | Washer 1/4 x 1 x 1/8 | 1 |
| 173825 | Clamp Washer | 2 |
| 173826 | Truarc Ret. Ring 5108-300 | 1 |
| 173827 | Thumb Screw | 1 |
| 173828 | Nyloc Set Screw 1/4 - 20 x 5/8 Oval Point | 2 |
| 173829 | Hole Plug | 1 |
| 173844 | Clamp Button | 2 |
| 270009 | Shaft | 1 |
| 271411 | Bracket Elevating Vernier | 1 |
| 273833 | Ring Clamp | 1 |
| 370155 | Locking Case for Head Elevation Shaft | 1 |
| 371410 | Elevating Vernier | 1 |
| 373831 | Handwheel - Vertical Travel | 1 |
| 373832 | Graduated Rim .050 | 1 |
| 472617 | Housing | 1 |

[illegible]


GEAR HOUSING ASSEMBLY
 FOR MODEL HYD/DF SERIAL NOS. 21960, 21981 and 22069 and after.
 AND FOR ALL OTHER MODELS WITH POWER VERTICAL TRAVERSE
 DRAWING NO. 373934 - ASSEMBLY NO. 973946

| <u>PART NO.</u> | <u>DESCRIPTION</u> | <u>QUANTITY</u> |
|-----------------|-------------------------------|-----------------|
| 173909 | Bearing Spacer - Inner | 1 |
| 173910 | Bearing Spacer - Outer | 1 |
| 173911 | Locknut | 1 |
| 173912 | Bearing Cup | 1 |
| 373907 | Bevel Gear - 16 Tooth | 1 |
| 373908 | Bearing Cartridge | 1 |
| 373914 | Elevating Shaft | 1 |
| 373915 | Pivot Plate (974040 & 973945) | 1 |
| 373932 | Bevel Gear - 40 Tooth | 1 |
| 373933 | Oil Pan | 1 |
| 473892 | Bevel Gear Housing | 1 |
| 800770 | Ball Bearing | 1 Pair |
| 800771 | Roller Bearing | 2 |
| 800778 | Locknut | 1 |
| 800781 | Key 3/16 x 15/16 | 2 |
| 800783 | Retaining Ring | 1 |
| 973931 | Elevating Screw & Nut | 1 |


373934


| ITEM | RECD | MAT | DESCRIPTION |
|------|------|-----|-------------|
| | | | |

973931 ASSEMBLY OF
373930 - SCREW
373882 - NUT



NOV 25 1980


| DATE | | | DRAWN | CHECKED | MATERIAL | HARDNESS | TITLE |
|-------------------------------------|--|--|----------|--|----------|----------|--------------|
| BY | | | TH | TH | | | GEAR HOUSING |
| WAS | | | DATE | DATE | PATT. | | ASSEMBLY |
| | | | 9-24-79 | 1-8-80 | NO. | | |
| CHANGES | | | LIST NO. | REID BROS. COMPANY | | | SHEET |
| TOLERANCE | | | SCALE | One of the White Consolidated Industries | | | OF |
| COMMON FRACTIONS $\pm \frac{1}{32}$ | | | FULL | DEXTER  MAINE | | | 373934 |



CROSS SLIDE...SHOWING CROSS FEED TABLE DRIVE, AND CROSS SLIDE LIMIT SWITCH ARRANGEMENT

Effective S/N 21781 Refer
Drawing No. 473806, Cross
Traverse Assembly, 10 P A
HYD/DF, HYD when ordering
parts.

| FEW | MOST | MAY | DESCRIPTION |
|-----|------|-----|-------------|
|-----|------|-----|-------------|




SEE 379021 FOR
ANNOUNCED ASSEMBLY

279764

373790

275900



- ETJONE (C)

173815 (2)

1954

—27301

-172619

— 10050 —

673807

- 175775 (X)

178733 (B)

- 173648

001573

- 473789

Y-170030

170000
170000

-178940

171050

873809-

171026 -

273013 -

-1700EG (R)

-375808

-475810

-17109E

-171093

[illegible]

473806

473806

CROSS TRAVERSE ASSEMBLY
DRAWING NO. 473806
MODELS HYD & HYD/DF
EFFECTIVE SERIAL NO. 21781



| <u>Part No.</u> | <u>Description</u> | <u>Quantity</u> |
|-----------------|---------------------------|-----------------|
| 100804 (800235) | Retaining Ring | 2 |
| 170026 | Bushing | 2 |
| 170030 | Compression Sleeve | 1 |
| 170031 | Compression Nut | 1 |
| 170271 | Spring | 1 |
| 170370 | Ball Handle | 1 |
| 170381 | Str. Adapter | 1 |
| 171026 | Cam | 1 |
| 171092 | Adjusting Screw | 1 |
| 171093 | Adjusting Frame | 1 |
| 171094 | Arm | 1 |
| 172619 (801903) | Bearing | 1 |
| 172732 | Hose Clamp | 2 |
| 172939 | Plunger | 1 |
| 172940 | Micrometer Switch | 1 |
| 173648 (801985) | Bearing | 1 |
| 173775 | Boot | 2 |
| 173815 | Rubber Channel | 2 |
| 173885 | Switch Cam | 1 |
| 174058 | Bracket (Replaces 171310) | 1 |
| *273766 | Vernier | 1 |
| *273788 | Bearing Adapter | 1 |
| *273789 | Bearing Cap | 1 |
| 273796 | Boot Ring | 2 |
| 273800 | Cover | 1 |
| 273809 | Half Nut | 1 |
| 273810 | Half Nut Pin | 1 |
| 273811 | Bearing Adapter | 1 |
| 273812 | Boot Flange | 2 |
| 273813 | Shaft - Cam | 1 |
| 273814 | Cover | 1 |
| 373790 | Cross Feed - Screw | 1 |
| 373808 | Nut Bracket | 1 |
| *373821 | Cross Feed Handwheel | 1 |
| 673803 | Cross Slide | 1 |
| 673807 | Mid-Section | 1 |

*For machines with Micrometer Find Cross Feed refer to Drawing No. 473682.


CROSS FEED HANDWHEEL ASSEMBLY
DRAWING NO. 373821
EFFECTIVE MACHINE S/N 21781

| <u>Part No.</u> | <u>Description</u> | <u>Quantity</u> |
|-----------------|--------------------------------|-----------------|
| 170055 | Handle | 1 |
| 170905 | Nylok Round HD 1/4 - 20P x 3/4 | 1 |
| 172632 | Washer 1/4 x 1 x 1/8 | 1 |
| 173648 | Ball Bearing N.D.H. 455503X1C | 1 |
| 173825 | Clamp Washer | 1 |
| 173826 | Truarc Ret. Ring 5108-300 | 1 |
| 173827 | Thumb Screw | 1 |
| 173828 | Nyloc Set Screw 1/4 - 20 x 5/8 | |
| | Oval Point | 2 |
| 173829 | Hole Plug | 1 |
| 173844 | Clamp Button | 2 |
| 273766 | Cross Feed Vernier | 1 |
| 273788 | Bearing Adapter | 1 |
| 273789 | Bearing Cap | 1 |
| 273824 | Clamp Ring | 1 |
| 373822 | Handwheel - Cross Traverse | 1 |
| 373823 | Graduated Rim - .100 | 1 |
| 972557 | Soc. HD Screw 10-32 x 1/2 | 3 |
| 972625 | Key 3/16 x 3/16 x 11/16 | 1 |
| 972849 | Soc. HD Screw 10-32 x 3/8 | 3 |





Effective-S/N 21781



NOTE: Refer to Drawing No. 473682 for machines equipped with MICROMETER FINE CROSS FEED.



| | | | | | | | | |
|--|----|-----|-----------------|---|-------------|----|----------|---|
| DRAWN 711 | | | CHECKED 711 | | MATERIAL | | HARDNESS | TITLE HANDWHEEL ASSEMBLY CROSS TRAVERSE |
| DATE | BY | WAS | DATE 7-14-78 | DATE 10-29-78 | PART NO. | | | |
| CHANGES | | | LIST NO. | COMPANY (One of the White Consolidated Industries) | | | SHEET | 373821 |
| TOLERANCE COMMON FRACTIONS $\pm \frac{1}{16}$ | | | | | | | | |
| SCALE FULL | | | DEXTER | MAINE | | OF | | |



| REVISIONS | | | | REVISIONS | | | | REVISIONS | | | | REVISIONS | | | |
|-----------|------|----|-------------|-----------|------|----|-------------|-----------|------|----|-------------|-----------|------|----|-------------|
| NO. | DATE | BY | DESCRIPTION | NO. | DATE | BY | DESCRIPTION | NO. | DATE | BY | DESCRIPTION | NO. | DATE | BY | DESCRIPTION |
| 1 | | | | 2 | | | | 3 | | | | 4 | | | |

| | | | | | | | | | | | | | | | |
|------------------|--|-----|--|------|--|----|--|------|--|----|--|------|--|----|--|
| ARTI BY | | WAS | | DATE | | BY | | DATE | | BY | | DATE | | BY | |
| CHANGES | | | | | | | | | | | | | | | |
| TOLERANCES | | | | | | | | | | | | | | | |
| COMMON FRACTIONS | | | | | | | | | | | | | | | |

| | | | | | | | | | | | |
|---------------------|--|--|--|--------------|--|--|--|----------------|--|--|--|
| WELD BRO'S. COMPANY | | | | INCORPORATED | | | | NEW YORK, N.Y. | | | |
| 272704 | | | | 272704 | | | | 272704 | | | |
| DEXTER | | | | DEXTER | | | | DEXTER | | | |
| NAME | | | | NAME | | | | NAME | | | |

47584

INCREMENT VALVE ASSEMBLY
 REID MODEL: HYD HYD/DF
 ASSEMBLY LIST NO. 973870
 DRAWING NO. 473869

| <u>Part No.</u> | <u>Quantity</u> | <u>Description</u> |
|-----------------|-----------------|---|
| 170020 | 3 | 1/8 NPT Pipe Plug |
| 170021 | 1 | 1/4 NPT Pipe Plug |
| 171083 | 1 | Adjusting Needle |
| 171102 | 1 | "O" Ring |
| 171103 | 1 | "O" Ring |
| 171104 | 1 | "O" Ring |
| 171105 | 1 | Plug |
| 171201 | 1 | Adjusting Screw |
| 171202 | 1 | Knob |
| 171203 | 1 | Barrel |
| 171205 | 1 | Lever |
| 171206 | 1 | Screw |
| 173088 | 1 | Straight Fitting - 5/16 Tube to 1/4 NPT |
| 173089 | 1 | Elbow Fitting - 5/16 Tube to 1/8 NPT |
| 173090 | 2 | Elbow Fitting - 5/16 Tube to 1/4 NPT |
| 173871 | 1 | Nylon Shoe - 1/8 Diameter x 1/8 Long |
| 271068 | 1 | Piston - Fitted to Body 371067 used as an assembly. |
| 271076 | 1 | Spool - Fitted to Body 371067 used as an assembly. |
| 271079 | 1 | Front |
| 271080 | 1 | Rear Plate |
| 271081 | 2 | Gasket |
| 271085 | 1 | Stem |
| 371067 | 1 | Body |
| 801177 | 2 | Brass Shoe - 1/8 Diameter x 1/8 Long |
| 972552 | 1 | #10-32 x 1/4 Soc. Set Screw - Cup Point |
| 972633 | 1 | Dowel Pin - 3/8 x 3 |
| 972867 | 4 | 5/16-18 x 7/8 Soc. Cap Screw |
| 972878 | 8 | 3/8-16 x 7/8 Soc. Cap Screw |
| 972958 | 1 | #10-32 x 3/4 Soc. Set Screw - Cup Point |
| 973006 | 2 | #10-32 x 3/8 Soc. Set Screw - Cup Point |





TABLE ARRANGEMENT



**CROSS SLIDE...
SHOWING TABLE HANDWHEEL ASSY...
CROSS SLIDE LOCK ASSY...
TABLE HYDRAULIC DRIVE CYLINDER**


EFFECTIVE ON SERIAL NO. 16744

AUTO DOWNFEED UNIT ASSEMBLY

AUTO DOWNFEED UNIT ASSEMBLY

For Machine S/N's Up To 22068 but

Excluding S/N's 21960 and 21981



| REF. NO. | PART NO. | DESCRIPTION | REF. NO. | PART NO. | DESCRIPTION |
|----------|----------|--------------------|----------|----------|-----------------------|
| 1 | 271534 | Shaft | 21 | 171529 | Brake Shoe |
| 2 | 471554 | Housing | 22 | 170055 | Handle |
| 3 | 171531 | Bearing | 23 | -- | Washer |
| 4 | 171932 | Clip (3 req'd) | 24 | 271540 | Wheel Rim |
| 5 | 471563 | Mounting Brkt. | 25 | 172715 | Clamp Screw |
| 6 | 271564 | Lock Case Brkt. | 26 | 172714 | Clamp |
| 7 | 271541 | Clutch Housing | 27 | 271542 | Graduated Rim |
| 8 | 171530 | Cam Clutch | 28 | 371539 | Handwheel |
| 9 | 171532 | Bearing | 29 | 171545 | Guide Roller |
| 10 | 271535 | Actuating Yoke | 30 | 171536 | Yoke Extension |
| 11 | 171544 | Guide Fork | 31 | 371555 | Guard |
| 12 | 171548 | Locknut | 32 | 171550 | Graduation Strip |
| 13 | 171547 | Stop for Downfeed | 33 | 171552 | Thumb Screw |
| 14 | 171533 | Hydraulic Cylinder | 34 | -- | Key |
| 15 | 171549 | Pointer | 35 | 171272 | Switch |
| 16 | 171546 | Roller Shaft Screw | 36 | 171551 | Switch Mounting Plate |
| 17 | 271537 | Yoke Retainer | 37 | 171273 | Switch |
| 18 | 170283 | Lock Case | 38 | 371543 | Vernier Pointer |
| 19 | 170125 | Spring | 39 | 100116 | Sleeve |
| 20 | 170285 | Thumb Screw | 40 | 100122 | Knob |
| | | | 41 | -- | Key |
| | | | 42 | 171700 | Stop Cam |

Assembly No. 971695

AUTO DOWNFEED MECHANISM
 EFFECTIVE MACHINE S/N 21960
 DRAWING NO. 474001
 ASSEMBLY NO. 974022

| <u>Part No.</u> | <u>Description</u> | <u>Quantity</u> |
|-----------------|----------------------------|-----------------|
| 170038 (801947) | Bearing | 1 |
| 170067 | Spring | 1 |
| 170159 | Hose Clamp | 2 |
| 170161 | Air Cock | 1 |
| 170586 | Drag Shoe | 1 |
| 170812 | Knob | 1 |
| 171195 | Miniature Microswitch N.O. | 1 |
| 171701 | Table Reversing Switch | 1 |
| 171272 | Miniature Microswitch N.O. | 1 |
| 171273 | Miniature Microswitch N.C. | 1 |
| 171530 | Cam Clutch | 1 |
| 171532 | Bearing | 1 |
| 171533 | Hydraulic Cylinder | 1 |
| 171545 | Guide Roll | 1 |
| 171546 | Roller Shaft Screw | 1 |
| 171548 | Locknut | 1 |
| 173520 | Protection Spring | 2 |
| 173783 | Female Plug | 1 |
| 173871 | Nylon Shoe | 1 |
| 174005 | Bearing Housing | 1 |
| 174006 | Clutch Housing | 1 |
| 174007 | Bearing Cap | 1 |
| 174008 | Switch Mount | 1 |
| 174009 | Lever | 1 |
| 174010 | Rod Clevis | 1 |
| 174011 | Knob | 1 |
| 174012 | Cord Bracket | 1 |
| 174013 | Adjusting Rod | 1 |
| 174014 | Adjusting Screw | 1 |
| 174015 | Stop Block | 1 |
| 174016 | Lower Guide | 1 |
| 174017 | Actuator | 1 |
| 174021 | Graduated Plate | 1 |
| 174052 | Cam | 1 |
| 174108 | Clamp Knob | 1 |
| 271998 | Switch Bracket | 1 |
| 273523 | Bracket | 1 |
| 273524 | Bracket | 1 |
| 274107 | Actuating Yoke | 1 |
| 371410 | Vernier Pointer | 1 |
| 374003 | Vernier Bracket | 1 |
| 374004 | Switch Bracket | 1 |

AUTO DOWNFEED MECHANISM
 EFFECTIVE MACHINE S/N 21960
 DRAWING NO. 474001
 ASSEMBLY NO. 974022

| <u>Part No.</u> | <u>Description</u> | <u>Quantity</u> |
|-----------------|--------------------------------|-----------------|
| 374018 | Upper Guide | 1 |
| 374019 | Elevating Shaft | 1 |
| 374020 | Cover | 1 |
| 472617 | Housing | 1 |
| 474002 | Mounting Bracket | 1 |
| 773081 | 5/16 Nyla Flow Tubing | 11 |
| 800784 | Retaining Ring | 1 |
| 801348 | Retaining Ring | 1 |
| 801349 | Roll pin (3/32 x 1/2) | 1 |
| 801350 | Drive Screw (P-K #4 x 3/16"U") | 1 |
| 801351 | Spring Plunger | 1 |
| 801352 | Retaining Ring | 1 |
| 801353 | Spring | 1 |
| 801716 | Red. Bushing 3/8 x 1/4 | 1 |
| 802011 | Bearing | 1 |
| 802762 | Cable Clamp | 1 |
| 973428 | 1/4 Tube Elbow | 2 |
| 973429 | 1/8 Tube Elbow | 4 |
| 973430 | 1/4 Tee F-M-F | 1 |
| 973431 | 1/8 Str. Connector | 2 |
| 974117 | Solenoid Valve Assy. | 1 |
| 83-S-1835 | Spring | * |
| 83-S-1897 | Miniature Microswitch N.C. | 2 |

*Part of 83-S-1897

474001

ITEM REQD DESCRIPTION




NOTE

- V 171425 (1) NO 171135 (2) NC 171273

THESE SWITCHES ARE USED IN PLACE OF ONES SHOWN ON
MACHINE SERIAL NO'S. - 21960, 21981

AUTO DOWNFEEED ASSEMBLY

For Machine S/N 21960, 21981 and
22069 and after

973850
HANDWHEEL
ASSEMBLY

Assembly No. 974022

DC 171425

| DATE | BY | WAS | DRAWN T.M. | CHECKED T.M. | MATERIAL P21 | HARDNESS | TITLE |
|------------------|----|-----|---------------|-----------------|-----------------|----------|---|
| | | | 1-17-80 | | 1-21-80 | | AUTOMATIC DOWNFEEED MECHANISM - HYD/OA |
| CHANGES | | | 174002 | REID | COMPANY | SHEET | |
| TOLERANCE | | | EXACT | DEXTER | MAINE | OF | 474001 |
| COMMON FRACTIONS | | | 1/2 | FULL | | | |


JAN 23 1981

HYDRAULICS



373769

HYDRAULIC SEQUENCE OF OPERATIONS


1. HYDRAULIC START PUSHBUTTON STARTS DUAL HYDRAULIC PUMP (8) WHICH PRODUCES 4 GPM AND 1 GPM. WITH TABLE STOPPED, 4 GPM OUTPUT DOES NOT DEVELOP ADJUSTED PRESSURE DUE TO ORIFICE (24) CONTROL OF VENT OF RELIEF VALVE (12).
2. HAND TABLE TRAVERSE. WITH TABLE LEVER IN HAND POSITION, PRESSURE IS REMOVED FROM BOTH SIDES OF TABLE CYLINDER DUE TO SPRING CENTERING OF PILOT VALVE (14) AND TABLE REVERSING VALVE (14).
3. HAND CROSS TRAVERSE. WITH CROSS FEED SELECTOR LEVER IN HAND POSITION, PRESSURE IS REMOVED FROM BOTH SIDES OF CROSS TRAVERSE CYLINDER DUE TO SPRING CENTERING OF CROSS TRAVERSE DIRECTION VALVE (18).
4. HYDRAULIC TABLE TRAVERSE. WITH TABLE LEVER IN POWER POSITION, PILOT PRESSURE FROM 1GPM PUMP ACTUATES TABLE REVERSING VALVE DIRECTING OUTPUT OF 4 GPM PUMP TO TABLE TRAVERSE CYLINDER. ORIFICE (24) CAUSES RELIEF VALVE (12) TO INCREASE PRESSURE AND TRAVERSE TABLE EITHER LEFT OR RIGHT UNTIL SWITCH IS TRIPPED TO REVERSE DIRECTION. TABLE SPEED IS CONTROLLED BY THE FLOW CONTROL VALVE (13).
5. HYDRAULIC CROSS TRAVERSE.
 - A. INCREMENT FEED. USED WITH TABLE TRAVERSE. OUTPUT FROM THE 1 GPM PUMP IS DIRECTED THRU THE CROSS TRAVERSE DIRECTION VALVE (18) TO THE CROSS TRAVERSE CYLINDER. EXHAUST FLOW IS DIRECTED TO THE INCREMENT CONTROL VALVE WHICH IS ACTUATED SIMULTANEOUSLY WITH THE TABLE REVERSING VALVE PERMITTING FLOW TO THE AMOUNT VALVE WHICH DETERMINES THE VOLUME EXHAUSTED. ADJUSTMENT OF THIS VALVE CONTROLS THE SIZE OF INCREMENT. INCREMENT FEED CONTINUES IN ONE DIRECTION UNTIL FLOW TO THE CYLINDER IS REVERSED.
 - B. WHEEL DRESS AND RAPID POSITIONING. NORMALLY USED WITH TABLE STOPPED. ROTATION OF CROSS TRAVERSE MODE LEVER TOWARD WHEEL DRESS GOVERNS EXHAUST FLOW FROM CROSS TRAVERSE CYLINDER THRU ADJUSTABLE FLOW CONTROL VALVE. FURTHER ROTATION INCREASES FLOW UNTIL MAXIMUM POSITIONING SPEED IS REACHED. CROSS SLIDE TRAVELS EITHER IN OR OUT UNTIL SWITCH IS TRIPPED TO REVERSE DIRECTION.
6. AUTOMATIC DOWNFEED - HYD/DF ONLY. USED WITH TABLE TRAVERSE. OUTPUT FROM 1 GPM PUMP IS DIRECTED TO DOWNFEED CONTROL VALVE WHICH IS ACTUATED SIMULTANEOUSLY WITH EITHER THE TABLE PILOT VALVE (14) OR THE CROSS TRAVERSE DIRECTION VALVE (18) PERMITTING FLOW TO DOWNFEED CYLINDER. CYLINDER COMPLETES STROKE CAUSING DOWNFEED CONTROL VALVE TO REVERSE FLOW TO DOWNFEED CYLINDER. AN ADJUSTABLE POSITIVE STOP DETERMINES RESET POSITION OF CYLINDER FOR SIZE OF DOWNFEED INCREMENT.



| DATE | BY | WAS | DRAWN | CHECKED | MATERIAL | HARDNESS | TITLE |
|--|----|-----|--------------|-------------|----------|----------|-------------------|
| | | | TH | TH | | | HYDRAULIC DIAGRAM |
| | | | DATE 1-23-77 | DATE 1-3-78 | PART NO. | | 618 HYD & HYD/DF |
| CHANGES | | | LIST NO. | | | SHEET | |
| TOLERANCE | | | SCALE | | | OF | |
| COMMON FRACTIONS $\pm \frac{1}{64}$ | | | | | | | |
| REID BROS. COMPANY | | | | | 373769 | | |
| One of the White Consolidated Industries | | | | | | | |
| DEXTER MAINE | | | | | | | |



- | | | | |
|----|---|--|-------------------------------|
| 15 | 1 | BOLT HIT = #B003-G28 | |
| 16 | 1 | ADAPTER PLATE DING-A-1054-1 | |
| 23 | 1 | RELIEF VALVE #80050640 | |
| 24 | 1 | TURN FITTING | WDR #1808-214 |
| 25 | 1 | TURN FITTING | WDR #785-314 |
| 26 | 2 | TURN FITTING #3405-0-6 | |
| 27 | 1 | RETURN LINE ELVLR VK01M2 #785-P10P-OPTION | |
| 28 | 1 | HANDLE #1901 | |
| 29 | 1 | BOLT HIT = #B006-G28 | |
| 30 | 1 | SUBPLATE #EG6H-06-00 (WOOD-FIBER AS SHOWN ABOVE) | |
| 31 | 1 | ONE NO. 10-32 X 1/2" SCREW | #8005-E-W-9-10 |
| 32 | 1 | FLOW CONTROL VALVE #1-400-8 | |
| 33 | 1 | PRESS RELIEF VALVE #T-05-D8-40 | |
| 34 | 1 | MOTOR - 1HP/1800/RV444543PM 0-0-B #VMM31ST | |
| 35 | 1 | ADAPTER PLATE #7001-0-0 | |
| 36 | 1 | CUMULING #P000 | DOME TYPE #1-X 1/4" X 1/8" HT |
| 37 | 1 | PUMP DUAL #9C8128-AT-RAC | |
| 38 | 1 | DEFUSER #0-28 | |
| 39 | 1 | WAGNET PIPE PLUG | |
| 40 | 1 | WAGNET PLUG W/VALVE | SIZE 3" O.D. (SUM) |
| 41 | 3 | PUMP STRAINER #10-1-J100 | |
| 42 | 1 | OIL LEVEL GUAGE #LT-1M4 | |
| 43 | 1 | FILLER BUSHING #1-2-1800-2 | |
| 44 | 1 | DISCHARGE 10" DIA. (W/ 10" O.D. 18") | |
| 45 | 1 | DESCRIPTION | |



KNOX • NORTON
EAST
ASSEMBLY

[illegible]

HYDRAULIC POWER UNITS

| <u>ITEM NO.</u> | <u>PART NO.</u> | <u>QTY.</u> | <u>NAME</u> | <u>DESCRIPTION</u> |
|-----------------|-----------------|-------------|-----------------------|---|
| 1 | 173862 | 1 | Tank | Knox-Norton #D-1015-1 |
| 2 | 800165 | 1 | Filler-Breather | Flow-Ezy #AB-1000-3 (includes 40 Micron Mesh) |
| 3 | 803053 | 1 | Oil Sight Gage | Hydro-Craft #HC-FLT-1314 |
| 4 | 800167 | 1 | Intake Strainer | Flow-Ezy #10-1-100 (100 Micron Mesh) |
| 5 | 800168 | 1 | Strainer Magnet | Flow-Ezy Flex-Wrap for 3" OD |
| 6 | 800685 | 1 | Pipe Plug | Pipe Plug |
| 7 | 800169 | 1 | Exhaust Diffuser | Flow-Ezy #D-33 |
| 8 | 800170 | 1 | Pump | John S. Barnes #GC-5235-A-1-RA-C Duplex Fluid Pump) |
| 9 | 800171 | 1 | Coupling | Gerbing #G100 (7/8 dia. x 3/16 key & 7/16 dia. x 1/8 key) |
| 10 | 800172 | 1 | Adapter pump/motor | Chicago HYD Adapter - 56C Frame |
| 11 | 800173 | 1 | Motor | Baldor Motor, 1 HP (VWM-3116T) 1800 - 3 - 60-230/460 |
| 12 | 171833 | 1 | Table Relief Valve | Vickers #CT06-BV-40 (modified by Knox-Norton) |
| 13 | 173602 | 1 | Table Speed Control | Manatrol #F-800-S |
| 14 | 974117 | 1 | Pilot Valve | Vickers #DG4V3-6C-WB10 with Male Receptacle |
| 14 | 800175 | 1 | Bolt Kit for 974117 | Vickers #BKDG3-698 |
| 14 | 800176 | 1 | Table Reversing Valve | Vickers #DG3S4-069C-E-51 (Note 1) |
| 14 | 802694 | 1 | Table Reversing Valve | Vickers #DG3S-8-9C-E-10 (Note 2) |
| 16 | 800177 | 1 | Bolt Kit for 800176 | Vickers #BKDGO6-635 |
| 16 | 173863 | 1 | Adapter for 800174 | Knox-Norton PHD #A-01 (Note 3) |

HYDRAULIC POWER UNIT
 REID MODEL: HYT, HYD & HYD/DF
 REID ASSEMBLY NO. 671239
 KNOX-NORTON DRAWING NO. D-1014-1
 Page 2

| <u>ITEM NO.</u> | <u>PART NO.</u> | <u>QTY.</u> | <u>NAME</u> | <u>DESCRIPTION</u> |
|-----------------|-----------------|-------------|-----------------------------|---|
| 15 | 173864 | 1 | Sub-Plate for 800176 | Vickers #DGSM-06-50 (modified by Knox-Norton) |
| 17 | 800178 | 1 | Tank Handle | Guden Handle #1901 |
| 23 | 800179 | 1 | Cross Traverse Relief Valve | Delta #8500-5059 |

NOTE 1: For units built prior to S/N 800596

NOTE 2: For all units beginning with S/N 800596

NOTE 3: Adapter not required when Note 2 applies.

THE FOLLOWING ITEMS ARE FOR THE REID MODEL HYD/DF ONLY - NOT SHOWN ON DRAWING:

| | | | | |
|---|---------|---|----------------|--------------------|
| - | 270832 | 1 | Sub Plate | |
| - | *973785 | 1 | Valve Assembly | Vickers #MOD-6C-30 |

*First used on Machine Serial No. 21137. For machines built prior to S/N 21137 use Part No. 973091, Valve Assembly.


10/23/79
 Rev. 2/6/81

LUBRICATION

PIPING LAYOUT, PARTS LIST AND MAINTENANCE INSTRUCTIONS

| NO. | PART NO. | NAME |
|-----|----------|------------------------------|
| 1 | 170004 | 7 WAY JUNCTION |
| 2 | 172580 | METER UNIT FJD-3/0 |
| 3 | 170030 | COMPRESSION SLEEVE-3/32 |
| 4 | 170031 | COMPRESSION NUT-3/32 |
| 5 | 170033 | STEEL TUBING - 3/32 x .020 |
| 6 | 172581 | COMPRESSION BUSHING-5/32 |
| 7 | 170012 | COMPRESSION SLEEVE-5/32 |
| 8 | 170043 | 5 WAY JUNCTION |
| 9 | 170042 | STRAIGHT ADAPTOR |
| 10 | 170261 | 2 WAY JUNCTION |
| 11 | 170379 | 20" HOSE ASSEMBLY-5/16" O.D. |
| 12 | 972618 | SET SCREW |
| 13 | 170381 | STRAIGHT ADAPTOR |
| 14 | 173578 | COMPRESSION NUT 5/32" |
| 15 | 172951 | PUMP ASSY TM5 |
| 16 | 170021 | PIPE PLUG-1/4-18 NPT |
| 17 | 172583 | CLOSURE PLUG |
| 18 | 170018 | BRASS TUBING - 5/32 O.D. |
| 19 | 170003 | 3 WAY JUNCTION |
| 20 | 172721 | METER UNIT FJD 00 |
| 21 | 172582 | CLIP |
| 22 | 170032 | COMPRESSION BUSHING |
| 23 | 171992 | LUB PUMP MOUNT |

NOTE: Use Socony-MOBIL OIL
VACTRA #2 OR EQUIVALENT



**AUTO LUBE PIPING LAYOUT ...
AND PARTS LIST**

Service Instructions

For systems with lubricator type TM-5

BIJUR

Your machine is well protected by a built-in Bijur central lubricating system - by CORRECT lubrication of all bearings served. It assures smooth operation of your machine for years, if properly maintained.

The Bijur system consists of three basic elements; (1) A LUBRICATOR which periodically forces a measured volume of oil into (2) a single line of DISTRIBUTION TUBING branched to supply oil to the bearing surfaces through (3) METER-UNITS which proportion the correct oil film to each bearing.

OIL: Use only a clean mineral oil of type and viscosity recommended by machine manufacturer.

OPERATION: The Lubricator is a piston pump of the spring discharge type and driven by a timing motor. The motor drives the pump through a gear train and cam at a predetermined rate. Oil volume is determined by the stroke setting and discharge frequency by the timing motor.

Descent of the piston will be faster as the temperature rises and slower as the temperature decreases. This variation in discharge time compensates for changes in oil viscosity thereby assuring a constant volume of oil pumped to the bearings.

LIQUID LEVEL SWITCH: Some models of this lubricator (see Below) are equipped with a Liquid Level Switch. The standard Liquid Level Switch closes at high oil level. When switch is connected to light or other indicating device liquid level is monitored. Switch contact rating is 15 Watt maximum. Indicating device is not supplied by Bijur.

STARTING A NEW MACHINE: Fill reservoir. Pull and release "Instant Feed Button" several times until oil shows freely at all bearings.


MAINTENANCE: Check oil level daily and refill reservoir when required. Check the system periodically for loose or broken tubing, pin holes, loose fittings and connections. Replace Filter Group annually.

SERVICE: Too little oil at all bearings - check for low oil level, broken or cracked tubes, loose connections, flattened lubricator outlet tube, or clogged filter. If one bearing receives too much oil, remove Meter-Unit and replace with one of the same type but next lower Flow Rate Number. For too little oil at one bearing, replace the Meter-Unit with one of the same type but next higher Flow Rate Number. Each increase in Flow Rate Number doubles oil feed. Don't attempt to adjust, disassemble, blow through or drill out Meter-Units.

FILTER REPLACEMENT: A filter at pump inlet protects the lubricating system. The filter disc should be inspected every six months. If not clean, replace. To replace filter remove snap ring which releases clamp ring, filter disc and screens. Insert new screens, coarse screen first, and filter disc. Reassemble clamp and snap ring.

MOTOR REPLACEMENT: Remove motor cover and the two screws holding motor. To reassemble be sure slot in motor shaft engages with pin in drive shaft, before replacing screws.

SERVICE PARTS: Order By Part Number and Name shown below. You must also specify COMPLETE Lubricator Part Number and Serial Letters shown on the Name Plate*. Example: "S-109 Filter Group for Lubricator D-2936, serial ED". For major repairs requiring parts not identified in illustration return lubricator for factory rebuilding and adjustment. If a new lubricator is required for replacement, order by Part Number and Serial Letters shown on the Name Plate.



IMPORTANT: REPLACE FILTER GROUP ONCE A YEAR


OPERATION:

Lubricator Type TM-5 is a motor driven piston pump of spring - discharge type. The motor incorporates a gear reduction which determines the operating cycle of the pump piston. The cycle times available are shown in the table below.

DISCHARGE VOLUME PER STROKE:

Adjustable - 2.5 cu cm minimum
5.0 cu cm maximum

Lubricator supplied set at maximum stroke, 5.0 cu cm discharge. For less delivery remove the lock screw, measure A, turn adjusting screw clockwise increasing A by .5 dimension.



| B | DISCHARGE |
|------|-----------|
| .400 | 2.5 cc |
| .320 | 3.0 cc |
| .240 | 3.5 cc |
| .160 | 4.0 cc |
| .080 | 4.5 cc |
| 0 | 5.0 cc |

DISCHARGE PRESSURE RANGE: 30 - 50 psi

Discharge pressure will decrease as the number of Meter-Units in the system increases.

MOTOR:

Type: Continuous duty, single phase, synchronous induction timing motor for 50 and/or 60 cps.

Voltage: 115/220 Volt

Wiring: For 110 Volt service connect Blue and White, Insulate Red.
For 220 Volt service connect Blue and Red, Insulate White.

Power Consumption: 3 Watts.

BIJUR reserves the right to change motor size, mounting dimensions and manufacturer.

Liquid Level Switch:

Models of this lubricator equipped with a Liquid Level Switch are listed below. For fail safe operation, they are supplied so the switch will close an electrical circuit whenever the oil in the reservoir is above the minimum operating level. Thus, when connected to a light or other indicating device, the liquid level can be monitored.

Customers may reverse the operation when desired by inverting the float. When the float is reversed, the switch will close an electrical circuit whenever the oil level is below the minimum operating level.

NOTE: Switch Contact Rating: 15 Watt Max.

Light or Indicating device not supplied by BIJUR

LUBRICATOR INLET FILTER:

40 micron particle separation. It should be inspected periodically and cleaned or replaced as required.

RESERVOIR: 1 litre (1000 cu cm) refill capacity, (1 quart).

SYSTEM: Use Meter-Units Type F

SYSTEM LIMITATION:

For System & Limitation see "Engineering Manual".

Viscosity range 150 to 3000 SSU at operating temperature.

WHEN ORDERING SPECIFY:


Name, Symbol and Part Number such as:
LUBRICATOR TM-5 0-2994

| LUBRICATOR CYCLE TIME IN MINUTES | | PART NUMBER | | | |
|--|--------|--------------------------------|--|-----------------------------|--|
| | | WITHOUT LIQUID LEVEL SWITCH | | WITH LIQUID LEVEL SWITCH | |
| 50 cps | 60 cps | BIJUR | | BIJUR | |
| 6.4 | 5.3 | 0-2994 | | 0-2986 | |
| 10.6 | 8.8 | 0-2996 | | 0-2988 | |
| 32 | 27.7 | 0-2998 | | 0-2990 | |
| 64.0 | 53.5 | 0-3189 | | 0-3187 | |
| 128 | 107 | 0-3000 | | 0-2992 | |

OUTLET-5/16-24 NF THREAD F
5/32 O.D. TUBING CONNECTION
(USE COMPRESSION NUT B-1093
AND COMPRESSION SLEEVE B-10

GROUNDING TERMINAL

7/8 DIA. HOLE FOR 1/2 IN
CONDUIT CONNECTION




FILLER CAP

PART NUMBER STAMP

2 MOUNTING HOLES-17/64 DIA.
FOR 1/4 DIA. BOLTS

LIQUID LEVEL
SWITCH LEAD
18 GAGE STRA


MOTOR LEADS 20 GAGE
6 INCHES LONG



OPERATING INSTRUCTIONS - REID MODEL HYD/DF

OPERATING INSTRUCTION - REID MODEL HYD/DF
 MANUAL OPERATION OF AUTOMATIC DOWNFEED
 WITH AUTO TABLE STOP IN THE ON POSITION

AUTO STOP
RESET




AUTO STOP
OFF ON




DOWNFEED
PLUNGE SURFACE




SPINDLE
START




HYD MOTOR
START




DOWNFEED
PULL TO START
PUSH TO STOP



SPINDLE
STOP



HYD MOTOR
STOP



DOWNFEED
AUTO STOP
OFF ON




When it is desirable to surface grind without automatic downfeeding, yet have the table stop at the end of a cross slide traverse (IN or OUT), the operator controls must be set as shown above.

In this mode, the table will stop in the extreme right hand position when the cross slide limit switch is tripped. The machine can be started again by pushing the AUTO STOP RESET button.

OPERATING INSTRUCTIONS - REID MODEL HYD/DF
PLUNGE GRINDING

AUTO STOP
RESET




AUTO STOP
OFF ON




DOWNFEED
PLUNGE SURFACE




SPINDLE
START



HYD MOTOR
START




DOWNFEED
PULL TO START
PUSH TO STOP



SPINDLE
STOP



HYD MOTOR
STOP



DOWNFEED
AUTO STOP
OFF ON




For plunge (downfeeding on table reversal with the cross slide inactivated) grinding, the DOWNFEED selector switch is turned to the PLUNGE position. With the DOWNFEED AUTO STOP selector switch turned to the OFF position, the table will continue to operate when the total incremental downfeed is completed, but the downfeed will stop feeding. The table must be stopped by the table hand controls.

If desired, the table may be stopped automatically in the right hand position on completion of the total incremental downfeed, with the DOWNFEED AUTO STOP selector switch in the ON position.

OPERATING INSTRUCTIONS - REID MODEL HYD/DF
 MANUAL OPERATION OF AUTOMATIC DOWNFEED
 WITH AUTO TABLE STOP IN THE OFF POSITION

AUTO STOP
RESET




AUTO STOP
OFF ON




DOWNFEED
PLUNGE SURFACE




SPINDLE
START




HYD MOTOR
START




DOWNFEED
PULL TO START
PUSH TO STOP



SPINDLE
STOP



HYD MOTOR
STOP



DOWNFEED
AUTO STOP
OFF ON




For typical surface grinding, power table and cross slide traverse and manual downfeed, hand controls must be used to stop the table.

ELECTRICAL


V - PH - H₂
L1 L2 L3

| MAGNETIC CHUCK CONTROL | | |
|------------------------|---------------|------------|
| PART NO | INPUT VOLTAGE | CONNECT TO |
| 173104 | 230/460 | L1 - L3 |
| 173124 | 115 | 1 - 2 |
| 173125 | 115 | 1 - 2 |
| 173126 | 230/460 | 1 - L3 |

(OPTIONAL)



| TRANSFORMER CONNECTIONS | | | |
|-------------------------|----|----|---------------------|
| INPUT | L1 | L3 | CONNECT TOGETHER |
| 230V | H1 | H4 | H1 TO H3 - H2 TO H4 |
| 460V | H1 | H4 | H2 TO H3 |



TITLE ELECTRICAL SCHEMATIC
STANDARD HYD

DRAWN
DATE 7-7-79

CHECKED
DATE 7-7-79

MATERIAL
PART NO

REID BROS. COMPANY
One of the World's Leading Industrial

DEXTER
MAINE

SCALE
COMMON FRACTIONS 1/8"


DATE BY
WAS

CHANGES
TOLERANCE

SHEET
OF



W-B-903-E1

JUN 2 1980




| TRANSFORMER CONNECTIONS | | | | | |
|-------------------------|----|----|----|----|----|
| WYD | 11 | 12 | 13 | 14 | 15 |
| COOLANT | 16 | 17 | 18 | 19 | 20 |
| SPINDLE | 21 | 22 | 23 | 24 | 25 |

STARTER PANEL




| MAGNETIC POWER CONTROL | | |
|------------------------|-------------|------------|
| PART NO. | WYD VOLTAGE | CONNECT TO |
| 275125 | 275125 | 11 & 12 |
| 275126 | 115 | 1 & 2 |
| 275127 | 115 | 1 & 2 |
| 275128 | 275128 | 11 & 12 |

DELAY PANEL



11, 12, 13, 14, 15, 16, 17, 18, 19, 20, 21, 22, 23, 24, 25, 26, 27, 28, 29, 30, 31, 32, 33, 34, 35, 36, 37, 38, 39, 40, 41, 42, 43, 44, 45, 46, 47, 48, 49, 50, 51, 52, 53, 54, 55, 56, 57, 58, 59, 60, 61, 62, 63, 64, 65, 66, 67, 68, 69, 70, 71, 72, 73, 74, 75, 76, 77, 78, 79, 80, 81, 82, 83, 84, 85, 86, 87, 88, 89, 90, 91, 92, 93, 94, 95, 96, 97, 98, 99, 100

115 - TABLE REVERSE
 116 - LOCATED IN TABLE CONTROL RMR, WELD CLOSED IN OPERATION
 117 - CROSS SLIDE REVERSE
 118 - LOCATED IN CROSS SLIDE CONTROL RMR, WELD CLOSED IN OPERATION
 119 - LOCATED IN VERTICAL TRAVERSE CONTROL RMR, WELD WHEN HANDWHEEL EXERCISES ONE REVOLUTION
 120 - LOCATED AT DOWNFEED STROKE CYLINDER, CLOSED WHEN DOWNFEED STROKE COMPLETE



1/2/76

REID FROS. COMPANY

ELECTRICAL SCHEMATIC FOR A STRIPPED THE DOWNFEED

W-A-864-E1

SPINDLE MAINTENANCE

HELPFUL HINTS FOR MAINTENANCEOFWHITNON SURFACE GRINDER SPINDLES

Whitnon surface grinder spindles, as well as all of the other products in the Whitnon line, are ideally designed for the application for which they are intended. Great care is taken to select the materials durable enough to stand up for years of dependable operation. Considerations for strength and rigidity are always made part of the design.

Our manufacturing people are craftsmen who take pride in the work they do, knowing that the finished product is one of the finest available. They take no shortcuts for the sake of compromising quality, precision and rigidity.

While the Whitnon spindle is built with precision and rigidity, proper care must be exercised to maintain this precision and prolong spindle life just as is true of any other precision instrument. The intention here is to convey some helpful hints which will help extend the long life already built into your Whitnon spindle.

1. All Whitnon spindles are test run under no load conditions at our plant. During this test run, vibration and temperature rise are monitored. No spindle is shipped without first passing the rigid specifications established and enforced by our Engineering Department.
2. All good spindles will develop heat during operation. In the case of a surface grinder spindle, there are three sources of heat. The first is the motor, the second is the front seal, and the third is the bearing system. Operating temperatures over the motor may get as high as 150°F or 80°F above ambient, and temperatures of 125°F or 65°F above ambient over the spindle barrel are possible. These temperatures are hot to the touch so a pyrometer or some other temperature recording instrument should be used if a question of temperature arises.
3. During the initial run, it is possible to experience temperatures exceeding those previously stated over the spindle barrel. This may be caused by the excess grease in the bearing grease pockets migrating back to the bearings from vibration during transit. In effect, the bearings may be overlubricated which will cause an increase in operating temperature. If this occurs, shut off the spindle, let it cool and restart the unit. This cycle may have to be repeated 2 or 3 times, but usually once is enough.
 - A. If the heat problem persists, call the Whitnon factory for further advice.
 - B. While you may feel the motor is too hot, it is not too hot unless the sealing wax begins to melt and becomes visible over two set screws which secure the motor stator in the motor housing. When this occurs, call the Whitnon factory for further advice.

4. The amplitude of vibration reading on a Whitton surface grinder spindle is less than .000050 peak to peak. If you feel you have a vibration problem, remove the grinding wheel and wheel holder, and shut off all pumps and machinery close by. In this way you will have excluded other sources and you can now run the spindle alone. In just about every case, you will find that the vibration is being transmitted from some other source. The other source can easily be found by starting or adding one possible source at a time. Make sure the wheel holder runs true and the wheel is dressed before a vibration check is made.
5. Never bang on a spindle. This can cause flat spots on the balls and in the races of the bearings (brinelling) which will cause noise and premature failure. Banging can also increase runout on the spindle nose.
6. Always remove the wheel holder with a puller.
7. If the combination wrench normally supplied with a surface grinder is bent at 90° half way between the socket and pin end, you will obtain better leverage for tightening and loosening the wheel nut and flanged hex nut. At least, if tapping the wrench is required, it will be transmitted to the bearings as a rotational force rather than a shock load.
8. Surface finish problems should be referred back to the original machine tool builder. These are almost always related to the wheel and dressing of the wheel unless the spindle and machine are old.
9. If you notice that the front end of the spindle seems to be throwing out grease, do not panic. The bearings are permanently lubricated for life with a grease that is the finest available. It will not flow or break down under 400°F. What is probably seen is some of the rust preventative solution which leaked into the labyrinth clearances prior to shipment. This will eventually disappear.
10. Never spray coolant directly on the spindle nose. The coolant belongs between the wheel and the workpiece. While the spindle is sealed, no seal lasts forever. In fact, the bearings will last a lot longer than the seal, so if you wish to take advantage of maximum bearing life, do not make the seal work by directing the coolant on the spindle nose.
11. When the day comes that your Whitton spindle requires repair, send it back to our plant for restoration back to first class condition. This expert service will add more years to the life of the spindle and result in the best performance of your machine.

12. If you use on your surface grinder, a high speed attachment which is clamped over the spindle barrel, tighten the clamp only enough to secure in place. Do not over tighten as this will take out the clearances in the bearing bores, which can result in excessive heat and shortened bearing life. Also, do not over tension the belt to the high speed spindle.
13. The bearings in your Whitnon spindle are grease sealed and require no further maintenance.

We hope this information is useful and if these hints are used you will find that you will obtain many years of dependable service from your Whitnon spindle.

Whitnon Spindle, Div. of Mite Corp.
Rt 6 & New Britain Avenue
Farmington, Conn. 06032
Tel: 203-677-2607

MAINTENANCE AND TROUBLE SHOOTING GUIDE

H Y D R A U L I C P O W E R U N I T

TROUBLE SHOOTING GUIDE

Hydraulic mechanisms are precision units and their continued smooth operation depends on proper care. Therefore, do not neglect hydraulic systems. Keep them clean. Change the oil and oil filter (if present) at established intervals.

If, in spite of these precautions, improper operation does occur, the cause can generally be traced to one of the following:

1. Use of the wrong viscosity or type of oil.
2. Insufficient fluid in the system.
3. Presence of air in the system.
4. Mechanical damage or structural failure.
5. Internal or external leakage.
6. Dirt, decomposed packing, water sludge, rust, etc., in the system.
7. Improper adjustments.
8. Oil cooler plugged, dirty or leaking.

Some possible causes of specific troubles which may be encountered and their remedy are indicated in the succeeding pages.

HYDRAULIC POWER UNIT

MAINTENANCE

1. Make frequent inspections of reservoir oil level sight gauge to insure proper amount of oil in system.
2. Immersed suction line strainers and filters should be inspected every six months for excessive contamination or clogging. Clean or replace as required.
3. The frequency with which used oil should be drained and replaced depends on the nature of the oil and the operating conditions to which it is subjected.

Visual inspection of the oil to note any change in appearance, such as darkening or thickening, may serve as a rough guide to indicate the need for a change. However, periodic testing of the oil, by submitting samples to your bulk supplier, is the safest way to determine when the oil needs changing.

4. Periodically check all mounting bolts of the pump and motor assembly to guard against possible loosening due to vibration and use. Also check motor/pump coupling, if applicable.
5. Always check to see that cover plate is properly bolted down, all filter/breather caps are in place and that the integrity of reservoir is preserved against the incursion of dirt and moisture.
6. Make certain the oil operating temperatures do not exceed prescribed limits and do not allow line or component leaks to go unattended.

IMPROPER OPERATION OF PUMPS

A. Failure of pump to deliver fluid.

Possible Causes

Remedy

- | | |
|---|--|
| 1. Low fluid level in reservoir. | 1. Add recommended oil, and check level on both sides of tank baffle to be certain pump suction line is submerged. |
| 2. Oil intake pipe or suction filter plugged. | 2. Clean filter or otherwise remove obstruction. |
| 3. Air leak in suction line, preventing priming or causing noise and irregular action of control circuit. | 3. Repair leaks. |
| 4. Pump shaft turning too slowly to prime itself (vane type pumps only). | 4. Check minimum speed recommendations in manufacturers' descriptive literature. |
| 5. Oil viscosity too heavy to pick up prime. | 5. Use lighter viscosity oil. Follow manufacturers' recommendations for given temperature and service. |
| 6. Wrong direction of shaft rotation. | 6. Must be reversed immediately to prevent seizure and breakage of parts due to lack of oil. |
| 7. Broken pump shaft or parts broken inside pump. Shear pin or shear linkage broken. | 7. Refer to manufacturers' literature for replacement instructions. |
| 8. Dirt in pump. | 8. Dismantle and clean. |
| 9. On variable delivery pumps the stroke is not right. | 9. Check pump manufacturers' instructions. |

B. No pressure in the system.

Possible Causes

Remedy

- | | |
|---|---|
| 1. Pump not delivering oil for any of the above reasons. | 1. Follow remedies given above. |
| 2. Relief valve not functioning properly. (a) Valve setting not high enough. (b) Valve leaking. (c) Spring in relief valve broken. | 2. See below (a) Increase pressure setting of valves. (b) Check seat for score mark and reseal. (c) Replace spring and readjust valve. |
| 3. Vane or vanes stuck in rotor slots (vane type pumps only). | 3. Inspect for wedged chips or sticky oil. |
| 4. Head too loose (very infrequent). | 4. Must not be tightened too tightly. See manufacturers' instructions before tightening. |
| 5. Free re-circulation of oil to tank being allowed through system. | 5. Directional valve may be in open-center neutral, or other return line open unintentionally. |
| 6. Internal leakage in control valves or cylinders. | 6. To determine location progressively, block off various parts of circuit. When trouble is located repair. |

C. Pump making noise.

| Possible Causes | Remedy |
|---|--|
| 1. Partially clogged intake line, intake filter or restricted intake pipe. | 1. Clean out intake, strainer or eliminate restriction. Be sure suction line is completely open. |
| 2. Air leaks <ul style="list-style-type: none">(a) At pump intake piping joints.(b) At pump shaft packing (if present).(c) Air drawn in through inlet pipe opening. | 2. See below. <ul style="list-style-type: none">(a) Test by pouring oil on joints while listening for change in sound of operation. Tighten as required.(b) Pour oil around shaft while listening for change in sound of operation. Follow manufacturers' recommendations when changing packing.(c) Check to be certain suction and return lines are well below oil level in reservoir. Add oil to reservoir if necessary. |
| 3. Air bubbles in intake oil. | 3. Use hydraulic oil containing a foam depressant. |
| 4. Reservoir air vent plugged. | 4. Air must be allowed to breathe in the reservoir. Clean or replace breather. |
| 5. Pump running too fast. | 5. Check recommended maximum speeds from manufacturers' descriptive bulletins. |
| 6. Too high oil viscosity. | 6. Use lower viscosity oil. Follow manufacturers' recommendations for given temperature and service. |
| 7. Filter too small. | 7. Capacity may be adequate only when just cleaned, and should have added capacity. |
| 8. Rag, paper, etc., pulled into suction line or pump. | 8. Remove. |
| 9. Coupling misalignment. | 9. Re-align. |
| 10. Pump head too loose, or a faulty head gasket. | 10. Test by pouring oil over head, replacing gasket or tighten head as is necessary. |
| 11. Stuck pump vane (vane type pump). | 11. Inspect for wedged chips or sticky oil, and re-assemble. |
| 12. Worn or broken parts. | 12. Replace. |

D. External oil leakage around pump.

| Possible Causes | Remedy |
|--|---|
| 1. Shaft packing worn. | 1. Replace. |
| 2. Head of oil on suction pipe connection. | 2. Sometimes necessary, but will usually cause slight leakage. Keep all joints tight. |
| 3. Damaged head packing. | 3. Replace. |

E. Excessive wear.

Possible Causes

Remedy

- | | |
|--|--|
| 1. Abrasive matter in the hydraulic oil being circulated through the pump. | 1. Install adequate filter or replace oil more often. |
| 2. Viscosity of oil too low at working conditions. | 2. Check pump manufacturers' recommendations or consult your lubrication engineer. |
| 3. Sustained high pressure above maximum pump rating. | 3. Check relief or regulator valve maximum setting. |
| 4. Drive misalignment or tight belt drive. | 4. Check and correct. |
| 5. Air recirculation causing chatter in system. | 5. Remove air from system. |

F. Breakage of parts inside pump housing.

Possible Causes

Remedy

- | | |
|--|---|
| 1. Excessive pressure above maximum pump rating. | 1. Check relief or regulator valve maximum setting. |
| 2. Seizure due to lack of oil. | 2. Check reservoir level, oil filter and possibility of restriction in suction line more often. |
| 3. Solid matter being wedged in pump. | 3. Install filter on suction line. |
| 4. Excessive tightening of head screws. | 4. Follow pump manufacturers' recommendations. |

IMPROPER OPERATION OF ACTUATING MECHANISMS

A. System inoperative.

Possible Causes

Remedy

- | | |
|-------------------------------------|---------------------------------|
| 1. Any of the reasons listed above. | 1. Follow remedies given above. |
|-------------------------------------|---------------------------------|

B. Mechanisms creep when stopped in intermediate position.

Possible Causes

Remedy

- | | |
|---|---|
| 1. Internal leakage in actuating cylinders or operating valves. | 1. Replace piston packing or replace cylinder if walls are scored. Replace or repair valve. |
| 2. Spool in selector valve not seating. | 2. Clean unit to remove foreign matter, then check cam clearance. |

C. Times of operation longer than specified.

| Possible Causes | Remedy |
|---|---|
| 1. Air in system. | 1. Bleed the system. |
| 2. Internal leak in actuating cylinder or selector valve. | 2. See remedy for B: 1 and 2 (page 76). |
| 3. Worn pump. | 3. Repair or replace. |
| 4. If action is sluggish on starting up, but somewhat less sluggish after operating temperatures have increased, or if action slows down after warm up (depending on equipment and circuit design), it is probable that viscosity of the oil is too high. | 4. Consult pump manufacturers' recommendations, or your oil supplier for correct oil viscosity. |
| 5. Low auxiliary control pressure. | 5. Control lines may be too small, particularly if they are long. |

D. External oil leakage.

| Possible Causes | Remedy |
|-------------------|--|
| 1. End caps. | 1. Tighten if possible or replace gasket if necessary. |
| 2. Packing gland. | 2. Tighten, or replace packing if necessary. |

E. Abnormal packing gland wear.

| Possible Causes | Remedy |
|--|--|
| 1. Cylinder not securely fastened to frame, causing vibration. | 1. Tighten. This should be checked periodically. |
| 2. Misalignment of cylinder and piston rod extension. | 2. Check and correct. |
| 3. Side load on piston rod. | 3. Revise construction to eliminate side loads. |

IMPROPER OPERATION OF ACCUMULATOR

A. Pressure from accumulator drops suddenly when position of selector valve is changed.

| Possible Causes | Remedy |
|--|--|
| 1. Internal or external leak in accumulator. | 1. Repair leak or replace accumulator valve core (if present). |

B. When pump is running pressure is normal, but when pump is stopped no pressure is available.

Possible Causes

Remedy

- | | |
|--|-------------------|
| 1. Leaking gas valve or leaking check valve in hydraulic line. | 1. Replace valve. |
|--|-------------------|

C. Sluggish response from accumulator.

Possible Causes

Remedy

- | | |
|--|--|
| 1. Stoppage of oil screen in accumulator (if present). | 1. Dismantle accumulator and clean screen. |
| 2. Gas precharge not sufficient. | 2. Precharge according to manufacturers' instructions, also check for gas leaks. |

Be sure all internal pressure is released before repairs are made on accumulators.

EXCESSIVE HEATING OF OIL IN SYSTEM

A. Heating caused by power unit (reservoir, pump, relief valve and coolers).

Possible Causes

Remedy

- | | |
|--|--|
| 1. Relief valve set at a higher pressure than necessary, excess oil dissipated through increased slippage in various parts, or through relief valve or through throttle valve. | 1. Reset relief valve to slightly above maximum pressure required for work stroke. Check manufacturers' recommendations for maximum pressure settings. |
| 2. Internal oil leakage due to wear. | 2. Repair or replace pump. |
| 3. Viscosity of oil too high. | 3. Follow manufacturers' recommendations for correct viscosity grade to be used at various temperatures. |
| 4. Pumps assembled after overhaul may be assembled too tightly. This reduces clearances and increases rubbing friction. | 4. Follow manufacturers' instructions when re-assembling. |
| 5. Leaking check valves or relief valves in pump. | 5. Repair. |
| 6. Improper functioning of oil cooler or coolant is cut off. | 6. Inspect cooler and see that it is working properly. |
| 7. Automatic unloading control inoperative. | 7. Repair valve. |

ating because of conditions in system.

when

Remedy

1. Air

2. I-
va'

properly.

1. If lines are crimped, replace; if partially plugged for any reason, remove obstruction.

2. Make certain that open-center valves are neutralized, and that any pressure-relieving valves are in the correct position. Only small pump volumes should be allowed to remain at high pressures when clamping or running idle for long periods of time.

3. Use artificial cooling.

4. Locate leaks then replace packing.

5. Replace with larger reservoir, or install cooler.

6. Check flow velocity through lines and valves and compare with manufacturers' recommendations. If excessive, replace by installing larger equipment.

on.

As.

voir too small to provide adequate cooling.

Undersize valves or piping.

Note: If system operates continually at high operating temperatures, consideration should be given to the installation of an oil cooler.

IMPROPER OPERATION OF FLUID MOTORS

A. Motor turning in wrong direction.

Possible Causes

Remedy

1. Incorrect piping between control valve and motor.

1. Check circuit to determine correct piping.

B. Motor not turning over or not developing proper speed or torque.

Possible Causes

Remedy

1. System overload relief valve adjustment not set high enough.

1. Check system pressure and reset relief valve.

2. Relief valve sticking open.

2. Remove dirt under pressure adjustment ball or piston.

3. Free recirculation of oil to reservoir being allowed through system.

3. Directional control valve may be in open center neutral or other return line unintentionally open. Repair or replace valve.

4. Driven mechanism binding because of misalignment.

5. Pump not delivering sufficient pressure or volume.

6. Motor yoke not set at proper angle (on adjustable motors).

4. Remove motor and check torque requirement of driven shaft.

5. Check pump delivery and pressure.

6. Adjust pump yoke angle by means of hand wheel.

C. External oil leakage from motor.

Possible Causes

1. Gaskets leaking (may be due to reservoir drain not being connected if this is required).

Remedy

1. Replace. (If drain line required it must be piped directly to reservoir.)

REPAIR PARTS ORDERING PROCEDURE

PARTS ORDERING INFORMATION

TO ORDER REPAIR PARTS:

1. State the machine SERIAL NUMBER.
2. State the MODEL of your machine.
3. State the QUANTITY of each part required.
4. State the PART NUMBER and NAME from the parts manual.
5. State exact SHIPPING INSTRUCTIONS:
 - (a) Specify where to ship.
 - (b) Specify the type of shipping agency.
 - (c) Specify regular delivery, special delivery or special handling.
6. Forward all requests for repair parts to our authorized representative in your area or the the attention of CUSTOMER SERVICE DEPARTMENT at the Home Office of Faysscott, Dexter, Maine.

NOTE: The serial number for the machine for which the repairs parts are needed is necessary so that the Service Department can check and furnish the proper parts to fit your machine. This will avoid unnecessary delays and possibilities of errors.

The serial number is shown on the nameplate attached to the front of the hydraulic power unit and is also stamped on front of machine base under the cross feed handwheel.

MISCELLANEOUS INSTRUCTIONS


INSTRUCTIONS FOR GRINDING CHUCK

Grinding in a chuck to the table of its grinder is extremely important to the flatness and finish which will be obtained. Grinding the chuck is easy, but must be done with care. The following procedures should be followed carefully.

GENERAL INSTRUCTIONS

- Use the proper grinding wheels -- 32A46-G12VBEP or equivalent for a new Walker chuck -- 384H or equivalent for others.
- Due to the different materials on the top of the chuck, there is a tendency for uneven heat build up during grinding which can cause distortion. To avoid, use wet grinder for top if available. If not, it is suggested that the grinding wheel be opened by grinding slots as illustrated, using a pedestal or snagging grinder. Then rebalance the slotted wheel.

2" Wide x 1/4" To 1/2" Deep



Grinding The BOTTOM Of The Chuck

1. Diamond (rough) dress wheel using fast cross feed. Remove 2 to 3 thousandths (.002 to .003) from the wheel dresser.
2. Mount chuck bottom side up, and hold down with chuck clamps in reversed position. Do not over-tighten the clamps!
3. Start grinding from the high point of the chuck. Use top speed if the grinder is a power model. Use normal speed if grinder is a hand feed -- but not slow.
4. Cross feed at approximately 150 thousands (.150).
5. Make one pass only across the chuck.
6. Rough re-dress wheel as in Step 1. Then repeat steps 3, 4 and 5, until surface is flat.

Grinding In The TOP Of The Chuck

1. Remove the chuck from its bottom up position, and thoroughly clean the table top and bottom of chuck.
2. Place the chuck face up in its normal position, and clamp to the table. Then magnetize the chuck. Remember -- don't over-tighten the clamps.
3. Re-dress the wheel, as in Step 1, above.
4. Grind the top of the chuck exactly as you ground the bottom (Steps 3, 4, 5 and 6 above).

REID-O-MATIC
MISCELLANEOUS INSTRUCTIONS

Please contact our local sales representative in your area or our CUSTOMER SERVICE DEPARTMENT for any instructions not included in this manual.

When ordering additional instructions:

1. State the machine SERIAL NUMBER.
2. State the MODEL of your machine.
3. State the type of INSTRUCTIONS required.
4. State exact MAILING INSTRUCTIONS:
 - (a) Specify where and to whom to mail.
 - (b) Specify regular delivery or special handling.

NOTE: The serial number is shown on the nameplate attached to the front of the hydraulic power unit and is also stamped on the front of the machine base under the cross feed handwheel.