



Replacement Parts

Ref. No.	Part NO.	Description	Ref. No.	Part No.	Description
1	412-02-031-5004	Guard Cover	16	412-02-048-5001	Rubber Foot
2	901-02-010-0525	#10-24 X 1/2" Rd. Hd. Scr.	17	901-02-010-0525	#10-24 X 1/2" Rd. Hd. Scr.
3	412-02-103-5001	Wheel Flange	18	904-01-010-1614	9/32 X 5/8 X 1/16" Washer
4	412-02-054-5003	Guard	19	904-02-020-1702	1/4" Lockwasher
5	412-02-089-5002	Tool Rest	20	901-02-180-2301	1/4-20 X 1/2" Hex Hd. Scr.
6	902-01-120-1034	1/4-20 Hex Nut	21	901-02-010-0560	#10-32 X 7/16" Rd. Hd. Scr.
7	901-11-020-0824	1/4-20 X 1/2" Car. Bolt	22	438-01-015-0025	Relay
8	412-02-089-5003	Tool Rest Support	23	1225378	Switch
9	438-02-314-0846	Complete Motor Ass'y., Incl:	24	412-02-031-5003	Base Cover Plate
10	902-01-200-5439	1/2-20 Hex Nut (L.H.)	25	901-02-010-0560	#10-32 X 7/16" Rd. Hd. Scr.
11	902-01-120-1203	#10-32 Hex Nut	26	1201141	Power Cord
12	412-02-072-5001	End Bell	27	902-01-010-1208	1/2-20 Hex Nut (R.H.)
13	412-02-112-5001	Thru Bolt	28	412-02-036-5001	Spark Breaker
14	901-02-010-0560	#10-32 X 7/16" Rd. Hd. Scr.	29	901-02-010-0525	#10-24 X 1/2" Rd. Hd. Scr.
15	412-02-005-5001	Base	30	23-800	Set of Eye Shields