



**DP-10A**

Replacement Parts

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	SP-1300	5/16"Hex. Nut	76	402-07-072-5006	Cover Plate
2	SP-1620	11/32 x 11/16 x 1/16" Washer	*	402-07-406-5002	Spindle Shaft, Consisting of:
3	SP-2951	Speed Nut	77	SP-7025	Retaining Ring
4	402-07-372-5001	Motor Plate	78	920-04-021-5116	Bearing
5	402-07-106-5006	Shaft	79	926-01-051-6349	Pulley
6	904-15-011-7105	Retaining Ring	80	SP-5360	Bearing
7	SP-834	5/16-18 x 3/4" Carriage Bolt	81	SP-2600	Key
8	SP-1226	5/8"-18 Hex. Jam Nut	82	402-07-106-5005	Spindle
9	SP-1674	5/8" Int. Tooth Lockwasher	83	SP-7352	Spring Washer
10	402-07-072-5008	Plate	84	SP-2661	3/16 x 3/16 x 2" Key
11	LBS-169	Collar	85	402-07-072-5001	Cover Plate
12	SP-208	1/4-20 x 1/4" Set Screw	86	SP-1034	1/4"-20 Hex. Jam Nut
13	402-07-071-5003	Pin	88	SP-5225	Oiler
14	402-07-357-5002	Head Casting, Including:	89	DP-631-S	Hub, Including:
15	402-07-020-5004	Cap	90	FJ-324	Ball
16	SP-615	7/16-14 x 1 3/4 Cap Screw	91	DP-632	Stud
18	SP-3114	7/16-14 x 2 1/2 Cap Screw	92	402-07-406-5005	Pinion Shaft, Including:
67	402-07-079-5002	Retainer Pin	*	DDL-123	Spring
17	SP-633	7/16-14 x 3 1/4 Cap Screw	*	SP-28	Steel Ball
19	SP-5437	7/16-14 Hex. Nut	93	DP-634	Pin
20	SP-308	5/16-18 x 3/4" Sq. Hd. Set Scr.	94	SP-1145	3/8-24 x 1/2" Set Screw
21	SP-1270	3/8"-24 Hex. Jam Nut	95	DP-748	Rod
22	SP-1669	3/8" Int. Tooth Lockwasher	96	DP-282	3/8"-24 Thumb Screw
23	SP-1403	5/16"-18 Wing Nut	97	DP-572	Cover
24	402-07-071-5001	Pin	98	SP-3019	#6-32 x 1/2" Self-Tapping Scr.
25	SP-303	5/16-18 x 1 1/4" Set Screw	99	901-06-120-3016	#6-32 x 7/16" Self-Tapping Scr.
26	SP-207	5/16-18 x 1/2" Set Screw	100	438-01-021-0081	Plate
27	NCS-43	5/8 x 1 x 1/32" Washer	101	SD-18	1/4"-20 Special Hex. Nut
28	DP-642	Compound Gear Shaft	102	402-07-112-5001	Special Screw
29	402-07-051-5002	Compound Gear	103	SP-703	1/4-20 x 1 3/4" Fil. Hd. Scre.
30	SP-103	5/16-18 x 1/4" Set Screw	*	402-07-377-5005	Quill Assembly (#2 Morse Taper), Consisting of:
31	DP-636-S	Worm Shaft			Sleeve
32	DP-638	Bearing Closure Spanner Nut	104	DP-615	Key
33	DDL-160-S	Ball Crank, Including:	105	DP-623	Garter Spring
34	SP-206	5/16-18 x 5/16" Set Screw	106	DP-622	Quill, Including:
35	SP-912	1/4-20 x 4 1/2" Rd. Hd. Screw	107	402-07-377-5006	Quill Guide Key
42	MJ-4409	5/32" Hex. Wrench	108	402-07-052-5001	Ring
43	SP-1610	13/64 x 3/8 x 1/32" Stud Washer	109	DP-704	Bearing Closure Nut
44	928-01-041-5879	Spring	110	BG-12	Lower Spindle (#2 Morse Taper), Including:
45	402-07-406-5006	Shaft Assembly		DP-610-A	Pinion Gear
46	402-07-105-5001	Sleeve	111	402-07-051-5005	5/16-18 x 1 Soc. Hd. Cap Scr.
47	904-10-021-2064	Collar	112	SP-750	Quill & Lower Spindle (1/2" Chuck), Consisting of:
48	SP-246	#10-32 x 3/16" Set Screw	*	402-07-377-5004	Sleeve
49	SP-7103	Oiler	104	DP-615	Key
50	402-07-031-5001	Cover	105	DP-623	Garter Spring
51	901-04-140-9419	1/4-28 x 3/8" Set Screw	106	DP-622	Quill, Including:
52	402-07-037-5001	Feed Dial	107	402-07-377-5006	Quill Guide Key
53	DP-544	Knurled Knob	108	402-07-052-5001	Garter Spring
54	SP-732	#10-32 x 1 1/4" Fil. Hd. Scr.	109	DP-704	Bearing Closure Nut
55	SP-737	1/4-20 x 5/8" Fil. Hd. Scr.	110	BG-12	Lower Spindle (1/2" Chuck), Including:
56	402-07-074-5001	3/16 x 3/8" Brass Plug	111	DP-700-A	Spindle Nut
57	NCS-178	1/4"-28 Thumb Screw	112	BM-23	1/2" Chuck
58	SP-1227	1/2"-20 Hex. Jam Nut	113	DP-42	Key for Chuck
59	402-07-072-5005	Stop Finger	114	DP-790	Bumper
60	402-07-372-5002	Stop Plate, Including:	115	402-07-014-5003	Bracket
61	905-02-051-1698	1/4 x 5/8" Groove Pin	116	901-11-011-1453	1/4-20 x 2 1/2" Sq. Hd. Scr.
62	402-07-351-5003	Gear, Including:	117	402-07-054-5002	Upper Guard
63	905-02-021-1697	1/4 x 1/2" Groove Pin	118	SP-7510	1/4-20 x 3/4" Truss Hd. Screw
64	DP-619-L	Cover Plate	119	PF-62	Spring Clip
65	DP-633-L	Return Spring	120	SP-1079	1/4"-20 Hex. Lock Nut
66	DP-607-L	Return Spring Housing	121	402-07-059-5002	Hinge
68	399-32	Plug	122	SP-1614	9/32 x 5/8 x 1/16" Washer
69	960-03-010-2413	Lubrication Plate	123	SP-626	1/4-20 x 3/4" Hex. Hd. Cap Scr.
70	Cat. #1311	Slo-Speed Motor Pulley, Including:	124	401-04-314-5010	Rear Bracket
71	SP-201	5/16-18 x 5/16" Set Screw	125	11-180	Front Bracket
70	Cat. #1312	Hi-Speed Motor Pulley, Including:	126	SP-506	5/16-18 x 5/8" Rd. Hd. Screw
71	SP-201	5/16-18 x 5/16" Set Screw	127	402-07-054-5001	Lower Guard
72	Cat. #501	Hi-Speed V-Belt	128	SP-629	5/16-18 x 3/8" Hex. Hd. Cap Scr.
72	Cat. #520	Slo-Speed V-Belt	129	960-02-011-5194	Delta Name Plate
73	DP-825-R	Slo-Speed Pulley, Including:	130	901-05-381-7352	#4 x 1/4" Self-Tapping Scr.
71	SP-201	5/16-18 x 5/16" Set Screw	131	*	Not Shown
73	DP-826-R	Hi-Speed Pulley, Including:			
71	SP-201	5/16-18 x 5/16" Set Screw			
74	901-20-241-6107	Hex. Hd. Washer Mach. Screw			



Replacement Parts

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
*	402-07-314-5001	Table Bracket, Consisting of:	157	SP-630	3/4-10 x 3 1/2" Cap Screw
16	SP-615	7/16-14 x 1 3/4" Cap Screw	158	DP-665	Sleeve
26	SP-207	5/16-18 x 1 1/2" Set Screw	159	DP-736	25/32 x 1 1/4 x 3/32" Washer
27	NCS-43	5/8 x 1 x 1/32" Washer	160	SP-1707	3/4" Lockwasher
28	DP-642	Compound Gear Shaft	161	SP-1245	3/4"-10 Hex. Nut
29	402-07-051-5002	Compound Gear	162	DP-666-S	Index. Pin
30	SP-103	5/16-18 x 1/4" Set Screw	163	Cat. #1367	3 1/2 x 62" Column (Floor Model)
31	DP-636-S	Worm Shaft	163	Cat. #1368	3 1/2 x 38 1/2" Column (Bench)
32	DP-638	Brg. Closure Spanner Nut	164	DP-648-S	Rack Thrust Bearing
33	DDL-160-S	Ball Crank, Including:	165	DP-678-S	Collar, Including:
34	SP-206	5/16-18 x 5/16" Set Scr.	166	SP-631	7/16-14 x 4" Hex. Hd. Cap Scr.
71	SP-201	5/16-18 x 5/16" Set Scr.	167	DDL-174	29/64 x 1 x 1/8" Std. Washer
150	402-07-014-5006	Bracket	168	902-01-040-1004	7/16"-14 Hex. Nut
151	402-07-020-5003	Cap	169	402-07-351-5001	Gear Rack
152	SP-637	7/16-14 x 3 3/4" Cap Scr.	173	402-05-091-5001	Table
153	SP-5438	7/16"-14 Hex. Jam Nut	174	402-07-005-5001	Base
154	DP-6	33/64 x 1 x 3/16" Collar	175	SP-1124	1/2-13 X 3/4" Soc. Hd. Set Screw
155	DP-663-S	Clamp Handle, Including:			
90	FJ-324	Ball			
156	SP-643	1/2-13 x 4" Hex. Hd. Cap Scr.	*	Not Shown	